

YEAR	MODEL	PART NAME	Per Car	Part No.
<b>Group 2.004 PEDAL, STARTER</b>				
1941-48	All L.H.D.		1	512180
<b>Group 2.016 GUIDE, STARTER PEDAL ROD</b>				
1939-40	P/8	rubber	1	4095471
<b>Group 2.020 PAD, STARTER PEDAL</b>				
1939-48	All L.H.D.		1	408232
<b>Group 2.041 MOTOR AND SWITCH ASSEMBLY, STARTER (L.H.D.)</b>				
1941-48	P/6		1	1107070
1941-48	P/8	use 510965 Gr. 3.430 with this assy. on 1941 thru 47	1	1107947
1949-54	P/6 H.T. & S.T.		1	1107079
1949-54	P/8 H.T. & S.T.		1	1107957
1953	P/6 P.G.		1	1107144
1953	P/8 P.G.		1	1108031
1955	P/8 S.S.		1	1107631
1955	P/8 P.S.		1	1107632
1956	P/8		1	1107641
1935-54	All	<b>BOLT, starter to clutch housing</b> (Hex. $\frac{1}{16}$ "-14x1 $\frac{1}{8}$ ")	2	497289
1955-56	All	(Hex. $\frac{1}{16}$ "-14x1 $\frac{1}{8}$ ")	1	497289
1955-56	All	(Hex. $\frac{1}{16}$ "-14x2 $\frac{3}{4}$ ")	1	122327
<b>Group 2.043 ARMATURE, STARTER MOTOR</b>				
1935-38	All		1	823881
1939-54	All		1	1917855
1955	All		1	1926626
1956	All		1	1932185
<b>Group 2.049 COIL, STARTER MOTOR FIELD</b>				
1935-38	P/6	Upper	1	820153
1935-38	P/6	Lower	1	820154
1935-38,				
1949-54	P/8	Upper	1	826282
1935-38,				
1949-54	P/8	Lower	1	826281
1939-48	P/6	R.H.	1	1921607
1939-48	P/6	L.H.	1	1921608
1939-48	P/8	Upper	1	820153
1939-48	P/8	Lower	1	820154
1949-54	P/6	R.H.	1	1921195
1949-54	P/6	L.H.	1	1921196
1955	All	Upper	1	1927213
1955	All	Lower	1	1926613
1956	All	Upper	1	1932181
1956	All	Lower	1	1932183
<b>Group 2.051 BRUSH, STARTER MOTOR</b>				
1935-54	All		4	811553
1955-56	All		4	1906945
1935-48	All	<b>SCREW, brush attaching</b> (No. 6-32x $\frac{1}{2}$ ")	AR	132705 (8.906)
<b>Group 2.052 HOLDER, STARTER MOTOR BRUSH</b>				
1935-54	All		4	810226
1955-56	All	ground	2	1926617
1955-56	All	insulated	2	1926618
<b>Group 2.053 SPRING, STARTER MOTOR BRUSH</b>				
1935-54	All		4	813521
1955-56	All		2	1926622
<b>Group 2.054 PIN, STARTER MOTOR END FRAME</b>				
1935-54	All	brush holder stop (w/insulation)	2	812015
1935-54	All	brush holder hinge (w/insulation)	2	812016
1935-54	All	brush holder hinge	2	817313
1935-54	All	brush holder stop	2	817314
1955-56	All	brush holder support attaching	2	1926600

<b>Group 2.055</b>		<b>LEAD, STARTER MOTOR BRUSH</b>	
1935-54	All	ground	2 813554
1935-54	All	field	1 819362
1955-56	All	ground	2 1926605
<b>Group 2.063</b>		<b>COLLAR—RING—WASHER, STARTER MOTOR THRUST</b>	
1955-56	All	<b>COLLAR</b> , pinion stop—drive end	1 1927849
1955-56	All	<b>RING</b> , thrust—drive end	1 1927848
1935-56	All	<b>WASHER</b> , commutator end—leather	1 818265
1936-38	P/6	drive end	1 1838568
1939-54	All	drive end	1 1838568
1955-56	All	drive end	1 1927850
<b>Group 2.067</b>		<b>FRAME, STARTER MOTOR (C.E.)</b>	
1935-38	All		1 1908580
1939-54	P/8		1 1908580
1939-54	P/6		1 1907038
1955-56	P/8		1 1926606
<b>Group 2.070</b>		<b>BAND, STARTER MOTOR COMMUTATOR COVER</b>	
1935-54	All		1 817114
<b>Group 2.077</b>		<b>BOLT, STARTER MOTOR THRU</b>	
1935-54	All	( $\frac{1}{4}$ "-20x6 $\frac{1}{16}$ ")	2 809053
1955-56	All		2 1926625
<b>Group 2.083</b>		<b>BUSHING, STARTER MOTOR DRIVE END</b>	
1935-54	All		1 1839345
1955-56	All		1 1923907
<b>Group 2.085</b>		<b>HOUSING, STARTER MOTOR DRIVE, WITH BUSHING</b>	
1941-48	P/6		1 1881794
1941-48	P/8		1 1881846
1949-54	P/6 exc. P.G.		1 1912392
1949-54	P/8 exc. P.G.		1 1912389
1953	P/6 P.G.		1 1928849
1953	P/8 P.G.		1 1928850
1955	P/8 S.S.		1 1930059
1955	P/8 P.S.		1 1930076
1956	P/8		1 1932187
<b>Group 2.086</b>		<b>DRIVE GEAR ASSEMBLY, STARTER MOTOR</b>	
1934-54	All		1 1873789
1955	All		1 1927200
1956	All		1 1932188
<b>Group 2.100</b>		<b>SWITCH ASSY., STARTER MOTOR</b>	
1935-38	P/6		1 820052
1939-48	All		1 820052
1949-52	All L.H.D.	push button	1 1996053
1953-56	All	starter and ignition	1 1116472
1935-38	P/8 L.H.D.	solenoid	1 001546
1949-54	All L.H.D.	solenoid	1 1118140
1955	P/8	solenoid	1 1119760
1956	P/8	solenoid	1 1119781
1949-52	All L.H.D.	<b>BUSHING ASSY.</b> , starter switch to instrument panel.	1 1911548
<b>Group 2.102</b>		<b>CONNECTOR, SOLENOID SWITCH</b>	
1949-54	P/6	to starting motor	1 1912117
1949-54	P/8	to starting motor	1 1912920
1955	P/8	to starting motor	1 1930075
1955-56	P/8	<b>BLOCK</b> , solenoid wires junction	1 520046
1955	P/8	<b>COVER</b> , solenoid wires junction block	1 520195
1955	P/8	<b>WIRE ASSY.</b> , starter to junction block	1 2961689
1956	P/8		1 2964181

(2.188)

Group 2.108		LEVER, STARTER MOTOR DRIVE SHIFT	
1939-40	P/8		1 1882077
1941-48	All	use 510965 throttle cracker stud on S.T.— use 510841 throttle cracker stud on H.T.	1 1885353
1949-54	All		1 1912114
1955	All S.S.		1 1926642
1955	All P.S.		1 1930072
1956	All		1 1932205
1935-55	All	<b>NUT</b> , drive shift lever stud	1 805258
1956	All		1 1926640
1935-38	P/8	<b>PIN</b> , gearshift lever	1 1853305
1949-55	All		1 1853305
1956	All		1 1932204
1935-40	P/6	<b>SPRING</b> , lever return	1 1859742
1941-54	All		1 1881861
1955	All	shift lever return	1 1927763
1956	All		1 1932208
1956	All	shift lever assist	1 1932209
1935-54	P/8 exc. 1939-40 L.H.D.	<b>STUD</b> , drive shift lever	1 1848796
1937-54	P/6 L.H.D.		1 1848796
1955	All		1 1926645
1956	All		1 1932197
1935-54	All	<b>SUPPORT</b> , gearshift lever return spring	1 1835998
Group 2.113		LINK, STARTER MOTOR GEAR SHIFT	
1955	All	<b>LINK</b> , shift lever adj.	1 1927033
1949-54	All	<b>PLUNGER AND LINK ASSY.</b> , starter solenoid	1 1912055
1955	All S.S.		1 1926647
1955	All P.S.		1 1929626
1956	All		1 1932200
1949-55	All	<b>BOOT</b> , starter motor solenoid plunger	1 1912448
Group 2.170		COIL, IGNITION	
1935-47	All		1 1911441
1948-54	All		1 1115378
1955	All		1 1115084
1956	All		1 1115085
Group 2.173		RESISTANCE UNIT, IGNITION COIL	
1955-56	All	12 volt	1 1935134
1955-56	All	<b>SPACER</b> , resistor to dash	1 520294
Group 2.175		RETAINER, COIL TO DISTRIBUTOR WIRE	
1935-48	All		1 494104
1955-56	All		1 494104
Group 2.183		BRACKET, IGNITION COIL MOUNTING	
1949-54	P/6		1 512170
Group 2.187		KEY, LOCK (UNCODED)	
1935-56	All	door and ignition blank, octagon head	2 3694624
1935-56	All	tire, deck, trunk, and inst. panel compt., blank	2 7002238
Group 2.188		CYLINDER, IGNITION LOCK	
1935-56	All		1 1458180
Group 2.188		SWITCH, IGNITION (LESS CYLINDER & KEYS)	
1940-47	All L.H.D.	with cable	1 1116255
1948	All	less cable	1 1116455
1949-52	All	less cable	1 1116464
1953-56	All	starter and ignition	1 1116472
1940-42	All	<b>CLIP</b> , ignition cable to brace	1 504556
1946-47	26 All		1 504556
1949-52	All	<b>NUT</b> , ignition switch to bracket (Hex No. 10-24)	1 510266

<b>Group 2.189</b>		<b>BRACKET, IGNITION SWITCH</b>			
1941-48	All L.H.D.			1	505860
1949-52	All	<b>BRACKET ASS'Y.</b> , ignition switch sup't.		1	512165
1955-56	All L.H.D.	<b>HOUSING ASSY.</b> , ignition lock and lamp support		1	519568
<b>Group 2.192</b>		<b>FERRULE, IGNITION SWITCH LOCK</b>			
1942-48	All			1	507109
1949-52	All			1	515703
1953-54	All			1	1923766
1955	All	and insert		1	1929497
1956	All	and insert		1	1933205
1953-54	All	<b>INSERT</b> , ignition and starter switch		1	515377
<b>Group 2.201</b>		<b>PIPE, DISTRIBUTOR TO CARBURETOR</b>			
1935-56	All	copper tubing—cut to required length ( $\frac{3}{16}$ "x10' coil)	AR	217276	(8.964)
1934-56	All	<b>CONNECTOR</b> , distributor to carb. line (Threaded sleeve $\frac{3}{16}$ " tubing)	AR	152120	(1.740)
1935-52	P/6	<b>ELBOW</b> , distributor to carburetor (Threaded sleeve $\frac{3}{16}$ " )	AR	114890	(8.963)
1934-56	All	<b>NUT</b> , distributor to carb. line (Threaded sleeve $\frac{3}{16}$ " tubing)	AR	114962	(8.963)
<b>Group 2.239</b>		<b>PACKAGE, SPARK PLUG AND COIL WIRES</b>			
1935-48	P/6		1	509151	
1937-47	P/8		1	509152	
1948	P/8		1	511653	
1948-49	P/6	for large towers	1	511870	
1948-49	P/8	for large towers	1	5291015	
1950-54	P/6		1	5290888	
1950-53	P/8		1	5290889	
1954	P/8		1	2961132	
1955	P/8		1	2961714	
1956	P/8		1	2964685	
<b>Group 2.241</b>		<b>CABLE, HIGH TENSION IGNITION</b>			
1935-49	All	7 m/m	100 ft. roll AR	1851208	
<b>Group 2.251</b>		<b>BRACKET, SPARK PLUG WIRE CLAMP</b>			
1949-54	P/6		1	512169	
1955	P/8		2	518212	
1956	P/8		2	521526	
1954	P/8	<b>BRACE</b> , spark plug wire support	1	518875	
1935-48	P/6	<b>CLAMP</b> , spark plug wire	2	404438	
1954	P/8		2	517746	
1948	P/8	<b>COVER</b> , wire manifold	1	511171	
1949-53	P/8		1	511172	
1955	P/8	<b>GROMMET</b> , spark plug wires	2	518217	
1949-53	P/8	<b>MANIFOLD</b> , spark plug wire	1	512172	
1954	P/8	<b>SUPPORT</b> , spark plug wires	1	517747	
<b>Group 2.258</b>		<b>NIPPLE, IGNITION WIRE</b>			
1935-54	All	to distributor cap	w/small towers AR	431508	
1937-52	All	to spark plug—w/type 45 plug	AR	510269	
1948-49	All	to distributor cap	w/large towers AR	1885405	
1948-54	All	to coil	1	510267	
1952-54	All	to spark plug—w/type 44-5 plug	AR	515604	
1955	All	to spark plug	AR	5297901	
1955-56	All	to coil	1	5290441	
1955-56	All	to distributor cap	AR	5289527	
1956	All	to spark plug	8	2962673	
<b>Group 2.270</b>		<b>PLUG, SPARK</b>			
1934-51	All	type 45, 14 m/m	AR	1559493	
1952-55	All	type 44-5, 14 m/m	AR	5569761	
1956	All	type 46, 14 m/m	AR	1559494	
<b>Group 2.271</b>		<b>GASKET, SPARK PLUG</b>			
1935-56	All	for 14 m/m plugs	AR	1555475	



**Group 2.274 PULLEY AND FAN, GENERATOR**

1940-48	All	(3½" dia.)	1	1885475
1946-51	All w/police gen.		1	1880689
1949-52	All exc. heavy duty	(3" dia.)	1	1923266
1953-54	All exc. heavy duty		1	1925294
1955-56	All w/25 amp. gen. exc. A.C.	(2⅞" dia.)	1	1924689
1955-56	All w/A.C.	(2⅞" dia.)	1	1935804
1956	All w/35 amp. gen. exc. A.C.		1	1925586
1951-54	All w/heavy duty gen.		1	1880558
1955	All w/35 amp. police gen.		1	1866400
1955-56	All w/A.C.		1	1922950
1951-54	All w/heavy duty gen.		1	1881158

**FAN**

**PULLEY**

**Group 2.275 NEW GENERATOR ASSEMBLIES**

1940-50	All	less pulley (35 amp.)—exchange item	1	1102810
1946-51	All w/police gen.	less pulley—no exchange item	1	1106403
1951-54	All w/heavy duty gen.	less pulley—no exchange item	1	1105008
1951	All exc. police & h.d. gen.	less pulley (40 amp.)—exchange item	1	1102717
1951-52	All exc. heavy duty gen.	less pulley (45 amp.)—exchange item	1	1102785
1953-54	All exc. heavy duty	less pulley—exchange item	1	1102797
1955-56	All w/25 amp. gen.	less pulley—exchange item	1	1100313
1955	All w/30 amp. gen.	less pulley—exchange item	1	1102012
1955	All A.C.	less pulley (35 amp.)	1	1102039
1956	All w/35 amp. gen.	less pulley	1	1102055

**Group 2.275 REBUILT GENERATOR ASSEMBLIES**

1940-50	All	less pulley (9U) exchange item	1	1102742
---------	-----	--------------------------------	---	---------

The following list of used Delco Remy Generators are acceptable for exchange credit on the purchase of either new or rebuilt generator assemblies. These model numbers are stamped on the generator identification plate.

7-U	1100304	1102665	1102710	1102742	1102778	1102797
9-U	1100313	1102667	1102711	1102744	1102780	1102803
72-U	1102012	1102672	1102717	1102749	1102785	
85-U	1102018	1102680	1102719	1102761	1102793	
94-U	1102664	1102701	1102737	1102769	1102794	

**Group 2.275 BOLT, GENERATOR MOUNTING**

1933-54	All	bracket to block	(Hex. ⅜"-18x¼")	1	180077	(8.900)
1937-54	All	generator to bracket, long	(Hex. ⅜"-24x1¼")	2	181610	(8.900)
1940-51	All w/police gen.	generator to bracket	(Hex. ⅜"-20x2")	2	124133	(8.900)
1955-56	All w/25 amp. gen.	generator to bracket	(Hex. ⅜"-24x1")	2	181608	(8.900)
1955-56	All w/30 & 35 amp. gen.	generator to bracket	(Hex. ⅜"-24x1¼")	2	181639	(8.900)
1955-56	All exc. A.C.	bracket to manifold	(Hex. ⅜"-16x¼")	2	180120	(8.900)
1933-56	All exc. A.C. and police gen.	NUT, generator mounting bolt	Special	2	517011	

**Group 2.277 BRACKET, GENERATOR MOUNTING**

1935-51	All exc. police gen.		Rear	1	505573
1940-48	All with police gen.		Front	1	504945
1941-51	All w/police gen.		Rear	1	512362
1952-54	All		Rear	1	505573
1955-56	All w/police gen.	auxiliary 6 volt generator		1	518000
1955-56	All exc. A.C.			1	518073
1956	All A.C.			1	522520
1955-56	All heavy duty exc. A.C.	SPACER, generator mounting	Rear	1	518847

**Group 2.279 ARMATURE, GENERATOR**

1935-39	All		1	1871826
1940-50	All		1	1921235
1951	All exc. police gen.	use w/40 amp. gen.	1	1912599
1951-54	All heavy duty		1	1918009
1951-54	All exc. heavy duty gen.		1	1912599
1955-56	All w/25 amp. gen.		1	1928952
1955	All w/30 amp. gen.		1	1923535
1955-56	All w/35 amp. gen.		1	1932900

**Group 2.280 NUT, GENERATOR ARMATURE SHAFT**

1935-56	All		1	806915
---------	-----	--	---	--------

**Group 2.285 BRUSH, GENERATOR**

1940-51	All		2	1906917
1952-55	All exc. heavy duty gen.		2	1923295
1952-56	All exc. A.C. and heavy duty	to eliminate excessive brush noise	2	1906946
1954	All heavy duty		2	1906931
1955	All w/35 amp. gen.		2	1906931
1956	All		2	1923295
1933-39	All	BRUSH PACKAGE	1	1857963

<b>Group 2.286</b>		<b>SPRING, GENERATOR BRUSH</b>			
1940-51	All.....	.....	.....	2	1878184
1952-55	All exc. heavy duty gen.....	.....	.....	2	1908829
1955	All w/35 amp. gen.....	.....	.....	2	1878184
1956	All.....	.....	.....	2	1908829
<b>Group 2.287</b>		<b>PLATE, GENERATOR BRUSH</b>			
1940-48	All.....	.....	.....	1	1878177
<b>Group 2.291</b>		<b>ARM, GENERATOR BRUSH</b>			
1940-56	All.....	.....	.....	2	1878183
<b>Group 2.297</b>		<b>FRAME, GENERATOR COMMUTATOR END (With Bushing)</b>			
1940-51	All exc. police gen.....	.....	.....	1	1913990
1952-54	All exc. heavy duty gen.....	.....	.....	1	1933933 ■
1955-56	All exc. A.C. & police gen.....	.....	.....	1	1927596
1955	All A.C.....	.....	.....	1	1930826
1955	All w/35 amp. police gen.....	.....	.....	1	1929712
1956	All w/35 amp. gen.....	.....	.....	1	1934298
<b>Group 2.298</b>		<b>BUSHING, GENERATOR COMMUTATOR END FRAME</b>			
1935-48	All.....	.....	.....	1	812823
<b>Group 2.299</b>		<b>BAND, GENERATOR COMMUTATOR COVER</b>			
1935-51	All.....	.....	.....	1	816340
<b>Group 2.300</b>		<b>GASKET, GENERATOR COMMUTATOR END DUST</b>			
1935-48	All.....	.....	.....	1	817220
<b>Group 2.301</b>		<b>OIL FITTINGS, GENERATOR COMMUTATOR END</b>			
1935-48	All.....	wick, oil.....	felt.....	1	804076
<b>Group 2.305</b>		<b>FRAME PACKAGE, GENERATOR DRIVE END</b>			
<b>NOTE:</b> Package consists of 1 drive end frame, 1 plate and 1 gasket.					
1937-52	All.....	.....	.....	1	1910404
1953-54	All exc. heavy duty.....	.....	.....	1	1925295
1955-56	All w/25 and 30 amp. gen.....	.....	.....	1	1927598
1955	All w/35 amp. gen.....	.....	.....	1	1930823
1955	All w/35 amp. police gen.....	.....	.....	1	1929568
1956	All w/35 amp. gen.....	.....	.....	1	1934300
<b>Group 2.306</b>		<b>BEARING, GENERATOR</b>			
1935-51	All exc. police gen.....	drive end.....	.....	1	954378
1952-56	All.....	drive end.....	.....	1	954378
<b>Group 2.307</b>		<b>COLLAR—GASKET—PLATE—SCREW—WASHER, GENERATOR DRIVE END</b>			
1935-56	All.....	<b>COLLAR</b> , spacer.....	.....	1	1858603
1935-56	All.....	<b>GASKET</b> , bearing retainer plate.....	.....	1	1912008
1935-56	All.....	<b>PLATE</b> , bearing retainer.....	.....	1	1911263
1937-56	All.....	<b>SCREW</b> , bearing retainer plate.....	.....	3	1904370
1935-54	All.....	<b>LOCKWASHER</b> , bearing retainer plate screw..... (3/16")	.....	3	802731
1935-56	All.....	<b>WASHER</b> , bearing spacer—inside.....	.....	1	809945
1935-56	All.....	bearing felt.....	.....	1	809961
1935-56	All.....	<b>OILER</b> .....	.....	1	125609
1955	All w/25 and 30 amp. gen.....	.....	.....	1	1927598
1955	All w/35 amp. gen.....	.....	.....	1	1880641
<b>Group 2.310</b>		<b>COIL UNIT, GENERATOR FIELD</b>			
1940-48	All.....	.....	.....	1	1902111
1949-50	All exc. police gen.....	.....	.....	1	1912654
1951-54	All exc. heavy duty gen.....	.....	.....	1	1922702
1955-56	All w/25 amp. gen.....	.....	.....	1	1927700
1955	All w/30 amp. gen.....	.....	.....	1	1922701
1955	All w/35 amp. gen.....	.....	R.H.....	1	1923472
1955	All w/35 amp. gen.....	.....	L.H.....	1	1923473
1955	All w/35 amp. police gen.....	.....	.....	1	1931686
1956	All w/35 amp. gen.....	.....	.....	1	1931686

(8.984)

<b>Group 2.313</b>		<b>STUD—BUSHING—WASHER, GENERATOR</b>			
1935-48	All	<b>STUD</b> , w/terminal	1	1858754	
1951-56	All	field terminal	1	1921860	
1951-56	All	armature terminal	1	1921369	
1951-56	All	<b>BUSHING</b> , armature terminal	1	1921362	
1951-56	All	<b>WASHER</b> , field terminal stud insulator	1	1858753	
<b>Group 2.316</b>		<b>BOLT, GENERATOR THRU</b>			
1940-54	All		2	809763	
1955-56	All w/25 and 30 amp. gen.		2	809763	
1955	All w/35 amp. gen.		2	1845053	
<b>Group 2.317</b>		<b>STRAP, GENERATOR ADJUSTING</b>			
1937-48	All		1	499777	
1949-51	All w/police gen.		1	512363	
1949-51	All exc. police gen.		1	516634	
1952-54	All		1	516634	
1955-56	All exc. A.C.		1	518072	
1955	All A.C.		1	519056	
1956	All A.C.		1	522521	
1935-54	All exc. police gen.	<b>SPACER</b> , generator adjusting strap	1	499778	
1933-54	All	<b>WASHER</b> , generator adj. strap to gen. (Special $\frac{5}{16}$ " )	1	525083	
1955-56	All exc. A.C.		1	518266	
1955	All A.C.		1	520785	
<b>Group 2.332</b>		<b>BATTERY—FLUID, ELECTRIC STORAGE</b>			
1935-37	P/6	<b>BATTERY</b> , type 1M70—wet	6 volt	1	1890497
1935-37	P/6	type 1MR105—dry	6 volt	1	1890573
1935-37	P/8	type 2HR130—wet	6 volt	1	1890506
1935-37	P/8	type 17K—wet	6 volt	1	1890376
1935-37	P/8	type 2MR120—dry (use w/1890639)	6 volt	1	1890584
1935-37	All	type 1HR115—dry (use w/1890638)	6 volt	1	1890539
1935-37	All	type 1M72—dry (use w/1890638)	6 volt	1	1890678
1938-54	All	type 2E92—dry (use w/1890639)	6 volt	1	1890681
1938-54	All	type 2ER130—dry (use w/1890639)	6 volt	1	1890542
1938-54	All	type 2ER120—dry (use w/1890639)	6 volt	1	1890576
1955-56	All	type 2SM41—dry (use w/1890639)	12 volt	1	1890700
1955-56	All	type 2SMR53—dry (use w/1890638)	12 volt	1	1890590
1955-56	All	type 2SMR60—dry (use w/1890638)	12 volt	1	1890563
1955-56	All	type 3SMR72—dry (use w/1890639)	12 volt	1	1890569
All	All	<b>FLUID</b> , electrolyte—use w/2, 2E, 2F, 3EM, 3EK and 3SM type batteries		1	1890639
All	All	use w/1, 2L, 2N, 2SM and 3N type batteries		1	1890638
All	All	<b>DATE RING</b> , dry battery stamp		1	3726416
<b>Group 2.333</b>		<b>BRACKET—BRACE—SUPPORT, BATTERY</b>			
1949-52	All	<b>BRACKET</b> , battery support to frame	Rear	1	511863
1949-52	All		Front	1	511862
1953-54	All		Front	1	515405
1953-54	All		Rear	1	515406
1955-56	All	to fender skirt		2	518906
1949-52	All	<b>BRACE</b> , battery to fender skirt		2	511864
1953-54	All			2	515382
1955-56	All			1	520055
1938-54	All	<b>SUPPORT</b>		1	501214
1955-56	All w/std. btry.			1	518907
1955-56	All w/heavy duty btry.			1	519824
1955-56	All	<b>SPACER</b> , battery		4	522205
1955-56	All	<b>NUT</b> , battery to fender skirt brace		2	520054
1940-48	All	<b>SCREW</b> , battery support to frame. (Hex. $\frac{5}{16}$ "-18x $3\frac{3}{4}$ " )		1	171104
1949-54	All	battery support to frame. (Hex. $\frac{3}{8}$ "-16x $\frac{5}{8}$ " )		5	171121
<b>Group 2.334</b>		<b>RETAINER, BATTERY</b>			
1938-48	All			1	508673
1955-56	All w/std. btry.			1	520297
1955-56	All w/heavy duty btry.			1	519590
1938-56	All	<b>BOLT</b> , battery hold down (Carr. $\frac{5}{16}$ "-18x $3\frac{3}{4}$ " )		2	508676
1928-42	All	<b>NUT</b> , battery clamp bolt (Hex. $\frac{5}{16}$ "-18)	AR	1	120376
1946-56	All	(Hex. Spec. $\frac{5}{16}$ "-18)		2	508677
<b>Group 2.335</b>		<b>COVER—CLIP—PLATE, BATTERY</b>			
1949-54	All	<b>COVER</b>		1	417420
1949-54	All	<b>CLIP</b> , cover		1	554834
1949-54	All	<b>PLATE</b> , battery filler hole cover		1	417422
<b>Group 2.337</b>		<b>BUMPER, BATTERY TO FENDER APRON</b>			
1949-54	All			2	506351

**Group 2.341 STRAP, BATTERY GROUND**

**NOTE:** Length measured from center to center of holes.

1938-54	All	-----	16 1/2" long	1	5286925
1955-56	All	-----	20 1/2" long	1	2963169
		see Group 2.342 for use	-----		5286911

**Group 2.342 LEAD, BATTERY POSITIVE**

**NOTE:** Length measured from center to center of holes.

1937	All	-----	30" long	1	5286913
1938-48	All exc. P/B 1938	-----	16 1/2" long	1	5286909
1949-54	P/6	-----	27" long	1	5286912
1949-54	P/8	-----	23 1/2" long	1	5286911
1955	All	-----	46 1/2" long	1	2961755
1956	All	-----	-----	1	2964182

(2.341)

**Group 2.343 BRACKET—CLIP—NUT AND BOLT, BATTERY CABLE**

1955-56	All	BRACKET, battery ground strap	-----	1	520196
1955	All	CLIP, battery cable	-----	1	520206
1935-56	All	NUT AND BOLT, battery terminal	-----	2	1846534

**Group 2.360 DISTRIBUTOR REPAIR KIT**

1937-48	P/8	-----	-----	1	1913500
1937-48	P/6	-----	-----	1	1913502
1949-54	P/6	-----	-----	1	1912609
1949-54	P/8	-----	-----	1	1917253
1955-56	P/8	-----	-----	1	1925369

**Group 2.361 DISTRIBUTOR, IGNITION**

1937-52	P/6	less cap and rotor	-----	1	1912884
1937-54	P/8	less cap and rotor	-----	1	1912885
1953	P/6	less cap and rotor—w/7.7 ratio head	-----	1	1925987
1953	P/6	less cap and rotor—w/7.0 ratio head	-----	1	1925988
1954	P/6	less cap and rotor—w/7.7 ratio head	-----	1	1928820
1954	P/6	less cap and rotor—w/7.0 ratio head	-----	1	1928821
1955	P/8	less cap and rotor	-----	1	1930531
1956	P/8	less cap and rotor	-----	1	1934591

**Group 2.362 HOUSING, DISTRIBUTOR**

1940-48	P/8	-----	-----	1	1878878
1949-53	P/6	-----	-----	1	1912602
1949-54	P/8	-----	-----	1	1912670
1954	P/6	-----	-----	1	1927351
1955-56	P/8	-----	-----	1	1927384

**Group 2.363 BUSHING, DISTRIBUTOR HOUSING**

1937-54	P/8	-----	-----	1	1874335
1949-54	P/6	-----	-----	1	1874335
1955-56	All	-----	Upper	1	1923250
1955-56	All	-----	Lower	1	1927386
1933-54	All	GASKET, distributor to block	-----	1	495206
1955-56	P/8	-----	-----	1	516149

**Group 2.364 WICK, DISTRIBUTOR SHAFT OIL**

1935-48	P/6	-----	-----	1	816803
1935-48	P/8	-----	-----	1	819639
1949-56	All	-----	-----	1	819639
1935-54	All	GREASE CUP, distributor hsg.	AR	1	805579
All	All	LUBRICANT, distributor cam and bearing	AR	1	1912969
1955-56	All	OILER ASSY., distributor	-----	1	1927396

**Group 2.367 CAP, DISTRIBUTOR**

1935-54	P/8	with small towers	-----	1	1837974
1935-53	P/6	with small towers	-----	1	824735
1948-49	P/8	with large towers (radio)	-----	1	1911566
1948-49	P/6	with large towers (radio)	-----	1	1911597
1954	P/6	-----	-----	1	1924248
1955-56	P/8	-----	-----	1	1917247

**Group 2.368 SPRING, DISTRIBUTOR CAP RETAINER**

1935-54	P/6	-----	-----	2	1871838
1949-56	P/8	-----	-----	2	1909594

**Group 2.369 SUPPORT, DISTRIBUTOR CAP RETAINER SPRING**

1935-48	P/6	-----	-----	2	1847289
1949-56	All	-----	-----	2	1847289
1935-54	P/8	SUPPORT PKG. (Contains 1 spring and 1 support)	-----	2	1911336



<b>Group 2.372</b>		<b>SHAFT, DISTRIBUTOR MAIN</b>	
1937-48	P/8		1 1866458
1937-48	P/6		1 1866886
1949-51	P/8		1 1923045
1949-52	P/6		1 1912607
1953	P/6		1 1925242
1954	P/6		1 1927354
1955	P/8		1 1927388
1956	P/8		1 1933383
<b>Group 2.375</b>		<b>GEAR, DISTRIBUTOR DRIVE</b>	
1955-56	P/8		1 1927398
<b>Group 2.379</b>		<b>COLLAR—PIN, DISTRIBUTOR SHAFT</b>	
1935-48	P/8	<b>COLLAR, distributor shaft</b>	1 819741
1935-48	P/6		1 1858578
1949-54	All		1 821865
1937-54	All	<b>PIN, collar attaching</b>	1 813131
1955-56	P/8	gear attaching	1 822273
1935-54	All	<b>WASHER, dist. shaft spacer</b>	AR 810074
1935-54	All	(.005" thick)	AR 810078
1955-56	All	(.010" thick)	AR 1848595
1955-56	All	(.005" thick)	AR 1848596
1955-56	All	(.010" thick)	AR 1848596
			1 1266718
<b>Group 2.381</b>		<b>CAM ASSEMBLY, DISTRIBUTOR</b>	
1937-48	P/8		1 1866456
1937-48	P/6		1 1867181
1949-54	P/8		1 1912674
1949-52	P/6		1 1912605
1953	P/6		1 1913882
1954	P/6		1 1927356
1955	P/8		1 1929565
1956	P/8		1 1927126
<b>Group 2.382</b>		<b>ROTOR, DISTRIBUTOR</b>	
1935-54	P/8		1 1836893
1935-53	P/6		1 820445
1954	P/6		1 1924245
1955-56	P/8		1 1927393
<b>Group 2.384</b>		<b>POINT PACKAGE, DISTRIBUTOR</b>	
<b>NOTE: Point Package consists of 1 Breaker Arm and 1 Support with Points.</b>			
1937-54	P/6		1 1871678
1937-56	P/8		1 1918148
<b>Group 2.385</b>		<b>PLATE, DISTRIBUTOR BREAKER</b>	
1949-54	P/6		1 1912783
1949-54	P/8		1 1912784
1955-56	P/8		1 1925439
1935-48	All	<b>BALL, steel</b> (1/4" dia.)	3 104918
1937-48	P/8	<b>REPAIR PKG., dist. breaker plate and brgs.</b>	1 1914446
1937-48	P/6		1 1914448
1949-54	P/6	<b>RETAINER, dist. breaker plate</b>	1 1912614
1949-56	P/8		1 1912226
1949-54	All	<b>SPRING, dist. breaker plate washer</b>	1 1912227
1955-56	All		1 1925375
1949-54	All	<b>WASHER, dist. breaker plate</b>	AR 1912225
1949-55	All	dist. breaker plate brg.	Fiber 1 1912224
1949-54	All	dist. breaker plate stop	1 1869357
1956	All	dist. breaker plate brg.	Fiber 1 1927778
<b>Group 2.387</b>		<b>SCREW, DISTRIBUTOR CONTACT POINT SUPPORT CLAMP</b>	
1935-56	All	(No. 8-32x3/16")	1 816784
1935-56	All	<b>NUT, distributor contact point support clamp screw</b>	1 817363
1937-55	All	<b>SCREW, distributor contact arm spring</b>	1 1858576
1937-48	P/8	<b>LOCK CLIP, distributor contact arm tension spring screw</b>	1 1868992
1949-56	All		1 1868992
1937-48	All	<b>WASHER, distributor contact arm spring screw insulator</b>	1 1865977
<b>Group 2.388</b>		<b>WEIGHT, DISTRIBUTOR</b>	
1935-54	P/8		2 1880902
1937-52	P/6		2 1881371
1953-54	P/6		2 1880902
1955-56	P/8		2 1881371

(8.899)

<b>Group 2.389</b>		<b>SPRING, DISTRIBUTOR WEIGHT</b>			
1935-48	P/6.....	.....	.....	2	823238
1937-48	P/8.....	.....	.....	2	829567
1949-51	P/8.....	.....	.....	2	1887553
1949-52	P/6.....	.....	.....	2	1887743
1953-54	P/6.....	.....	.....	2	1925251
1952-54	P/8.....	.....	.....	2	1884610
1955	P/8.....	.....	.....	2	1886277
1956	P/8.....	.....	.....	2	1933350
<b>Group 2.390</b>		<b>PLATE, DISTRIBUTOR WEIGHT HOLD DOWN</b>			
1949-56	All.....	.....	.....	1	1885557
<b>Group 2.393</b>		<b>CONDENSER, DISTRIBUTOR</b>			
1937-56	All.....	with bracket and lead.....	.....	1	1869704
<b>Group 2.400</b>		<b>LEAD-NUT-STUD, DISTRIBUTOR TERMINAL</b>			
1937-56	All.....	<b>LEAD ASSEMBLY</b> , distributor terminal.....	.....	1	1865978
1937-54	All.....	<b>LEAD</b> , distributor breaker plate ground.....	.....	1	1879140
1938-55	All.....	<b>NUT</b> , distributor terminal stud.....	.....	1	817363
1935-50	All.....	<b>STUD</b> , distributor terminal, w/bushing.....	.....	1	1853625
					(2.387)
<b>Group 2.401</b>		<b>BUSHING-CLIP-SCREW, DISTRIBUTOR TERMINAL</b>			
1935-48	All.....	<b>BUSHING</b> , distributor contact arm screw.....	.....	1	1904600
1937-48	All.....	distributor terminal stud—inside housing.....	.....	1	1865985
1949	All.....	.....	.....	1	1912229
1935-50	All.....	<b>CLIP</b> , distributor terminal.....	.....	1	026153
1935-48	All.....	<b>SCREW</b> , distributor terminal... (Rd. Hd. No. 8-32x $\frac{3}{8}$ ").....	.....	3	121832
					(8.906)
<b>Group 2.410</b>		<b>VACUUM CONTROL, DISTRIBUTOR</b>			
1937-52	P/6.....	.....	.....	1	1116051
1940-54	P/8.....	.....	.....	1	1116050
1953	P/6.....	.....	.....	1	1116077
1954	P/6.....	.....	.....	1	1116079
1955-56	P/8.....	.....	.....	1	1116080
<b>Group 2.414</b>		<b>CLAMP, DISTRIBUTOR ADJUSTING</b>			
1939-40	All exc. P/8 1939.....	with arm.....	.....	1	1873331
1941-49	P/8.....	with arm.....	.....	1	1873331
1941-49	P/6.....	with arm.....	.....	1	1914530
1950-54	All.....	with arm.....	.....	1	1914530
1955-56	All.....	hold down.....	.....	1	518068
<b>Group 2.420</b>		<b>COUPLING, DISTRIBUTOR VACUUM CONTROL</b>			
1937-48	P/8.....	.....	.....	1	1866166
<b>Group 2.421</b>		<b>GASKET, DISTRIBUTOR VACUUM CONTROL COUPLING</b>			
1935-48	All.....	.....	.....	1	1841901
1955-56	All.....	to housing.....	.....	1	1917246
<b>Group 2.447</b>		<b>SWITCH, STOPLIGHT</b>			
1935-39	All.....	.....	.....	1	403936
1940-54	All.....	.....	.....	1	1997725
1955	All L.H.D., S.B.....	.....	.....	1	1997919
1955	All P.B.....	.....	.....	1	1998104
1956	All L.H.D., P.B.....	.....	.....	1	1998142
1956	All L.H.D., S.B.....	.....	.....	1	1997923
<b>Group 2.459</b>		<b>SWITCH, DIMMER</b>			
1935-56	All.....	.....	.....	1	1997008
1955-56	All L.H.D.....	<b>SHIELD</b> , dimmer switch.....	.....	1	521845

**Group 2.480 HARNESS, CHASSIS WIRING (L.H.D.)**

1941	All		1	1882504
1942-47	All		1	1885004
1948	All	except cars with direction signal	1	5288134
1948	All	cars with direction signal	1	5288490
1949-50	All	except cars with direction signal	1	5291191
1949-50	All	cars with direction signal	1	5291192
1951-52	All	except cars with direction signal	1	5291063
1951-52	All	cars with direction signal	1	5291062
1953-54	All	cars with direction signal	1	5292828
1955	All	cars with direction signal	1	2961359
1956	All	cars with direction signal	1	2964180

**Group 2.482 CLAMP, WIRE ASSEMBLY THRU DASH**

1949-50	All	<b>CLAMP ASSY.,</b> main wire and speedo. cable dash	1	514117
1951-54	All		1	514372
1955	All		Upper	519609
1955	All		Lower	519607
1956	All		Upper	522648
1956	All		Lower	522652
1949-54	All exc. 1949 2567	<b>CLAMP ASSY.,</b> accessory wires	1	512260
1949	2567		1	512262
1955-56	All		1	519604
1953-54	All	<b>MANIFOLD ASSY.,</b> wires to dash	Left side	515452
1953-54	All		Center	515449
1949-54	All	<b>PLATE,</b> speedo. cable and wiring harness cover	1	512517
1955-56	All		1	519847
1949-54	All	<b>FELT,</b> speedo. cable and wiring harness cover plate	1	512518
1955-56	All		1	519848

**Group 2.483 BLOCK, ACCESSORY FUSE AND TERMINAL**

1949-50	All		1	1998777
1951-52	All		1	1998783
1953-54	All		1	1998785
1955-56	All		1	520217
1949-50	All	<b>COVER,</b> accessory fuse and terminal block	1	512109
1951	All		1	514681
1952	All		1	516514
1953-54	All		1	515446
1955	All	<b>RETAINER,</b> fuse and terminal block wires	1	519503
1956	All		1	521970

**Group 2.485 SWITCH, LIGHT**

1938	All L.H.D.		1	1995002
1939	All L.H.D.		1	1995006
1942-48	All		1	1995035
1949-54	All		1	1995052
1955-56	All		1	1995059

**Group 2.486 KNOB, LIGHT SWITCH CONTROL**

1941	All		1	505715
1942-48	All		1	507216
1949-50	All		1	511828
1951-52	All	black	1	515708
1953-54	All	black—chrome insert	1	516942
1955	All		1	518909
1956	All		1	522296

**Group 2.487 SPACER, KNOB TO INSTRUMENT PANEL**

1941-48	All	light switch mounting—behind panel	1	511508
1955-56	All	<b>BRACKET,</b> light switch mounting	1	519502
1941-48	All	<b>BUSHING,</b> light switch knob	1	505825
1949-52	All		1	511754
1953-55	All		1	515441
1956	All		1	1165135
1949-52	All	<b>FERRULE,</b> lighting switch	1	515699
1953-54	All		1	516921
1955-56	All		1	518908
1941-48	All	<b>FLANGE,</b> light switch mounting	1	505826

**2.500-2.560**

**Group 2.500 REGULATOR ASSEMBLY, VOLTAGE AND CURRENT CONTROL**

1938-39	1938 P/6, 39 All.....		1	1118309	
1940-50	All exc. police gen.....		1	1118301	
1948-51	All w/police gen.....		1	1118352	
1951	All w/40 amp. gen.....		1	1118300	
1951-54	All w/heavy duty gen.....		1	1118835	
1951-54	All w/45 amp. gen.....		1	1118827	
1955	All w/25 amp. gen.....		1	1118945	
1955	All A.C. and heavy duty.....		1	1118967	
1956	All w/25 amp. gen.....		1	1119000	
1956	All A.C. and 35 amp. gen. ...		1	1119002	
1955	All.....	<b>BRACKET, regulator mounting</b> .....	1	520211	
1956	All.....		1	522065	

**Group 2.515 AMMETER, INSTRUMENT PANEL**

1940	All.....		1	857886	
1941	All.....		1	1500383	
1942	All.....		1	1500464	
1946	All.....		1	1500759	
1947	All.....		1	1500880	
1948	All.....		1	1501065	
1949-50	All.....		1	1501156	
1951-52	All.....		1	1501286	
1953-54	All.....		1	1501357	
1955	All.....		1	1501607	
1956	All.....		1	1501748	

**Group 2.525 CONNECTOR-GROMMET, FUEL GAUGE WIRE**

1941-48	All exc. sta. wag.....	<b>CONNECTOR, fuel gauge wire</b> .....	1	3114169	<b>(2.649)</b>
1939	All.....	<b>GROMMET, fuel gauge wire rear</b> compartment..... (3/8" I.D.)	1	216551	<b>(9.775)</b>
1949-52	2561-62-71 All.....	fuel tank to body harness.....	1	5289293	

**Group 2.530 CABLE, ELECTRICAL**

All	All.....	16 gauge..... 100 ft. roll	AR	5298971	
All	All.....	14 gauge..... 100 ft. roll	AR	5298978	
		see Group 2.697 for use.....		5289849	

**Group 2.548 NUT, HEADLAMP ANCHOR**

1939-48	All.....	see Group 2.725 for use.....	8	120375	<b>(8.915)</b>
				413395	

**Group 2.550 BRACKET, HEADLAMP**

1937	All.....		R.H.	1	500180	
1937	All.....		L.H.	1	500181	
1938	All.....	<b>SCREW, headlamp bracket</b> plate..... (Flt. Hd. No. 10-32x1/2")		AR	133634	<b>(8.908)</b>

**Group 2.560 BLOCK ASSEMBLY, HEADLAMP WIRE JUNCTION**

1939-54	All.....			2	1998792 ■	
1948	All L.H.D.....			2	1998763	
1955-56	All.....		R.H.	1	520947	
1955-56	All.....		L.H.	1	520948	



**Group 2.585 LAMP ASSY., PARKING**

NOTE: When Parking Lamp Assy. is used with direction signal see Group 2.899 for Wire and Socket.

1941	All		L.H.	1	916359
1942	All	glass lens—painted	R.H.	1	917172
1942	All	glass lens—painted	L.H.	1	917171
1942	All	lucite lens—chrome	R.H.	1	917058
1942	All	lucite lens—chrome	L.H.	1	917057
1946	All	glass lens—chrome	R.H.	1	917302
1946	All	glass lens—chrome	L.H.	1	917301
1947	All		R.H.	1	928512
1947	All		L.H.	1	928511
1948	All		L.H.	1	928529
1948	All		R.H.	1	928530
1949	All		R.H.	1	928550
1949	All		L.H.	1	928549
1950	All		R.H.	1	928094
1950	All		L.H.	1	928093
1951	All	w/die cast chrome door	R.H.	1	928994
1951	All	w/die cast chrome door	L.H.	1	928593
1951-52	All	w/stamped chrome door	R.H.	1	928696
1951-52	All	w/stamped chrome door	L.H.	1	928695
1953	All		R.H.	1	928282
1953	All		L.H.	1	928281
1954	All		R.H.	1	928804
1954	All		L.H.	1	928803
1955	All		R.H.	1	897588
1955	All		L.H.	1	897587
1956	All		R.H.	1	897934
1956	All		L.H.	1	897933

**Group 2.586 BODY, PARKING LAMP**

1946	All			2	5935892
------	-----	--	--	---	---------

**Group 2.587 BRACKET—PLATE—SUPPORT, PARKING LAMP**

1955	All	BRACKET, parking lamp mounting	R.H.	1	5945786
1955	All		L.H.	1	5945785
1954	All	PLATE ASSY., parking lamp mounting	Inner	2	5945171
1954	All		Outer	2	5945173
1941	All	SUPPORT		2	505340
1946	All			4	508494
1947	All			4	509546
1948	All			4	510541
1941,					
1946-48	All	BOLT, parking lamp support... (Hex. No. 10-24x $\frac{1}{8}$ "		2	187572 (8.900)
1954-55	All	SCREW, mounting plate to body		8	5942856
1956	All	parking lamp lens		4	5946849 ■ (2.688)

**Group 2.589 LENS, PARKING LAMP**

1940	All	fender lamp		2	5930136
1942	All	with direction signal		2	5932902
1942	All	without direction signal, lucite		2	5933423
1946	All			2	5935895
1947	All		R.H.	1	5936792
1947	All		L.H.	1	5936791
1948	All			2	5937577
1949	All			2	5938308
1950	All			2	5939313
1951-52	All			2	5939984
1953	All			2	5940671
1954	All		R.H.	1	5945178
1954	All		L.H.	1	5945177
1955	All		R.H.	1	5945790
1955	All		L.H.	1	5945789
1956	All			2	5946847

**Group 2.590 GASKET, PARKING LAMP LENS**

1940	All	fender lamp		2	5930153
1942	All			2	5932958
1946	All			2	5935896
1947-48	All			2	5936778
1949	All			2	5938311
1950-53	All			2	5939312
1954	All			2	5945179
1955	All			2	5945799
1956	All			2	5946848
		see Group 2.697 for use		2	5935956

**Group 2.593 CAP—FRAME—DOOR, PARKING LAMP**

1942	All	CAP	R.H.	1	507137
1942	All		L.H.	1	507138
1946	All	FRAME	R.H.	1	5935894
1946	All		L.H.	1	5935893
1955	All		R.H.	1	5945788
1955	All		L.H.	1	5945787
1949	All	DOOR	R.H.	1	5938310
1949	All		L.H.	1	5938309
1950	All		R.H.	1	5939316
1950	All		L.H.	1	5939315
1951	All	die cast—chrome 1st type	R.H.	1	5942576
1951	All	die cast—chrome 1st type	L.H.	1	5942575
1951-52	All	stamped—chrome 2nd type on 1951	R.H.	1	5942184
1951-52	All	stamped—chrome 2nd type on 1951	L.H.	1	5942183
1953	All		R.H.	1	5943806
1953	All		L.H.	1	5943805
1954	All		R.H.	1	5945176
1954	All		L.H.	1	5945175
1955	All	SCREW, parking lamp frame to body		4	5945852

**Group 2.594 SEAL, PARKING LAMP**

1949-50	All		Rubber	2	511432
1951-53	All		Rubber	2	514749
1956	All		Rubber	2	521485
		see Group 2.697 for use			5933049

**Group 2.596 SOCKET AND WIRE, PARKING LAMP**

1942	All	without direction signal		2	5932995
1946-47	All	without direction signal		2	5935897
1948	All	without direction signal		2	5937342
1949	All	without direction signal		2	5938314
1950-52	All	without direction signal		2	5939328
1954	All	RETAINER, parking lamp wire seal		2	517660
1954	All	SEAL, parking lamp wire		2	517695
1939	All	SCREW, fender lamp door (No. 8-32x1")		2	923315

(2.688)

**Group 2.646 WIRE ASSEMBLY, TAIL LAMP**

1941-47	All	tail lamp fuse		1	1882029
1948	All	tail lamp fuse		1	5287898
1941-47	Sta. wag.	dual tail lamp jumper		1	506482

**Group 2.649 CONNECTOR, LAMP WIRE**

1939-40	All exc. sta. wag.	2-wire—single lamp		2	3114169
1939-52	All exc. sta. wag.	3-wire—dual lamps		2	1872486
1940-54	All exc. sta. wag. & 2571	plug type terminal		2	1242002
1955-56	All	5 wire—strg. col. wires to main wire assy.		1	2962408
1955	All	3 wire—strg. col. wires to dome lamp and body wires		1	2962036

**Group 2.652 CLIP, FUEL GAUGE WIRE**

1939-48	All	wire to frame (Snap spring type 1/4")		2	177952
---------	-----	---------------------------------------	--	---	--------

(8.950)

**Group 2.660 PAD, TAIL LAMP**

1941-47	25 All	to body, with die cast lamp		2	506405
1941-47	2607 All	to body, with die cast lamp	R.H.	1	506059
1941-47	2607 All	to body, with die cast lamp	L.H.	1	506060
1941-47	2609 All	to body, with die cast lamp		2	506173
1948	25 All	to body		2	511516
1948	26 All exc. sta. wag.	to body		2	510962
1949-50	All exc. 2561-62-71	to fender		2	511661
1949-52	2562 All	to body	L.H.	1	512479
1949-52	2562 All	to body	R.H.	1	512478

**Group 2.660 PAD, TAIL LAMP (Continued)**

1949	2571	.....	.....	2	3688914	
1950-52	2571	.....	.....	1	514053	
1950-52	2571	.....	R.H.	1	514084	
1951-52	All exc. 2562-71	.....	L.H.	1	514648	
1953-54	All exc. 2562-71	.....	to fender	2	515259	
1953-54	2562-71 All	.....	to fender	2	5943402	
1954	28 All	.....	to fender	2	5945161	
1955	All exc. 2562-63	.....	to fender	2	5945920	
1955-56	25/2762-63 All	.....	to fender	2	5945814	
1956	27D, 28 All	.....	.....	2	5946942	
1956	2711-19-37-39	.....	.....	2	5945920	

**Group 2.662 BRACKET, TAIL LAMP**

1939-46	Sta. wag.	.....	1946 with plain trunnion pins	Outer	1-2	503337	
1946-48	Sta. wag.	.....	inner mounting—w/screw type trunnion	.....	1-2	5937103	
1946-48	Sta. wag.	.....	outer mounting—w/screw type trunnion	.....	1-2	5937104	
1949	2571	.....	mounting	R.H.	1	512208	
1949	2571	.....	mounting	L.H.	1	512209	
1950-52	2571	.....	mounting	R.H.	1	513910	
1950-52	2571	.....	mounting	L.H.	1	513911	
1949-52	2562 All	.....	.....	Outer	2	512451	
1949-52	2562 All	.....	.....	Inner	2	512450	
1949	2561 All	.....	.....	.....	2	512457	
1942-46	Sta. wag.	.....	<b>BOLT</b> , lamp bracket to body (Step $\frac{3}{8}$ "-16x2 $\frac{1}{4}$ ")	AR	1	128701	(8.902)
1949	2561 All	.....	tail lamp link	.....	2	512550	
1939-47	Sta. wag.	.....	<b>PIN</b> , tail lamp bracket pivot	.....	2	502495	(4.036)
1949	2561 All	.....	tail lamp clevis	.....	2	512552	
1949-52	2562 All	.....	tail lamp outer bracket	.....	2	502495	(4.036)
1939-48	Sta. wag.	.....	<b>SPRING</b> , tail lamp bracket pivot pin	.....	2	3655726	(4.016)
1939-48	Sta. wag.	.....	tail lamp bracket	.....	1	503338	
1949	2561 All	.....	tail lamp anti-rattle	.....	2	512454	
1946-48	Sta. wag.	.....	<b>SCREW</b> , tail lamp brkt. pivot (Cup pt. $\frac{1}{4}$ "-20x $\frac{1}{2}$ ")	2-4	2	216278	(8.975)
1949-52	2562 All	.....	<b>LINK</b> , tail lamp	.....	2	512472	
1949	2561 All	.....	.....	.....	2	512553	
1949	2561 All	.....	<b>ANCHOR</b> , tail lamp link	Lower	2	512456	
1949	2561 All	.....	<b>BRACKET</b> , tail lamp link anchor	.....	2	512551	
1949-52	2562 All	.....	tail lamp link	Lower L.H.	1	512516	
1949-52	2562 All	.....	.....	Lower R.H.	1	512515	
1949-52	2562 All	.....	.....	Upper	2	512453	
1949-52	2571	.....	<b>REINFORCEMENT</b> , tail lamp brkt.	R.H.	1	512211	
1949-52	2571	.....	.....	L.H.	1	512212	

**Group 2.664 SPRING, TAIL LAMP**

1949-52	2561-62 All L.H.D.	.....	outer brkt. pivot pin	.....	4	3687624	
---------	--------------------	-------	-----------------------	-------	---	---------	--

**Group 2.670 BRACKET-SPRING-STABILIZER, REAR LICENSE**

1937-52	Sta. wag.	.....	<b>BRACKET ASSY.</b> , rear license	.....	1	5938846	
1939-42	All exc. sta. wag.	.....	.....	.....	1	921007	
1946-48	All exc. sta. wag.	.....	.....	.....	1	5935891	
1949-52	All exc. 2561-62-71	.....	.....	.....	1	5942640	
1953-54	2562-71 All	.....	.....	.....	1	5944018	
1953-56	All exc. 25/2762-63-64-71	.....	.....	.....	1	5942458	(2.705)
1955-56	25/2764 All	.....	<b>STABILIZER</b> , rear license plate	.....	1	521069	(7.798)
1955	All exc. 2562-63-64	.....	.....	.....	1	519674	
1955-56	25/2764	.....	.....	.....	1	520605	

**Group 2.672 SUPPORT ASSY., TAIL LAMP LICENSE**

1949	2571	.....	.....	L.H.	1	5938741	
1950-52	2571	.....	.....	L.H.	1	5939348	

**Group 2.673 BUMPER, LICENSE PLATE BRACKET**

1949-52	All exc. rear on 2561-62-71	.....	<b>BUMPER</b> , license plate	.....	1-2	5937956	
1953-54	All exc. 2562-71	.....	.....	Rear	1	515590	
1953	All	.....	.....	Front	1	516785	
1953-54	2562-71 All	.....	.....	Rear	1	5937956	

**Group 2.674 WASHER, REAR LICENSE SUPPORT TO BODY SEALING**

1940-48	All	.....	.....	.....	1	505984	
1949-52	All exc. 2561-62-71	.....	.....	.....	2	512178	
1953-54	2562-71 All	.....	.....	.....	2	512178	
1941-48	26-29 exc. sta. wag.	.....	<b>CAP</b> , rear license holder to body screw	.....	1	506121	

**Group 2.679 LAMP ASSEMBLY, TAIL**

1937-48	Sta. wag.....			1	897861
1941-47	25 All exc. 2569.....		R.H.	1	927134
1941-47	25 All exc. 2569.....		L.H.	1	927133
1941-47	26 All exc. sta. wag.....		R.H.	1	927136
1941-47	26 All exc. sta. wag.....		L.H.	1	927135
1941	29 All.....		R.H.	1	927038
1941	29 All.....		L.H.	1	927037
1946-48	Sta. wag.....	w/bracket.....	R.H.	1	929970
1946-48	Sta. wag.....	w/bracket.....	L.H.	1	929969
1948	25 All.....		R.H.	1	927604
1948	25 All.....		L.H.	1	927603
1948	26 exc. sta. wag.....		R.H.	1	927606
1948	26 exc. sta. wag.....		L.H.	1	927605
1949-50	All exc. 2561-62-71.....		R.H.	1	927608
1949-50	All exc. 2561-62-71.....		L.H.	1	927607
1949-52	2561-62 All.....		R.H.	1	927630
1949-52	2561-62 All.....		L.H.	1	927629
1949	2571.....		R.H.	1	927610
1949	2571.....		L.H.	1	927609
1950-52	2571.....		R.H.	1	927868
1950-52	2571.....		L.H.	1	927867
1951-52	All exc. 2562-71.....		R.H.	1	927870
1951-52	All exc. 2562-71.....		L.H.	1	927869
1953-54	All exc. 2562-71.....			2	927847
1953-54	2562-71 All.....			2	928273
1954	28 All.....			2	928682
1955	2511-19-37-64 All D.....			2	897585
1955-56	25/2711-19.....			2	897818
1955	2819-37-67 All.....			2	897585
1955-56	25/2762-63 All.....			2	897640
1956	2719-37-39-64 All D.....			2	897932
1956	2819-37-39-67 All.....			2	897932

**Group 2.680 ORNAMENT, TAIL LAMP**

1955-56	25/2762-63 All.....	exc. w/back-up lamps.....		2	5945813
1953-54	2562-71 All.....	<b>MEDALLION</b> , tail lamp.....		2	5943947
1940	All.....	<b>RETAINER</b> , tail lamp ornament, nut type.....		2	3695282
1955-56	25/2762-63 All.....	<b>GASKET</b> , tail lamp ornament.....		2	5945806

(8.040)

**Group 2.681 DOOR, TAIL LAMP**

1937-38	All exc. sta. wag.....	with lens.....		1	921185
1949	2571.....	less lens.....		2	920628
1950-52	2571.....	less lens.....		2	5940987
1949-50	All exc. 2561-62-71.....	less lens.....	R.H.	1	5937854
1949-50	All exc. 2561-62-71.....	less lens.....	L.H.	1	5937853
1951-52	All exc. 2562-71.....	less lens.....	R.H.	1	5940986
1951-52	All exc. 2562-71.....	less lens.....	L.H.	1	5940985
1942-52	All sta. wag.....	with lens.....		1-2	914084
1953-54	2511-37-67-69 All.....	less lens.....		2	5942451
1953-54	2562-71 All.....	less lens.....		2	5943946
1954	28 All.....			2	5945158
1955	All exc. 2562-63-64.....			2	5945744
1955-56	25/2762-63 All.....			2	5945801
1956	2711-19-37-39.....			2	5945744
1956	2719-37-39-64 All D.....			2	5946938
1956	2819-37-39-67 All.....			2	5946938

**Group 2.682 LENS, TAIL LAMP DOOR**

1937-47	Sta. wag.....			1	919044
1939	All exc. sta. wag.....			1-2	920696
1941-47	All exc. 1941 29 & sta. wag..	with die cast lamp.....		2	5931535
1942	25 All.....	with stamped lamp.....	R.H.	1	5933578
1942	25 All.....	with stamped lamp.....	L.H.	1	5933577
1942	26 exc. sta. wag.....	with stamped lamp.....	R.H.	1	5933580
1942	26 exc. sta. wag.....	with stamped lamp.....	L.H.	1	5933579
1948-50	All exc. sta. wag. & 1949 2571			2	5937590
1949	2571.....			2	5937162
1950-52	2571.....			2	5937590
1951-52	All exc. 2562-71.....			2	5939888
1953-54	2511-37-67-69 All.....			2	5942453
1953-54	2561-71 All.....			2	5939888



Group 2.682		LENS, TAIL LAMP DOOR (Continued)			
1953-54	2562-71 All	tail lamp ornamental	4	5943919	
1954	28 All	w/ring	2	5945163	
1955	2511-19		2	5946382	
1955	All D exc. 2562-63	w/ring	2	5945748	
1955-56	25/2762-63 All		2	5945809	
1956	2719-37-39-64 All D		2	5946943	
1956	2711-19-37-39		2	5946382	
1956	2819-37-39-67 All		2	5946943	
Group 2.683		CLAMP, TAIL LAMP TO BODY			
1941-47	All exc. sta. wag. & 1941 29	Inner R.H.	1	505907	
1941-47	All exc. sta. wag.	Outer R.H.	1	505909	
1941-47	All exc. sta. wag. & 1941 26	Outer L.H.	1	505910	
1948	All exc. sta. wag.	(toothed)	4	510977	
1948	All exc. sta. wag.	(plain)	4	510976	
Group 2.684		GASKET, TAIL LAMP DOOR AND LENS			
1937-42	Sta. wag.		1	911771	
1939	All exc. sta. wag.		1-2	921874	
1940-41	All 1940,				
	1941 29 exc. sta. wag.		2	924657	
1941-47	All exc. 29 & sta. wag.	with die cast lamp	2	5931834	
1948-49	All exc. 2561-62 71		2	5937599	
1949	2571		2	920625	
1950-52	2571		2	5937599	
1950	All exc. 2562		2	5937599	
1951-52	All exc. 2562-71		2	5939889	
1953-54	2511-37-67-69 All		2	5942457	
1953-54	2562-71 All		2	5939889	
1953-54	2562-71 All	tail lamp ornament lens	4	5943920	
1954	28 All		2	5945162	
1955	All exc. 2562-63	tail lamp lens	2	5945747	
1955-56	25/2762-63 All	tail and signal lamp lens to body	2	5945808	
1956	2711-19-37-39		2	5945747	
1956	2719-37-39-64 All D		2	5946945	
1956	2819-37-39-67 All		2	5946945	
Group 2.685		LENS, TAIL LAMP SIDE AND TOP			
1937-52	Sta. wag.	clear	1-2	914778	
1949	2571	clear	L.H.	920634	
1950-52	2571	clear	L.H.	914778	
Group 2.686		GASKET, TAIL LAMP CLEAR LENS			
1937-52	Sta. wag.		1	914779	
1950-52	2571		1	914779	
Group 2.688		SCREW, TAIL LAMP DOOR			
1937-52	Sta. wag.	(Spec. hd. No. 8-32x <sup>5</sup> / <sub>8</sub> "	AR	912048	
1949	2571		2	920627	
1950-52	2571	(Spec. hd. No. 8-32x <sup>5</sup> / <sub>8</sub> "	AR	912048	
1955	All exc. 2562-63	tail lamp lens	4	455601	(8.906)
1955-56	25/2762-63 All	(Fil. hd. No. 10-24x1 <sup>3</sup> / <sub>4</sub> "	4	153374	
1956	27 All exc. D		4	455601	(8.906)
1956	2719-37-39-64 All D		4	5946946	
1956	2762-63 All		4	455601	(8.906)
1956	2819-37-39-67 All		4	5946946	
1956	All	parking lamp lens	4	5946849	
Group 2.694		SOCKET ASSY., TAIL LAMP			
1940-47	All exc. sta. wag.		2	923598	
1948	All exc. sta. wag.		2	5937588	
1949-50	All exc. 2561-62-71		2	5938601	
1951-52	All exc. 2562-71	with cup	2	5939945	
1953-54	All	with cup	2	5939945	
1948-50	All exc. 2561-62-71	GASKET, socket	2	5937600	
1951-52	All exc. 2562-71		2	5939951	
1953-54	All		2	5939951	
1951-56	All	PLUG, tail lamp wire connector	2	5291632	■
1955-56	All	back up lamp wire	2	5291638	■
1951-52	All exc. 2562-71	SPRING, socket and cup retainer	2	5939950	
1953-54	All		2	5939950	
1955	2562-63 All	CLIP, tail lamp wire—on lamp supt.	2	4576889	

## Group 2.697 LAMP, BACK UP

1942-48	All	LAMP ASSEMBLY, chrome door	1	927589	
1949-50	All exc. 2561-62-71		2	928041	
1949-52	2561-62 All				
1949-52	2561-62 All		R.H.	928048	
1949	2571		L.H.	928047	
1949	2571		R.H.	928052	
1950-52	2571		L.H.	928051	
1950-52	2571		R.H.	928660	
1951-52	All exc. 2562-71	with stamped door	L.H.	928659	
1953-54	All exc. 2562-71			928193	
1953-54	All exc. 2562-71		R.H.	928180	
1953-54	2562-71 All		L.H.	928179	
1955-56	All exc. 25/2762-63			928942	
1946-48	All			897586	
1951-54	All exc. 2562-71	BRACKET, lamp, short	1	5936169	
1953-54	All	CONNECTOR, lamp to body wire	2	5289849	(2.530)
1955-56	All exc. 25/2762-63	lamp to body wires	1	5289770	
1942-48	All	COVER, back up lamp opening	2	519637	
1949-50	All 2561-62-71	DOOR ASSEMBLY	1	5931447	
1949-51	2561-62-71 All		2	5938298	
1951-52	All exc. 2562-71		1	5931447	
1952	2562-71 All		2	5939817	
1953-54	All exc. 2562-71		2	5942262	
1953-54	All exc. 2562-71		L.H.	5943793	
1953-54	2562-71 All		R.H.	5940658	
1955-56	All exc. 25/2762-63			5939817	
1942-48	All		2	5945735	
1942-48	All	FUSE HOLDER AND WIRE, male half	1	5933754	
1942-48	All	female half	1	5933755	
1949-52	All exc. 2561-62-71	FUSE, 9 amp. (3/8" long)	2	147684	(8.965)
1953-54	All exc. 2562-71	GASKET, back-up lamp	2	5935956	(2.590)
1953-54	2562-71 All		2	5940662	
1955-56	All exc. 25/2762-63		2	5935956	(2.590)
1955-56	All exc. 25/2762-63	back up lamp opening cover	2	519642	
1955-56	25/2762-63 All	back up lamp lens	2	5945737	
1942-48	All	back up lamp lens to body	2	5945806	
1949-52	All exc. 2561-62-71	LENS, door	1	5938015	
1949-52	2561-62-71 All	with back-up lamp	2	5938297	
1953-54	All exc. 2562-71		1	5938015	
1953-54	2562-71 All		2	5940663	
1955-56	All exc. 25/2762-63		2	5938297	
1955-56	25/2762-63 All		2	5945736	
1949-50	All exc. 2561-62-71	NUT, door to body	4	5933049	(2.594)
1942-52	All	switch mounting	1	509294	
1949-50	All exc. 2561-62-71	PAD, to body	R.H.	512320	
1949-50	All exc. 2561-62-71		L.H.	512321	
1951-52	All exc. 2562-71			514750	
1953-54	All exc. 2562-71			515479	
1953-54	2562-71 All		R.H.	512320	
1953-54	2562-71 All		L.H.	512321	
1955-56	All exc. 25/2762-63			519898	
1949-50	All exc. 2561-62-71	RETAINER, back-up lamp	R.H.	512356	
1949-50	All exc. 2561-62-71		L.H.	512357	
1949-52	2561-62-71 All	SCREW, back-up lamp door	AR	912048	(2.688)
1951	All exc. 2562-71	w/die cast door (Fill. Hd. No. 6-32x3/8")	4	224535	
1951-52	All exc. 2562-71	w/stamped door (Pan Head No. 6-32 x 1/4")	4	451323	
1953-54	2562-71 All		4	451323	
1955-56	All exc. 25/2762-63		4	5945824	
1956	All S.T.	back-up lamp switch actuating	1	9400895	
1953-54	All exc. 2562-71	SOCKET AND WIRE ASSY., back-up lamp	2	5940664	
1953-54	All exc. 2562-71	SPACER, back-up lamp to body	4	5939849	
1942-48	All L.H.D., S.T.	STOP, switch	1	509258	
1948	All L.H.D., H.T.		1	510764	
1949-52	All L.H.D., S.T.		1	512323	
1953-54	All exc. 2562-71	STRIP, back-up lamp lens decorative	4	5940666	
1942-48	All L.H.D., S.T.	SUPPORT, switch	1	509257	
1948	All L.H.D., H.T.		1	510438	
1949-52	All L.H.D., S.T.		1	512325	
1942-48	All	SWITCH ASSEMBLY, back-up lamp	1	510964	
1949-52	All S.T.		1	512541	
1953-54	All S.T.		1	1997895	
1955	All S.T.		1	1998107	
1956	All S.T.		1	1998141	
1949-52	All H.T.		1	1997846	(4.054)
1953-56	All H.T. exc. C.C.		1	1998039	(4.054)
1953	All P.G.		1	1998071	(4.054)
1956	All C.C.-H.T.		1	1998129	(4.054)
1949-52	All	WIRE ASSY., switch to fuse block	1	5289339	
1953-54	All S.T.	back-up lamp	1	5293127	
1953-54	All H.T. & P.G.	back-up lamp	1	5293128	
1955	All S.T.	back-up lamp	1	2961412	
1955	All H.T.	back-up lamp	1	2961411	
1956	All	back-up lamp	1	2961411	

**Group 2.700 LAMP ASSEMBLY, REAR LICENSE**

1946-48	2607 All.....	-----	1	927420	
1946-48	All exc. 2607 & sta. wag.....	-----	1	927421	
1949-50	All exc. 2561-62-71.....	-----	2	927594	
1951-52	All exc. 2562-71.....	-----	1	927803	
1953-54	All exc. 2562-71.....	-----	1	897463	
1953-54	2562-71 All.....	-----	1	897465	
1955-56	All exc. 25/2762-63-64.....	-----	1	897574	
1955-56	25/2762-63-64 All.....	-----	2	897703	

**Group 2.702 PAD, REAR LICENSE LAMP BODY**

1940	2611-19.....	rubber.....	1	502240	
1946-48	2607 All.....	-----	1	508700	
1946-48	All exc. 2507.....	-----	1	3663703	
1949-50	All exc. 2561-62-71.....	-----	2	512555	
1951-52	All exc. 2562-71.....	<b>GROMMET</b> , lamp wire thru floor pan.....	1	514383	
1953-54	All exc. 2562-71.....	-----	1	515806	
1955-56	All exc. 25/2762-63.....	-----	1	518955	

**Group 2.703 SPACER, REAR LICENSE LAMP**

1941-42	2569 All.....	support to body.....	1	506699	
1942	2507 All.....	support to body.....	1	506699	

**Group 2.705 BRACKET ASSY., REAR LICENSE AND LAMP**

1953-56	All exc. 25/2762-63-64-71.....	-----	1	5942458	
---------	--------------------------------	-------	---	---------	--

**Group 2.706 COVER—DOOR, REAR LICENSE LAMP**

1939-42	All.....	<b>COVER</b> , chrome.....	1	5930151	
1949-50	All exc. 2561-62-71.....	-----	2	5937942	
1951-52	All exc. 2562-71.....	<b>DOOR</b> .....	1	5939872	
1953-54	All exc. 2562-71.....	-----	1	5943380	
1953-54	2562-71 All.....	-----	1	5939957	
1955-56	25/2762-63 All.....	-----	2	5945959	

**Group 2.707 GASKET, LICENSE LAMP OUTLOOK LENS**

1939-42	All exc. sta. wag.....	-----	1	922043	
1946-48	All exc. sta. wag.....	-----	1	5932762	
1949-50	All exc. 2561-62-71.....	-----	2	5937940	
1951-52	All exc. 2562-71.....	-----	1	5939870	
1953-56	All exc. 25/2762-63-64-71.....	rubber.....	1	5935949	
1953-56	All exc. 25/2762-63-64-71.....	felt.....	1	5936537	
1953-54	2562-71 All.....	-----	1	5939870	

**Group 2.708 SCREW, LICENSE LAMP COVER RETAINER**

1949-50	All exc. 2561-62-71.....	cover to body.....	(No. 6-32x $\frac{5}{16}$ "	4	426701	(8.909)
1939-42	All.....	<b>BOLT</b> , rear license lamp.....	(Carr. $\frac{1}{4}$ "-20x2 $\frac{3}{4}$ "	1	126614	(8.903)
1939-40	25-26 All.....	lamp to body.....	(Hex. $\frac{1}{4}$ "-20x2"	1	180044	(8.900)
1953-56	All exc. 25/2762-63-64-71.....	<b>NUT</b> , rear license lamp door.....	-----	2	120614	(8.915)
1949-52	All exc. 2561-62-71.....	<b>SCREW</b> , bracket to body.....	-----	2	3651216	(8.206)
1953-54	2562-71 All.....	-----	-----	2	3651216	
1955-56	25/2762-63 All.....	license lamp door to bumper guard.....	-----	4	3719610	

**Group 2.709 LENS, REAR LICENSE LAMP OUTLOOK**

1939-42	All exc. sta. wag.....	-----	1	922042	
1949-50	All exc. 2561-62-71.....	-----	2	5938832	
1951-52	All exc. 2562-71.....	-----	1	5940540	
1953-56	All exc. 25/2762-63-64-71.....	-----	1	5935947	
1953-54	2562-71 All.....	-----	1	5940540	

**Group 2.710 PLATE, REAR LICENSE LAMP NAME**

1946	All exc. sta. wag.....	-----	1	508619		
1947-48	All exc. sta. wag.....	-----	1	509512		
1940-41	All.....	<b>NUT</b> , license lamp name plate.....	(Clip type $\frac{1}{4}$ "	2	186463	(8.921)

**Group 2.714 WIRE ASSEMBLY, REAR LICENSE LAMP**

1939-41	All exc. 29 and sta. wag.....	-----	1	5931931	
1942	All exc. sta. wag.....	-----	1	5931692	
1946-48	All exc. sta. wag.....	-----	1	5932806	
1949-50	All exc. 2S61-62-71.....	w/socket.....	1	5937937	
1955-56	All exc. 25/2762-63-64.....	w/door.....	1	5945492	
1946-48	All exc. sta. wag.....	<b>SOCKET</b> , lamp bulb.....	1	5932764	
1946-48	All exc. sta. wag.....	<b>GASKET</b> , lamp socket.....	1	5932793	

**Group 2.721 SPRING, HEADLAMP INNER BODY TENSION**

1941-46	All.....	-----	12	5931749	
1947-55	All.....	1st type on 1955..... (1 1/2" long)	2	5937452	
1955	All.....	2nd type..... (1 1/4" long)	2	5946543	
1956	All.....	----- (1 1/4" long)	2	5946543	

**Group 2.722 GASKET, HEADLAMP BODY TO FENDER**

1942-48	All.....	-----	2	507005	
1949-52	All.....	-----	2	509478	
1953-54	All.....	-----	2	515258	
1955-56	All.....	-----	2	519628	

**Group 2.724 ORNAMENT, HEADLAMP BODY TRIM**

1941	All.....	<b>ORNAMENT</b> , headlamp lower.....	2	505617	
1942	All.....	<b>NUT</b> , headlamp ornament..... (Clip type 1/16")	2	3695282	(8.040)

**Group 2.725 HEADLAMP ASSEMBLY**

1941	All L.H.D.....	with door, chrome.....	2	925012	
1942-48	All L.H.D.....	with door.....	2	925177	
1949-52	All L.H.D.....	with door.....	2	925809	
1953-54	All L.H.D.....	less door.....	2	5940573	
1953-54	All L.H.D.....	with door.....	2	925971	
1955	All L.H.D.....	with door.....	2	898144	
1956	All L.H.D.....	with door.....	2	898137	
1940-56	All.....	<b>SCREW</b> , headlamp to fender..... (No. 10-12x5/8")	16	161901	(8.977)
1940-54	All.....	<b>NUT</b> , headlamp to fender screw..... (Spring type)	AR	413395	(2.548)
1955-56	All.....	----- (Spring type)	16	519912	

**Group 2.726 BODY, HEADLAMP**

1949-52	All.....	-----	2	5937072	
1953-54	All.....	-----	2	5940667	
1955-56	All.....	-----	2	5946624	
1940-55	All.....	<b>RING</b> , inner—1st type (see note).....	2	924535	
1955	All.....	2nd type (see note).....	2	5946426	
1956	All.....	-----	2	5947771	

**NOTE:** 1st type has rolled outer edge with three tabs for attaching retainer ring.  
2nd type has flat outer edge with four notches.

**Group 2.727 SEALED BEAM UNIT, HEADLAMP**

1940-54	All.....	glass reflector—type 5040.....	6 volt	2	456795
1940-54	All.....	glass reflector—type T-3.....	6 volt	2	5947206
1955-56	All.....	glass reflector—type 5400.....	12 volt	2	456796
1955-56	All.....	glass reflector—type T-3.....	12 volt	2	5947212
1955-56	All.....	glass reflector—type T-3—heavy duty.....	12 volt	2	5947324

**Group 2.728 DOOR, HEADLAMP**

1937-38	All.....	<b>RIM</b> , headlamp.....	R.H.	1	920450
1937-38	All.....	-----	L.H.	1	920449
1939	All.....	-----	L.H.	1	923453
1940	All L.H.D.....	-----		2	924565
1941	All.....	<b>DOOR ASSY.</b> , includes door, clip, gasket and spring.....		2	5931865
1942-48	All.....	-----		2	5932754
1949-52	All D & 2S71.....	chrome.....		2	5940532
1949-52	All exc. D & 2S71.....	prime.....		2	5940567
1953-54	All.....	chrome.....		2	5940574
1955	All.....	-----		2	5945563
1956	All.....	prime.....		2	5947113



<b>Group 2.729</b>		<b>SCREW, HEADLAMP DOOR CLAMPING</b>			
1940-41	All		(Fil. Hd. No. 8-32x $\frac{1}{2}$ " )	2	924622
1942-48	All		(Oval Hd. No. 10-32x $\frac{15}{16}$ " )	2	507004
1949-56	All			2	446869
					(8.977)
<b>Group 2.731</b>		<b>RING, HEADLAMP SEALED BEAM RETAINER</b>			
1940-55	All	1st type (see note)		2	924534
1955	All	2nd type (see note)		2	5946431
1956	All			2	5947705
<b>NOTE:</b> 1st type w/three tabs for attaching. 2nd type w/2 tabs welded to ring for attaching.					
<b>Group 2.735</b>		<b>GASKET, HEADLAMP LENS</b>			
1940-48	All L.H.D.	at door, rubber		2	5930594
1949-54	All			2	5930594
1955-56	All			2	5945844
<b>Group 2.736</b>		<b>CLIP—SCREW, HEADLAMP MOUNTING RING</b>			
1955	All L.H.D.	<b>CLIP</b>		AR	5947712
1940-56	All	<b>SCREW</b>	(No. 8-32x $\frac{1}{4}$ " )	6	924552
<b>Group 2.737</b>		<b>SCREW, HEADLAMP</b>			
1940-50	All	beam adjuster	( $\frac{1}{4}$ "-28x1")	4	924561
1940-48	All	<b>NUT</b> , beam adjuster screw		4	5930896
1949-56	All			4	5939769
<b>Group 2.746</b>		<b>SPRING, HEADLAMP DOOR SEAL RETAINER</b>			
1942-52	All			AR	914127
1951-52	All		Bottom	2	5939791
1951-52	All		Top	2	5939983
1953-54	All		Top	2	5940578
1953-54	All		Side and bottom	2	5940579
1955-56	All			2	5945961
<b>Group 2.750</b>		<b>WIRE AND SOCKET, HEADLAMP</b>			
1942-48	All L.H.D.	with sealed beam type		2	5932941
1949-52	All	with sealed beam type		2	5937970
1953-54	All	with sealed beam type		2	5942852
1955-56	All			2	5945680
<b>Group 2.765</b>		<b>SWITCH, INSTRUMENT PANEL LAMP</b>			
1936-39	All			1	001406
1940	All			1	1997719
1941	All			1	1997740
<b>Group 2.768</b>		<b>KNOB, INSTRUMENT LAMP SWITCH CONTROL</b>			
1941	All			1	505827
<b>Group 2.776</b>		<b>SOCKET AND WIRE, INSTRUMENT LAMP</b>			
1942-48	All	panel light		1	1885070
<b>Group 2.810</b>		<b>HORN ASSEMBLY</b>			
1937-41, 1946-48	All	high note—die cast	L.H.	1	1999688
1937-41, 1946-48	All	low note—die cast	R.H.	1	1999519
1949-54	All	low note	R.H.	1	1999645
1949-54	All	high note	L.H.	1	1999646
1955-56	All	low note	R.H.	1	1999763
1955	All	high note	L.H.	1	1999764
1956	All	high note	L.H.	1	1999768

<b>Group 2.815</b>		<b>RELAY ASSEMBLY, HORN</b>	
1934-54	All	for dual horns	1 1116775
1955-56	All		1 1116781
<b>Group 2.816</b>		<b>CUSHION, HORN BUTTON RUBBER</b>	
1941-42	All	key spring—key blowing type, w/std. wheel	2 754126
<b>Group 2.817</b>		<b>BUTTON—CAP, HORN</b>	
1940	25-26 All	<b>BUTTON</b> , w/std. wheel	1 266203
1941	All	w/D wheel	1 505917
1942	All	w/D wheel	1 507088
1942-48	All	w/std. center blowing type wheel—steering wheel cap	1 507532
1946-47	All	w/D wheel	1 508698
1948	All	w/D wheel	1 509557
1949-50	All	<b>CAP</b> , steering wheel, w/std. wheel	1 511934
1951-52	All	w/std. wheel	1 514650
1953-54	All	w/std. wheel	1 516940
1955	All	w/std. wheel	1 519591
1956	All	w/std. wheel	1 522306
1949	All	<b>CAP ASSEMBLY</b> , horn ring w/D wheel	1 512418
1950	All	w/D wheel	1 513826
1951-52	All	red—w/D wheel	1 515706
1952	2537 SD	green	1 516525
1953	All	red—w/D wheel	1 516842
1953	2537 SD	green	1 517175
1954	All D-S.S.	red	1 516842
1954	All SD-S.S.	beige	1 518346
1954	All SD-S.S.	coral red	1 518347
1954	All SD-S.S.	yellow	1 518348
1954	All D-P.S.	red	1 517903
1954	All SD-P.S.	beige	1 517904
1954	All SD-P.S.	coral red	1 518349
1954	All SD-P.S.	yellow	1 518350
1955	All D-S.S.	black	1 519508
1955	All SD-S.S.	blue	1 520597
1955	All SD-S.S.	firegold	1 520598
1955	All D-P.S.	black	1 519594
1955	All SD-P.S.	blue	1 520596
1955	All SD-P.S.	firegold	1 520595
1956	All D-S.S.		1 521501
1956	All P.S.		1 521488
1939-42	All	<b>PACKAGE</b> , horn button—use with 507490 wheel	1 544408
<b>Group 2.819</b>		<b>SLEEVE, HORN CABLE CONTACT</b>	
1937-38	All	on shaft	1 263287
1937-38	All	<b>CONNECTOR ASSEMBLY</b> , horn cable—on column	1 263549
1941-48	All	horn wire	1 3114169 (2.649)
1939-52	All	<b>INSULATOR</b> , horn button connector	1 5660044
1953-56	All	w/std. wheel	1 759230
1953-56	All	use w/5660046 assy.—w/D wheel	1 5660044
1939-52	All	<b>CONTACT AND SPRING ASSEMBLY</b> , horn button connector—use 5660044 with this assy.	1 5660046
1953-56	All	use w/5660044 insulator—w/D wheel	1 5660046
1953-56	All	w/std. wheel	1 759037
<b>Group 2.821</b>		<b>RETAINER, HORN BUTTON CAP</b>	
1942-52	All	w/std. wheel	1 506741
1942-48	All		2 507440
1953-56	All	<b>BUSHING</b> , horn button cup spacer—w/std. wheel	3 757440
1953-54	All	<b>CUP</b> , horn button contact—w/std. wheel	1 758409
1955-56	All	w/std. wheel	1 759802
1941	All	<b>INSULATOR</b> , horn button, ring guide	2 506097
1951-54	All		1 514412
1955-56	All	horn ring cap, w/D wheel	1 519397
1953-56	All	<b>SCREW</b> , steering wheel horn button cup bushing—w/std. wheel	3 759146
1937-52	All exc. 1940 29	<b>RING</b> , cap retaining, center blowing type on 1942 25 and w/std. wheel on 1942 thru 52 except 1942 25	1 263703
1949-52	All	<b>SPACER</b> , strg. wheel cap, w/std. wheel	1 511935

**Group 2.822 CONTACT, HORN BUTTON**

1939-52	All exc. 1940 29	w/std. wheel, center blowing type on 1942 25	1	265172
1941	All	w/D wheel	1	512246
1942-48	All	w/D wheel	1	504339
1949-56	All	w/D wheel	1	512246
1941-42	All	<b>RING</b> , horn button contact, w/std. key type wheel	1	754077
1940,				
1942-47	All	w/D wheel	1	507519
1941,				
1949-56	All	w/D wheel	1	506075
1948	All	w/D wheel	1	509556
1937-39	All	<b>SEPARATOR</b> , horn button contact	1	264584
1940,				
1942-52	All exc. 1940 29	center blowing type on 1942 25	1	264584
1940	All	w/D wheel	1	504342
1941	All	w/D wheel	1	506076
1942-56	All	w/D wheel	1	507722
1949-52	All	<b>SPRING</b> , horn ring ground—w/D wheel	1	512247
1953-56	All	horn button—w/std. wheel	1	758408
1940	All	<b>PLATE</b> , contact separator backing—w/D wheel	1	504340
1941-48	All	w/D wheel	1	506309
1941	All	horn button contact retainer—w/D wheel	1	506074
1949-52	All	contact retainer—w/D wheel	1	512734
1953-56	All	horn ring contact retainer—w/D wheel	1	517258
1953-56	All	horn button contact—w/std. wheel	1	758407
1955-56	All	<b>SCREW</b> , horn ring contact retainer plate	3	9404951 ■

**Group 2.823 PLATE, HORN BUTTON GROUND**

1940	29 All	cup grounding, w/std. wheel	1	753657
1941-42	All	key, w/std. key type wheel	1	754076
1942-48	All	w/D wheel	1	509553

**Group 2.829 RING, HORN BUTTON LOCK**

1939-52	All exc. 1940 29	with std. wheel, center blowing type on 1942 25	1	265173
1941-42	All 1941, 1942 25 only	<b>RETAINER</b> , horn blowing key, with std. wheel	2	754073
1941	All	<b>SCREW</b> , horn blowing key retainer, with std. wheel (Fil. Hd. No. 6-32x $\frac{1}{2}$ " )	2	131899 (8.907)

**Group 2.830 KEY—RING, HORN OPERATING**

1941-42	All 1941, 1942 25 only	<b>KEY</b> , horn operating—with std key blowing wheel (plastic)	2	754128
1941	All	<b>RING</b> , horn button—w/D wheel	1	505750
1942	All	w/D wheel	1	507721
1946-47	All	w/D wheel	1	508755
1948	All D		1	510693
1949-50	All D		1	511993
1951-52	All D		1	515701
1953-54	All D		1	516941
1955-56	All D		1	519302

**Group 2.831 SPACER, HORN BUTTON RING**

1942-48	All	with std. center blowing wheel	1	507537
1942-48	All	w/D wheel	1	507442
1942-48	All	<b>INSULATOR</b> —w/D wheel	1	507959

**Group 2.845 BRACKET, HORN MOUNTING**

1938-41,				
1946-54	All	with die cast horns	2	505716
1955-56	All		2	1924440
1935-41	All	<b>LAMINATION</b> , horn bracket	1	1849037
1938-54	All	<b>SPACER</b> , horn bracket	1	1860729

**Group 2.859 CABLE, HORN BUTTON**

1937-38	All	with terminal, at horn button	1	264249
1939-40	All L.H.D.		1	265076
1941-48	All		1	266918
1949-52	All		1	5660683
1953-54	All	with contact	1	5296935
1955-56	All L.H.D.	w/contact	1	2961695
1946-56	All	<b>CLAMP</b> , horn wire dual horns	1	269521
1939	All	<b>SCREW</b> , horn wire junction block (Hex. No. 7-16x $\frac{3}{4}$ " )	1	508100
1946-54	All	horn wire clamp to steering column (Rd. Hd. No. 10-16x $\frac{1}{4}$ " )	1	145111 (8.977)

**Group 2.892 FLASHER—CONNECTOR—WIRE, DIRECTION SIGNAL**

1940-42	All	<b>FLASHER</b>	1	5930991
1946-48	All exc. sta. wag.		1	5947767
1949-54	All		1	1335220
1955	All		1	5943797
1956	All		1	3713382
1953-55	All	<b>CONNECTOR, flasher</b>	1	560172
1949-50	All	<b>WIRE ASSY., dir. signal and flasher socket—w/field installed dir. signal</b>	1	5938733
1951-52	All	<b>w/field installed dir. signal</b>	1	5940264
1955	All	<b>WIRE AND SOCKET, inst. panel light</b>	2	2963861
1956	All		2	1886497

(8.866)

**Group 2.895 CONTROL—SWITCH ASSEMBLY AND PARTS, DIRECTION SIGNAL**

1946-47	All	<b>SWITCH BASE AND WIRE ASSEMBLY</b>	1	5936275
1948	All	w/factory installed direction signal	1	5937832
1948	All	w/field installed direction signal	1	5937763
1949-50	All		1	5938246
1951-52	All		1	5943132
1953-54	All		1	5942764
1955	All		1	1929732
1956	All		1	1932941
1949-50	All	<b>CONTROL ASSEMBLY—includes: cover, wire, switch and lever</b>	1	928542
1951-52	All		1	928874
1953-54	All S.T.		1	928459
1953-54	All H.T. & P.G.		1	928460
1955	All S.T.		1	1995593
1955	All H.T.		1	1995592
1956	All S.T.		1	1995804
1956	All H.T.		1	1995803
1955-56	All	<b>BALL, contact carrier</b>	4	169064
1955-56	All	<b>CARRIER, switch contact</b>	1	1929763
1955-56	All	<b>CONTACT, switch—three point</b>	2	1910372
1955-56	All	five point	1	1910373
1940-48	All	<b>RUBY-JEWEL, direction signal switch</b>	1	924855
1953-54	All	<b>RING AND SCREW PKG., direction signal switch</b>	1	897064
1953	All	<b>SCREW, direction signal switch ring pivot</b> (13/16" long)	1	5942768
1953-54	All	(13/16" long)	1	5944866
1953-54	All	<b>SPRING, direction signal switch pawl</b>	2	5942766
1953-54	All	switch ring lock	1	5942761
1953-54	All	switch ring centering	1	5942767
1955-56	All	contact carrier	9	1926913

(8.899)

**Group 2.896 CAM, STEERING WHEEL DIRECTION SIGNAL CANCELLING**

1949-52	All		1	512425
1953-54	All		1	5942639
1955	All		1	1929717
1956	All		1	1933259

**Group 2.897 LEVER ASSEMBLY, DIRECTION SIGNAL SWITCH**

1942-47	All exc. sta. wag.		1	5936282
1948	All		1	5937982
1949-52	All	w/black knob	1	5938247
1950	2537 SD	w/rust knob	1	5939468
1953-54	All		1	5943803
1955	All		1	1929716
1956	All		1	1933248

**Group 2.899 SOCKET AND WIRE, DIRECTION SIGNAL PARKING LAMP**

1941-47	All exc. sta. wag.		2	5936274
1948	All		1	5937806
1948	All	R.H.	1	5937805
1949	All	L.H.	1	5938264
1949	All	R.H.	1	5938263
1950	All	L.H.	1	5939330
1950	All	R.H.	1	5939329
1951-52	All	L.H.	1	5939996
1951-52	All	R.H.	1	5939995
1953	All	L.H.	1	5940676
1953	All	R.H.	1	5940675
1954	All	L.H.	1	5945168
1954	All	R.H.	1	5945167
1955	All	L.H.	1	5945818
1955	All	R.H.	1	5945817
1956	All	L.H.	1	5946852
1956	All	R.H.	1	5946851
		<b>BODY AND WIRE ASSY., parking lamp</b>		



**Group 2.901 COVER, DIRECTION SIGNAL LOOM**

1940	All	.....	1	5930708
1949-50	All	.....	1	5930393
1951-52	All	.....	1	5943134
1949-52	All	<b>SPRING</b> , loom cover.....	1	513750

**Group 2.902 CLAMP—BRACKET, DIRECTION SIGNAL**

1955	All L.H.D.	<b>CLAMP</b> , strg. col. jacket wire and flasher brkt.....	1	520351
1956	All L.H.D.	.....	1	515467
1949-52	All	<b>BRACKET</b> , flasher socket and multiple connector.....	1	512426
1953-54	All	.....	1	515464

**Group 2.906 HOUSING ASSEMBLY, DIRECTION SIGNAL SWITCH**

1948	All	.....	1	5937167
1953-54	All S.T.	.....	1	5944623
1953-54	All H.T. & P.G.	.....	1	5944624
1955-56	All S.T.	.....	1	1929785
1955-56	All H.T.	.....	1	1929731

**Group 2.910 PLATE—SPRING, DIRECTION SIGNAL SWITCH LEVER**

1955-56	All	<b>PLATE</b> .....	1	1929734
1955-56	All	<b>SPRING</b> , release.....	2	1921885

**Group 2.916 SPRING, DIRECTION SIGNAL SWITCH DETENT**

1955-56	All	.....	1	1925279
---------	-----	-------	---	---------

