

HEAVY-DUTY PARTS SECTION

(FOR CARS EQUIPPED WITH
DUAL FOUR-BARREL AND TRIPLE
TWO-BARREL CARBURETORS)



This section lists the replacement parts used only on cars equipped with the Dual Four-Barrel and Triple Two-Barrel Carburetor Engine. Parts listed as Heavy Duty are intended only for race cars.

Parts which are common to all models are located in their respective groups throughout the Master Parts Catalog.

	MODEL	PART NAME	Per Car	Part No.
		Group 0.033 ENGINE ASSEMBLY, PARTIAL		
1957	All.....	1	528310
		Group 0.253 PLUG, INTAKE MANIFOLD CORE HOLE		
1956-57	All.....	2	144000 (8.971)
		Group 0.269 HEAD, CYLINDER		
1956	All.....	2	522935
		Group 0.296 VALVE, INTAKE		
1956	All.....	std.....	8	522848
1957	All.....	std.....	8	523807
1956	All.....	.001 O.S.....	8	522968
1957	All.....	.001 O.S.....	8	523808
1956	All.....	.003 O.S.....	8	522969
1957	All.....	.003 O.S.....	8	523809
1957	All.....	.005 O.S.....	8	523810
		Group 0.297 VALVE, EXHAUST		
1956	All.....	std.....	8	522847
1957	All.....	std.....	8	523803
1956	All.....	.001 O.S.....	8	522971
1957	All.....	.001 O.S.....	8	523804
1956	All.....	.003 O.S.....	8	522972
1957	All.....	.003 O.S.....	8	523805
1957	All.....	.005 O.S.....	8	523806
		Group 0.303 SPRING, VALVE		
1956	All..... Inner	16	522846
1956	All..... Outer	16	522872
1957	All..... Inner	16	524598
1957	All..... Outer	16	524593
		Group 0.333 ARM, BALL AND PUSH ROD PKG., VALVE ROCKER		
1956	All.....	16	522974
		Group 0.386 COVER, VALVE ROCKER ARM		
1956	All..... R.H.	1	522897
1957	All..... R.H.	1	528645
1957	All..... L.H.	1	524922
		Group 0.439 COVER, VALVE PUSH ROD		
1956	All.....	1	523857
		Group 0.459 LIFTER, VALVE		
1956-57	All.....	hydraulic.....	16	5231615
		Group 0.519 CAMSHAFT, ENGINE		
1956	All.....	1	522869
1957	All.....	1	524886
		Group 0.603 ROD ASSEMBLY, CONNECTING		
1957	All.....	8	528979
		Group 0.646 CRANKSHAFT, ENGINE		
1957	All S.T. heavy duty.....	1	529207
		Group 0.659 BALANCER, HARMONIC		
1956-57	All S.S. exc. A.C.....	1	523989
1956	All P.S. exc. A.C.....	1	523998
1957	All P.S. exc. A.C. heavy duty.....	1	528775
1957	All P.S. exc. A.C.....	1	524981
1957	All A.C.....	1	529763 ■
		Group 0.737 ECCENTRIC, CAMSHAFT FUEL AND VACUUM PUMP		
1957	All S.T.....	1	518052 ■

1956	Group 0.795	FORK PKG., CLUTCH RELEASE			
	All heavy duty.....		1	524065	
1956	Group 0.799	BEARING ASSY., CLUTCH RELEASE			
	All heavy duty.....	ball type.....	1	900018	
1956	Group 0.859	COVER AND PRESSURE PLATE ASSY., CLUTCH			
1957	All S.T. heavy duty.....		1	523864	
	All S.T. heavy duty.....		1	528901	
1957	Group 0.886	PLATE ASSY., CLUTCH DRIVEN			
	All S.T. heavy duty.....		1	529133	
1956	Group 1.148	GAUGE, WATER TEMPERATURE, INSTRUMENT PANEL			
	All.....		1	1513172	
1956	Group 1.153	ELBOW, INTAKE MANIFOLD WATER OUTLET			
1957	All.....		1	522855	
	All.....		1	523921	
1956	Group 1.159	HOSE, RADIATOR			
1956	All.....	Inlet.....	1	522867	
1956	All heavy duty.....	Inlet.....	1	522996	
1956	All heavy duty.....	Outlet.....	1	522997	
1957	All exc. A.C.....	Inlet.....	1	523922	
1957	All A.C.....	Inlet.....	1	523923	
1957	Group 1.359	FAN ASSY., ENGINE			
1957	All heavy duty.....		1	528637	
1957	All P.S. exc. A.C.....	SPACER, engine fan.....	1	529359	
1957	All P.S. exc. A.C.....	BOLT, engine fan..... (3/16" x 24 x 2" long)	4	9410933	
1957	Group 1.406	PULLEY, BELT ADJUSTING			
	All.....		1	528889	
1956-57	Group 1.416	BELT, FAN AND GENERATOR			
1957	All exc. A.C.....	(3/8" wide x 57 1/2" long)	1	522930	
1957	All exc. A.C.....	(56 1/2" long)	1	523915	
1957	All A.C.....	(1/2" wide x 57 1/2" long)	1	524603	
1957	All.....	(58 3/4" long)	1	528884	
1957	All.....	fan..... (45 1/2" long)	1	528885	
1957	Group 1.758	CAP, CRANKCASE BREATHER AND OIL FILLER			
	All.....		2	1553088	
1957	Group 1.760	CLAMP-EXTENSION, OIL FILLER TUBE			
1957	All.....	CLAMP	1	524595	
1957	All.....	EXTENSION	1	524596	
1956	Group 1.762	PIPE, CRANKCASE VENTILATOR OUTLET			
1957	All.....		1	522865	
1957	All.....	Upper.....	1	528783	
1957	All.....	Lower.....	1	528784	
1956	Group 1.763	BRACKET, CRANKCASE VENTILATOR OUTLET PIPE			
1957	All heavy duty.....		1	522850	
	All.....	Upper.....	1	528785	
1956-57	Group 1.773	RING, VENTILATOR OUTLET PIPE SEAL RETAINING			
1957	All heavy duty.....		1	520587	
	All.....	SEAL, crankcase vent outlet.....	1	518109	
1956-57	Group 2.170	COIL, IGNITION			
	All.....		1	1115099	
1956-57	Group 2.173	RESISTANCE UNIT, IGNITION COIL			
	All.....		1	1931385	
1956	Group 2.183	BRACKET, IGNITION COIL SUPPORT			
1957	All heavy duty.....		1	524623	
	All.....		1	528723	

Group 2.239		PACKAGE, SPARK PLUG AND COIL WIRES		
1956-57	All heavy duty	-----	1	2968242
Group 2.251		BRACKET, SPARK PLUG WIRE		
1956	All	to coil	1	522915
1957	All heavy duty	to coil	1	524624
1957	All	L.H.	1	521526
Group 2.270		PLUG, SPARK		
1956	All	type 44, 14 m/m	8	1559492
Group 2.274		PULLEY AND FAN, GENERATOR		
1956-57	All	FAN (3 1/2" dia.)	1	1922950
1956-57	All	PULLEY (3 1/2" dia.)	1	1936435
Group 2.277		BRACKET, GENERATOR MOUNTING		
1956	All	-----	1	522851
1957	All	-----	1	524853
1957	All	belt adjusting and generator mounting	1	528886
Group 2.317		STRAP, GENERATOR ADJUSTING		
1956-57	All exc. A.C.	-----	1	522864
1957	All A.C.	-----	1	528719
Group 2.361		DISTRIBUTOR, IGNITION		
1956	All S.T.	w/cap and rotor	1	1110888
1957	All S.T. heavy duty	w/cap and rotor	1	1110897
Group 2.362		HOUSING, DISTRIBUTOR		
1956	All	-----	1	1935926
Group 2.372		SHAFT, DISTRIBUTOR MAIN		
1956	All	-----	1	1935929
Group 2.381		CAM ASSEMBLY, DISTRIBUTOR		
1956	All	-----	1	1935930
Group 2.385		PLATE, DISTRIBUTOR BREAKER		
1956	All	-----	1	1935507
Group 2.388		WEIGHT, DISTRIBUTOR		
1956	All	-----	2	1924737
Group 2.389		SPRING, DISTRIBUTOR WEIGHT		
1956	All	-----	2	1935843
Group 2.400		LEAD, DISTRIBUTOR TERMINAL		
1956	All	-----	1	1930587
Group 3.201		BRACKET, FUEL PUMP TO FILTER PIPE		
1956	All	-----	1	523035
1956	All	ELBOW, front carb. to rear carb. (3/16" x 90°)	1	504500
1957	All	vacuum pipe to front carb. (3/8" x 90°)	1	528721
1957	All	vacuum pipe to center carb. (1/4" x 90°)	1	528722
1957	All H.T.	TEE, front carb. to center carb. pipe (3/8" to 5/16")	1	528199
1957	All	fuel filter to front carb. (3/8")	1	528727
1957	All S.T. heavy duty	fuel line to carbs.—4 way (3/8" to 5/16")	1	528959
1957	All S.T. heavy duty	vacuum check valve—4 way (3/8")	1	528996
Group 3.265		MANIFOLD, INTAKE		
1956	All	-----	1	523550
1957	All	-----	1	528786

Group 3.288		STUD, MANIFOLD TO CARBURETOR			
1957	All	-----	-----	2	518101
Group 3.402		CLEANER AND SILENCER, CARBURETOR AIR			
1956	All	-----	-----	2	1552799
1957	All	-----	-----	1	1553222
1957	All S.T. heavy duty	-----	-----	1	1553314
1956	All	-----	ELBOW, carb. air cleaner and silencer	1	1552797
Group 3.403		GASKET-STUD-NUT, AIR CLEANER TO CARBURETOR			
1957	All	-----	GASKET	3	3708408
1957	All	-----	STUD	3	523746
1957	All	-----	NUT	3	148312 (8.920)
Group 3.410		ELEMENT PKG., CARBURETOR AIR CLEANER			
1956	All	-----	Purolator	1	523085 ■
1957	All	-----	type A-59C	1	1553443
Group 3.425		TRUNNION, CARBURETOR THROTTLE ROD			
1956	All	-----	-----	1	522860
Group 3.430		ROD-PIN-CLIP, CARBURETOR THROTTLE CONTROL			
1956	All	-----	ROD, front carburetor throttle	1	522857
1956	All	-----	inter connecting	1	522859
1957	All S.T.	-----	throttle control	1	528756
1957	All H.T.	-----	throttle control	1	528720
1956	All	-----	PIN, front carburetor throttle lever	1	522862
1956	All	-----	rear carburetor throttle lever	1	522861
1957	All	-----	CLIP, throttle control rod to front carb.	1	554285
1957	All	-----	throttle control rod to rear carb.	1	7011249 (8.077) (3.762)
Group 3.585		LEVER, ENGINE THROTTLE CONTROL			
1956	All	-----	-----	1	522911
Group 3.724		GASKET PACKAGE, CARBURETOR			
1956	All	-----	(Rochester)	2	7009952
1957	All	-----	(Rochester) Center	1	7015750 ■
1957	All	-----	(Rochester) Front and rear	2	7015753 ■
Group 3.725		CARBURETOR ASSEMBLY			
1956	All H.T.	-----	(Rochester)	2	7009820
1956	All S.T.	-----	(Rochester)	2	7010600
1957	All H.T.	-----	(Rochester) Center	1	7011350
1957	All S.T.	-----	(Rochester) Center	1	7011500
1957	All	-----	(Rochester) Front	1	7011351
1957	All	-----	(Rochester) Rear	1	7011352
1956	All	-----	KIT, carb. repair (Rochester)	2	7009932
1957	All	-----	(Rochester) Front and rear	2	7015739 ■
1957	All H.T.	-----	(Rochester) Center	1	7015735 ■
1957	All S.T.	-----	(Rochester) Center	1	7015738 ■
Group 3.726		GASKET, CARBURETOR TO MANIFOLD			
1957	All	-----	-----	3	518569
Group 3.729		BODY ASSY., CARBURETOR THROTTLE			
1957	All	-----	(Rochester) Center	1	7011638 ■
1957	All	-----	(Rochester) Front	1	7011090 ■
1957	All	-----	(Rochester) Rear	1	7011639 ■
Group 3.730		AIR HORN, CARBURETOR			
1956	All H.T.	-----	(Rochester)	2	7009868
1956	All S.T.	-----	(Rochester)	2	7010455
1957	All	-----	(Rochester) Center	1	7011380 ■
1957	All	-----	(Rochester) Front	1	7011381 ■
1957	All	-----	(Rochester) Rear	1	7011087 ■
Group 3.734		BOWL ASSY., CARBURETOR FLOAT			
1956	All	-----	(Rochester)	2	7009873
1957	All	-----	(Rochester) Center	1	7011637 ■
1957	All	-----	(Rochester) Front and rear	1	7011088 ■

		Group 3.735	GASKET, CARBURETOR THROTTLE BODY		
1956	All		(Rochester).....	2	7009256
1957	All		(Rochester).....	3	7011326 ■
		Group 3.738	GASKET, CARBURETOR AIR HORN TO BOWL		
1957	All		(Rochester).....	3	7000299 ■
		Group 3.740	TEE, CARBURETOR		
1957	All		front carb. to center carb.....	1	528199
		Group 3.747	PIN, CARBURETOR FLOAT LEVER HINGE		
1957	All		(Rochester).....	3	7002081 ■
		Group 3.750	COVER AND COIL ASSY., CARBURETOR THERMOSTATIC		
1956	All		(Rochester) w/gasket.....	2	7009872
1957	All S.T.		(Rochester).....	Center 1	7011636 ■
1957	All H.T.		(Rochester).....	Center 1	7011635 ■
1956	All		HOUSING ASSY., carb. choke (Rochester)	2	7009288
1957	All		(Rochester).....	Center 1	7011483 ■
1957	All		SCREW, choke housing to air horn (Rochester)	Center 2	7004821 ■
		Group 3.751	VALVE, CARBURETOR CHOKE		
1957	All		(Rochester).....	Center 1	7007151 ■
		Group 3.752	LEVER—PISTON—ROD, CARBURETOR CHOKE		
1957	All		LEVER AND LINK ASSY., carb. choke (Rochester).....	Center 1	7011511 ■
1957	All		LEVER, carb. choke trip (Rochester)	Center 1	7011014 ■
1957	All		PISTON, carb. choke (Rochester)	Center 1	7011799 ■
1957	All		ROD, carb. choke (Rochester)	Center 1	7005817 ■
		Group 3.758	VALVE, CARBURETOR THROTTLE		
	All		auxiliary (Rochester).....	2	7009585
		Group 3.762	LINK—LEVER, CARBURETOR		
1957	All		LINK, front to rear carb.	1	7011009 ■
1957	All		lock out lever.....	1	7011429
1957	All		LEVER, rear carb. lock out	1	7010993 ■
1957	All		LEVER AND PIN ASSY., front carb. actuating	1	7011369 ■
1957	All		rear carb. actuating.....	1	7011370 ■
1957	All		CLIP, carb. rod to rear carb.	1	7011249 ■
1957	All		SCREW, carb. actuating lever retainer	Front and rear 1	7010435 ■
		Group 3.763	PIN—SPRING, CARBURETOR THROTTLE RETURN		
1957	All		PIN	Front and rear 1	7010971 ■
1957	All		SPRING	Front and rear 1	7011003 ■
		Group 3.764	SWITCH—VALVE., CARBURETOR VACUUM CONTROL		
1957	All		SWITCH ASSY., vacuum	1	7011310 ■
1957	All S.T. exc. P.B.		VALVE ASSY., vacuum	1	5454944 ■ (4.955)
		Group 3.765	CONTROL—TANK ASSY., CARBURETOR VACUUM CONTROL		
1957	All		CONTROL ASSY., rear carb. vacuum	1	1998829 ■
1957	All		BRACKET, rear carb. vacuum control	1	7011427 ■
1957	All		LINK, rear carb. vacuum control	1	7011428 ■
1957	All S.T. exc. P.B.		TANK ASSY.	1	523959 ■ (4.902)
		Group 3.766	CAM, CARBURETOR FAST IDLE		
1956	All		(Rochester).....	2	7010028
1957	All		SCREW, carb. fast idle adjusting	1	7001664 ■
		Group 3.786	VENTURI PKG., CARBURETOR		
1956	All		(Rochester) primary.....	2	7010825
1957	All		(Rochester).....	Front and rear 2	7010972 ■
1957	All H.T.		(Rochester).....	Center 1	7011434 ■
1957	All S.T.		(Rochester).....	Center 1	7011513 ■
	All		SCREW, venturi (Rochester)	6	7000293 ■
	All		(Rochester).....	3	7000294 ■
1957	All		GASKET, venturi screw (Rochester)	3	7000295 ■

Group 3.790		GASKET, VENTURI CLUSTER	
1957	All	(Rochester)	3 7000292 ■
Group 3.792		JET, CARBURETOR	
1956	All H.T.	(Rochester) primary—standard	4 7002650
1956	All S.T.	(Rochester) primary—1 step lean	4 7001607
1956	All S.T.	(Rochester) secondary	4 7008673
1956	All H.T.	(Rochester) secondary	4 7008669
1957	All	(Rochester) Center	2 7002662 ■
1957	All	(Rochester) Front and rear	4 7002656 ■
1957	All S.T. heavy duty	JET KIT , main metering	1 7011532
Group 3.814		NEEDLE AND SEAT, CARBURETOR INTAKE	
1957	All	(Rochester)	3 7009458 ■
Group 3.838		PLUNGER AND ROD, CARBURETOR PUMP	
1956	All heavy duty	(Rochester)—4 jet carb.	2 7010846
1957	All	(Rochester) Center	1 7009485 ■
1957	All	(Rochester) Front and rear	2 7011533 ■
Group 3.841		SPRING, CARBURETOR PUMP RETURN	
1957	All	(Rochester) Center	1 7008694 ■
1957	All	(Rochester) Front and rear	2 7004597 ■
Group 3.842		LEVER AND COUNTERSHAFT, CARBURETOR PUMP OPERATING	
1956	All		2 7009519
1957	All	(Rochester) Center	1 7011415 ■
1957	All	CLIP , pump rod Rear	2 7003242 ■
Group 3.843		ROD, CARBURETOR PUMP LEVER ACTUATING	
1957	All	(Rochester) Front and center	2 7005816 ■
1957	All	(Rochester) Rear	1 7011005 ■
Group 3.858		PISTON—VALVE, CARBURETOR POWER	
1957	All S.T.	PISTON ASSY. , power (Rochester) Center	1 7011478 ■
1957	All S.T.	VALVE ASSY. , power (Rochester) Center	1 7009349 ■
1957	All H.T.	(Rochester) Center	1 7006331 ■
Group 3.900		FUEL PUMP PACKAGE	
1956	All	(type 4328) w/electric w/s wiper	1 5593941
Group 4.040		ROD ASSY., TRANSMISSION THROTTLE	
1956	All C.C.-H.T.		1 522789
1956	All H.T. exc. C.C.		1 522992
Group 4.286		LEVER, TRANSMISSION THROTTLE CONTROL	
1956	All C.C.-H.T.	Outer	1 521523
1956	All H.T. exc. C.C.	Outer	1 522229
1957	All H.T.	Outer	1 524579
Group 4.665		CYLINDER, FRONT WHEEL BRAKE	
1956-57	All heavy duty	R.H.	1 5455631
1956-57	All heavy duty	L.H.	1 5455632
Group 4.666		VALVE, FRONT WHEEL BRAKE CYLINDER BLEEDER	
1956	All heavy duty		2 2261467
Group 4.667		CUP, FRONT WHEEL BRAKE CYLINDER	
1956-57	All heavy duty		4 5455298
1956-57	All heavy duty	REPAIR KIT , front wheel cylinder	2 5455326

Group 4.668		PISTON, WHEEL CYLINDER	
1956	All heavy duty.....	Front 4	5450648
Group 5.001		SUPPORT ASSY., FRONT BRAKE	
1956-57	All heavy duty.....	2	5454341
Group 5.017		SHOE AND LINING PACKAGE, BRAKE	
1956-57	All heavy duty.....	Front 1	3630442
1956-57	All heavy duty.....	primary Rear 2	5456088 ■
1956-57	All heavy duty.....	secondary Rear 2	5456089 ■
Group 5.026		SPRING, FRONT BRAKE SHOE ADJUSTING SCREW	
1956-57	All heavy duty.....	2	5450534
Group 5.055		PIN, FRONT BRAKE SHOE ANCHOR	
1956-57	All heavy duty.....	2	3693513
Group 5.117		COVER, BRAKE ADJUSTING HOLE	
1956-57	All heavy duty.....	2	1455658
Group 5.387		HOUSING ASSY., REAR AXLE	
1956	All.....	1	523026
Group 5.420		SHAFT, REAR AXLE	
1956	All heavy duty.....	2	523075
1956	All heavy duty.....	2	524799
Group 5.529		RING GEAR AND PINION PKG., DIFFERENTIAL	
1956	All.....	41-9 ratio (4.55-1) 1	513460
Group 5.544		SHAFT, PROPELLER	
1956	All 27 S.T. heavy duty.....	1	5671047
1957	All 27 S.T. heavy duty.....	1	5671531
1957	All 27 S.T. heavy duty.....	balanced for race cars 1	5671891
Group 5.809		DRUM, REAR WHEEL BRAKE	
1956	All heavy duty.....	use w/3/16" hub bolts 2	523082
Group 5.812		BOLT, WHEEL TO HUB	
1956	All heavy duty.....	R.H. thread Rear (1/2"-20x1 3/4") 5	522941
1956	All heavy duty.....	L.H. thread Rear (1/2"-20x1 3/4") 5	522942
Group 5.813		NUT, WHEEL HUB BOLT	
1956-57	All heavy duty.....	(Special Hex. 3/16"-18) 20	566537
Group 5.815		DRAIN, REAR BRAKE OIL	
1956-57	All heavy duty.....	use w/3/16" hub bolts 2	523077
Group 6.020		KNUCKLE, STEERING	
1956	All heavy duty.....	R.H. 1	522979
1956	All heavy duty.....	L.H. 1	522980
Group 6.023		SUPPORT, STEERING KNUCKLE	
1956-57	All heavy duty.....	R.H. 1	522981
1956-57	All heavy duty.....	L.H. 1	522982

	Group 6.037	GUARD, FRONT BRAKE OIL			
1956-57	All heavy duty	-----	2	1457052	
	Group 6.038	GASKET, FRONT BRAKE TO STEERING KNUCKLE			
1956-57	All heavy duty	-----	2	1437917	
	Group 6.103	ARM, STEERING KNUCKLE			
1956-57	All S.S.	-----	R.H.	1	558058
1956-57	All S.S.	-----	L.H.	1	558059
	Group 6.306	HUB AND DRUM, FRONT WHEEL BRAKE			
1956-57	All heavy duty	-----	2	523071	
	Group 6.314	CONE, FRONT WHEEL BEARING INNER			
1956	All heavy duty	-----	2	909562	
	Group 6.315	CONE, FRONT WHEEL BEARING OUTER			
1956	All heavy duty	-----	2	909525	
	Group 6.316	CUP, FRONT WHEEL BEARING INNER			
1956-57	All heavy duty	-----	2	909662	
	Group 6.317	CUP, FRONT WHEEL BEARING OUTER			
1956-57	All heavy duty	-----	2	909625	
	Group 6.318	BALLS AND SEPARATOR, FRONT WHEEL BEARING INNER			
1956-57	All heavy duty	-----	2	909762	
	Group 6.319	BALLS AND SEPARATOR, FRONT WHEEL BEARING OUTER			
1956	All heavy duty	-----	2	909725	
	Group 6.326	SEAL ASSY., FRONT WHEEL HUB OIL			
1956-57	All heavy duty	-----	2	1440587	
	Group 6.335	BOLT, FRONT WHEEL HUB			
1956-57	All heavy duty	-----	($\frac{9}{16}$ "-18x $\frac{1}{16}$ ")	10	523072
	Group 6.606	BRACKET, POWER STEERING PUMP MOUNTING			
1957	All P.S. exc. A.C.	-----	1	523683	(9.180)
	Group 6.655	PULLEY, POWER STEERING PUMP GUIDE			
1957	All P.S.	-----	1	524979	
	Group 6.660	BELT, STEERING GEAR OIL PUMP			
1957	All P.S. exc. A.C.	-----	1	529358	
	Group 7.241	SHAFT, FRONT STABILIZER			
1956-57	All heavy duty	-----	1	522925	
	Group 7.243	INSULATOR, FRONT STABILIZER BAR			
1956-57	All heavy duty	-----	2	522924	
	Group 7.345	SHOCK ABSORBER			
1956-57	All	-----	Front	2	5352226
1956-57	All	-----	Rear	2	5513346