

PONTIAC MASTER PARTS CATALOG

1.002-1.123

YEAR	MODEL	PART NAME	Per Car	Part No.	
Group 1.002 REPAIR KIT, WATER PUMP					
NOTE: The kits consist of gaskets, impeller, shaft and bearing, spring, seals, washers and retainers.					
1939-40	P/6	for packless pump	1	509120	
1938-48	All exc. P/6 1939-40		1	509119	
1949-53	All		1	513164	
1954	All		1	518764	
Group 1.069 PUMP ASSEMBLY, WATER					
1937-48	All exc. P/6 1939-40		1	518760	
1939-40	P/6	less body back plate	1	514290	
1949-54	All exc. P.G.		1	518661	
1953	All P.G.	w/gasket	1	522938	
1955-56	All		1	518038	
Group 1.073 BOLT, WATER PUMP TO BLOCK					
1937-48	All	(Hex. $\frac{3}{8}$ "-16x1 $\frac{1}{4}$ ")	3	456656	(8.900)
1949-54	All	(Hex. $\frac{3}{8}$ "-16x1 $\frac{1}{4}$ ")	4	180128	(8.900)
1955-56	All	STUD, pump to sprocket cover	4	518172	
Group 1.079 GASKET, WATER PUMP TO BLOCK					
NOTE: See Group 1.114 for body to plate gasket.					
1937-48	All		1	503539	
1949	All	use with 511242 pump	1	511247	
1949-54	All	exc. with 511242 pump on 1949	1	513611	
1955-56	All	water pump to cover	1	518042	
Group 1.091 RETAINER, WATER PUMP SHAFT					
1933-52	All	with packless pump	1	408073	
Group 1.109 IMPELLER, WATER PUMP					
1938-54	All	with packless pump	1	501182	
Group 1.113 PLATE, WATER PUMP BODY					
1937-48	All	with service pump on 1940 thru 48	1	508968	
1949-54	All	use 513611 gasket—Gr. 1.079	1	513610	
1940-48	All	BOLT, water pump body to plate (Hex. $\frac{3}{8}$ "-24x1 $\frac{1}{2}$ ")	3	181614	(8.900)
1949-50	All	(Hex. $\frac{3}{8}$ "-24x2")	1	181648	(8.900)
1949-54	All	(Flt. Hd. $\frac{3}{16}$ "-18x $\frac{3}{8}$ ")	1	133822	(8.908)
Group 1.114 GASKET, WATER PUMP BODY TO PLATE					
NOTE: See Group 1.079 for plate to block gasket.					
1937-48	All		1	499887	
1949-54	All		1	511245	
Group 1.121 RING, WATER PUMP SEAL WASHER RETAINER					
1933-48	All	with round seal washer	1	500580	
Group 1.123 SEAL PACKAGE, WATER PUMP					
NOTE: This package consists of 1 each: retainer, seal, spring, washer and wire.					
1933-53	All		1	509121	
1954	All	SEAL ASSY., water pump	1	518198	

Group 1.135		TUBE, WATER INLET			
1937-54	P/6	in cylinder block	1	508708	
1937-54	P/8	in cylinder block	1	508710	
1955-56	P/8	in cylinder head	2	518063	
Group 1.146		PLUG, CYLINDER BLOCK CORE HOLE			
1936-56	All	(1 $\frac{15}{16}$ " O.D.)	AR	515631	
Group 1.148		GAUGE, WATER TEMPERATURE, INSTRUMENT PANEL			
1939	All		1	1510771	
1940	All		1	1510916	
1941	All		1	1511053	
1942	All		1	1511190	
1946	All		1	1511661	
1947	All		1	1511874	
1948	All		1	1512027	
1949-50	All		1	1512126	
1951-52	All		1	1512287	
1953-54	All	w/tube and engine unit	1	1512458	
1955	All		1	1513075	
1956	All L.H.D.		1	1513171	
1954	All A.C.	GAUGE ASSY., water temp. and oil pressure—w/tube and engine unit	1	1508227	
1956	All A.C.	water temp.—w/tube and engine unit	1	1513242	
Group 1.153		ELBOW, WATER INLET AND OUTLET			
1937-54	All	to cylinder head	Outlet 1	499629	
1955-56	All	to intake manifold	Outlet 1	516110	
1955-56	All	to cylinder head	Inlet 2	518093	
1955-56	All A.C.	radiator outlet to water pump	1	521427	
1956	All H.T. w/oil cooler	to cylinder head	1	521365	
1955-56	All A.C.	PIPE, radiator inlet	1	520990	
Group 1.154		GASKET, WATER INLET AND OUTLET ELBOW			
1933-54	All	to cylinder head	1	494904	
1955-56	All	to intake manifold	1	516111	
1955-56	All	to cylinder head	2	518094	
Group 1.159		HOSE, RADIATOR			
All	All	marked off in inches	(1 $\frac{1}{2}$ "x3 ft.) AR	3701363	
All	All	marked off in inches	(1 $\frac{1}{2}$ "x3 ft.) AR	393881	
1939-40	All	inlet to cylinder head, curved	(1 $\frac{3}{4}$ "x9 $\frac{1}{4}$ ") 1	502025	
1941-48	P/6	inlet to cylinder head, curved	(1 $\frac{3}{4}$ "x13 $\frac{1}{2}$ ") 1	506226	
1941-48	P/8	inlet to cylinder head, curved	(1 $\frac{3}{4}$ "x8 $\frac{1}{2}$ ") 1	506227	
1949-54	P/6	inlet to cylinder head, curved	(1 $\frac{3}{4}$ "x13 $\frac{1}{2}$ ") 1	511596	
1949-54	P/8 exc. A.C.	inlet to cylinder head, curved	(1 $\frac{3}{4}$ "x13 $\frac{1}{2}$ ") 1	511597	
1954	P/8 A.C.	inlet to cylinder head, curved	(1 $\frac{3}{4}$ "x8 $\frac{1}{2}$ ") 1	518750	
1955-56	P/8 exc. A.C.	inlet to cylinder head, curved	(1 $\frac{3}{4}$ "x9 $\frac{1}{2}$ ") 1	518188	
1955-56	P/8 A.C.	inlet to intake manifold, curved	(1 $\frac{3}{4}$ "x12 $\frac{3}{4}$ ") 1	519760	
1955	P/8	inlet to intake manifold	(1 $\frac{3}{4}$ "x3 $\frac{1}{2}$ ") 2	518043	
1956	P/8	pump to cyl. head inlet	(1 $\frac{1}{2}$ "x3 $\frac{1}{2}$ ") 2	522177	
1937-38	All	pump to cyl. head inlet	(1 $\frac{1}{2}$ "x9 $\frac{3}{4}$ ") 1	495192	
1939-40	All exc. 28	outlet, curved	(1 $\frac{1}{2}$ "x14 $\frac{1}{4}$ ") 1	502024	
1939-40	P/8	outlet to pump, curved	(1 $\frac{1}{2}$ "x13 $\frac{1}{2}$ ") 1	502671	
1941-48	P/6	outlet to pump, curved	(1 $\frac{1}{2}$ "x16 $\frac{1}{2}$ ") 1	506228	
1949-54	P/6	outlet to pump, curved	(1 $\frac{3}{4}$ "x17 $\frac{3}{4}$ ") 1	511746	
1949-54	P/8	outlet to pump, curved	(1 $\frac{3}{4}$ "x15 $\frac{1}{8}$ ") 1	511747	
1953	P/8	outlet to pump, curved	(1 $\frac{3}{4}$ "x16") 1	517411	
1954	P/8 A.C.	outlet to pump, curved	(1 $\frac{3}{4}$ "x15 $\frac{1}{8}$ ") 1	518751	
1954	P/8 exc. A.C.	outlet to pump, curved	(1 $\frac{3}{4}$ "x15 $\frac{1}{4}$ ") 1	511747	
1955-56	P/8 A.C.	outlet elbow to pump	(2"x3") 1	521428	
1955-56	P/8 A.C.	outlet to elbow	(2"x8") 1	521429	
1955-56	P/8 exc. A.C.	outlet to pump, curved	(2"x11") 1	518186	
Group 1.160		SPRING, RADIATOR OUTLET HOSE			
1937-48	All	to pump	1	506229	
1949-54	All exc. A.C.	to pump	1	511765	
1954	P/8 A.C.	to pump	1	518752	
1955-56	P/8 exc. A.C.	to pump	1	518187	
1955	P/8 A.C.	to pump	1	519762	
1955-56	P/8 A.C.	to pump (4 $\frac{3}{4}$ " long)	1	522417	
Group 1.166		CLAMP, RADIATOR HOSE			
1933-56	All	inlet or outlet	(1 $\frac{1}{2}$ " to 2 $\frac{3}{4}$ " I.D.) 4	3692864	
1946-56	All	inlet or outlet—aviation type	(1 $\frac{1}{2}$ " to 2 $\frac{1}{4}$ " I.D.) AR	1161694	
		see Group 4.931 for use		111603	
		see Group 8.846 for use		1162079	

Group 1.203 CAP, RADIATOR FILLER

1937-40	P/6	except special	1	594498
1937-48	All	pressure valve type	1	850594
1949-50	All	pressure valve type	1	850796
1951-54	All exc. A.C.	pressure valve type	1	850795
1954	All A.C.	pressure valve type	1	850800
1955	All	pressure valve type	1	850795
1956	All exc. A.C.	pressure valve type	1	850795
1956	All A.C.	pressure valve type	1	850800

Group 1.206 WASHER, RADIATOR FILLER CAP

1937-48	All	sealing	1	499561
---------	-----	---------	---	--------

Group 1.216 BUMPER, RADIATOR SHELL TO HOOD

1937	All	small	8	500222
1939	P/6 Special	small	2	500222
1940	All	small At side panel	10	503865
1940	All	large At bonnet	2	506351 (8.024)

Group 1.219 CORE, RADIATOR

1939-40	P/6	2" thick	1	3113436
1941-48	P/6	2" thick	1	3121015
1941-48	P/8	2 1/2" thick	1	3115919
1949-54	P/6	2" thick	1	3128996
1949-52	P/8	2 1/2" thick	1	3127575
1953-54	P/8 exc. A.C. & P.G.	2" thick	1	3133218
1953	P/8 P.G.	2 1/2" thick	1	3127575
1954	P/8 A.C.	2" thick	1	3132289
1955	P/8 exc. A.C.	2" thick	1	3132708
1955	P/8 A.C.	2" thick	1	3133609
1956	P/8 A.C.	1 3/4" thick	1	3135833
1956	P/8 exc. A.C.	2" thick	1	3135948
1937-39	All	BOLT, radiator core to shell (Hex. 5/16"-24x5/8")	6	181593 (8.900)
1939-40	All	radiator to frame (Carr. 3/8"-16x2")	2	126419 (8.903)
1941-56	All	radiator to frame (Carr. 3/8"-16x1 3/4")	2	126416 (8.903)
1949-56	All	SCREW, radiator to support (Hex. hd. 3/16"-18x3/4")	6	171104 (8.977)

Group 1.229 DRAIN COCK, RADIATOR

1935-54	All	use w/505304 pipe (1/4" pipe thread)	1	111668 (8.951)
1948-54	All	(1/4"x1 5/8" long—closed)	1	511771
1955-56	All	(1/4" pipe thread)	1	3719518

Group 1.240 HOSE, RADIATOR DRAIN

All thru 38	All	(1 1/2" I.D.x1 1/2" O.D.x9" long)	1	500084
1955	All		1	519758
1939-54	All	PIPE, radiator drain—use w/111668 drain cock	1	505304

Group 1.246 THERMOSTAT, CYLINDER HEAD WATER OUTLET

1937-54	All	with permanent anti-freeze 160 degree	1	3132436
1933-53	All	151 degree	1	3126560
1937-53	All	with permanent anti-freeze 170 degree	1	3126590
1955	All	with permanent anti-freeze 160 degree	1	3133596
1955	All	with permanent anti-freeze 170 degree	1	3133597
1955	All	with permanent anti-freeze 180 degree	1	3133698
1956	All exc. A.C.	160 degree	1	3133596
1956	All A.C.	160 degree	1	3126289
1956	All exc. A.C.	with permanent anti-freeze 170 degree	1	3133597
1956	All exc. A.C.	with permanent anti-freeze 180 degree	1	3133698

Group 1.251 RETAINER, WATER OUTLET THERMOSTAT

1937-54	All		1	500171
---------	-----	--	---	--------

Group 1.264 SUPPORT, RADIATOR

1941	All	with baffle	1	505241	
1942-47	All	with baffle	1	506967	
1948	All	with baffle	1	510580	
1949-52	All	with baffle	1	513762	
1953-54	All exc. A.C.	with baffle	1	515640	
1954	All A.C.	with baffle	1	518789	
1955-56	All	with baffle—use w/519236 reinf. for 1955	1	522700	■
1955	All	REINFORCEMENT , radiator splash apron	1	519236	
1956	All A.C.		1	519236	
1953	All	NUT , radiator supt. seal to radiator supt. (spring type)	6	516618	
1953	All	SEAL , radiator supt. to radiator lower tank	1	516621	
1939	All	SCREW , radiator shell to support (Hex. No. 12x $\frac{1}{2}$ ")	AR	145415	(8.977)

Group 1.266 GRILLE, RADIATOR

1938	All		R.H.	1	501059
1938	All		L.H.	1	501060
1940	All	in fender	Side R.H.	1	503674
1940	All	in fender	Side L.H.	1	503675
1941	All		Side L.H.	1	505123
1942	All		Center R.H.	1	506979
1942	All		Center L.H.	1	506980
1946	All		Inner R.H.	1	508869
1946	All		Inner L.H.	1	508870
1946	All		Outer R.H.	1	508879
1946	All		Outer L.H.	1	508880
1947	All	one piece		1	509597
1948	All	one piece, less name plate and No. 1 blade		1	510697

Group 1.266 PANEL, RADIATOR CENTER

1940	All			1	504734
1941	All			1	505196
1942	All			1	507129
1946	All			1	508656

Group 1.266 BLADE, RADIATOR GRILLE

1947	All		No. 1	1	509532
1947	All		No. 2	1	509533
1947	All		No. 3	1	509534
1947	All		No. 4	1	509536
1948	All		No. 1	1	510527
1948	All		No. 2	1	510528
1948	All		No. 3	1	510530
1948	All		No. 4	1	510523

Group 1.266 BAR, RADIATOR GRILLE—CURVED

1949	All		Upper outer R.H.	1	511259
1949	All		Upper outer L.H.	1	511260
1950	All		Upper outer R.H.	1	513717
1950	All		Upper outer L.H.	1	513718
1951-52	All		Upper outer R.H.	1	514655
1951-52	All		Upper outer L.H.	1	514656
1953	All		Upper outer R.H.	1	515173
1953	All		Upper outer L.H.	1	515174
1954	All		Upper outer R.H.	1	517625
1954	All		Upper outer L.H.	1	517626
1955	All		Outer R.H.	1	519731
1955	All		Outer L.H.	1	519732
1956	All		Outer R.H.	1	521730
1956	All		Outer L.H.	1	521731

Group 1.266 BAR ASSY., RADIATOR GRILLE—HORIZONTAL

1949	All	between curved bars—on hood	Upper center	1	511994
1949	All	above vertical bars	Center	1	512151
1949	All	below vertical bars	Lower	1	512161
1950	All	between curved bars—on hood	Upper center	1	513735
1950	All	behind vertical bars	Center R.H.	1	513913
1950	All	behind vertical bars	Center L.H.	1	513914

Group 1.266 BAR ASSY., RADIATOR GRILLE—HORIZONTAL (Continued)

1950	All	below vertical bars	Lower	1	513746
1951	All	between curved bars—on hood	Upper center	1	516245
1952	All	between curved bars—on hood	Upper center	1	516450
1951-52	All	above parking lamp	Center R.H.	1	514776
1951-52	All	above parking lamp	Center L.H.	1	514777
1951-52	All		Lower	1	514623
1953	All	holds grille emblem	Center	1	515109
1953	All	between curved bars—on hood	Upper center	1	516762
1953	All	parking lamp mounted inside	R.H.	1	515646
1953	All	parking lamp mounted inside	L.H.	1	515647
1953	All		Lower	1	516767
1954	All	on hood	Upper center	1	517630
1954	All		Center	1	517663
1954	All		Outer center R.H.	1	517665
1954	All		Outer center L.H.	1	517666
1954	All		Lower	1	517670
1955	All	on hood	Upper center	1	519985
1955	All		Center	1	519982
1956	All	on hood	Upper center	1	521452
1956	All		Center	1	521829
1954	All	BRACKET , center bar to baffle brace		1	517741
1955	All	bumper to center bar outer brace		2	519747
1953	All	EXTENSION , outer bar	R.H.	1	516771
1953	All	outer bar	L.H.	1	515180
1954	All	lower bar	R.H.	1	517677
1954	All	lower bar	L.H.	1	517678
1954	All	INSERT , center bar		1	517639
1951-52	All	SUPPORT , lower bar to bumper apron		1	514791
1956	All	upper center bar to hood		2	521459

Group 1.266 BAR, RADIATOR GRILLE—VERTICAL

1948	All	includes retainers	Center No. 1	1	510506
1948	All	includes retainers	No. 2 R.H.	1	510510
1948	All	includes retainers	No. 2 L.H.	1	510511
1948	All		No. 3 R.H.	1	510517
1948	All		No. 3 L.H.	1	510518
1948	All		No. 4 R.H.	1	510519
1948	All		No. 4 L.H.	1	510520
1949	All		R.H.	4	512158
1949	All		L.H.	4	512159
1950	All		Inner R.H.	1	513723
1950	All		Inner L.H.	1	513724
1950	All		Outer R.H.	1	513725
1950	All		Outer L.H.	1	513726
1951-52	All		R.H.	2	514627
1951-52	All		L.H.	2	514628

Group 1.266 PLATE, RADIATOR GRILLE

1949	All	center bar to upper curved bar	R.H.	1	512087
1949	All	center bar to upper curved bar	L.H.	1	512088
1950	All	center bar to upper curved bar	R.H.	1	513719
1950	All	center bar to upper curved bar	L.H.	1	513720
1950	All	grille to fender finish—outside parking lamp	R.H.	1	513736
1950	All	grille to fender finish—outside parking lamp	L.H.	1	513737
1951	All	grille to fender finish—outside parking lamp	R.H.	1	514631
1951	All	grille to fender finish—outside parking lamp	L.H.	1	514632
1951-52	All	center bar to upper curved bar	R.H.	1	514629
1951-52	All	center bar to upper curved bar	L.H.	1	514630
1953	All	center bar to upper curved bar	R.H.	1	515181
1953	All	center bar to upper curved bar	L.H.	1	515182
1954	All	center bar to lower bar	R.H.	1	517738
1954	All	center bar to lower bar	L.H.	1	517739

Group 1.266 RETAINER, RADIATOR GRILLE

1947	All		Center	1	509537
1947	All		Outer center R.H.	1	509538
1947	All		Outer center L.H.	1	509539
1947	All		Outer R.H.	1	509540
1947	All		Outer L.H.	1	509541
1948	All	blade to vertical bar		13	510554
1949	All	center bar to ornament		1	512100
1950	All	vertical bar to lower bar		4	513730
1950	All	vertical bar to center bar rear		4	513731
1950	All	vertical bar to center bar front		4	513732

Group 1.266 RETAINER, RADIATOR GRILLE (Continued)

1950	All	center bar to ornament	1	513740
1950	All	lower bar to ornament	1	513741
1951-52	All	center bar to lower bar	4	514633
1951-52	All	spinner to lower bar support	1	514790
1951-52	All	spinner to center bar	2	514829

Group 1.267 BOLT-SPACER, RADIATOR GRILLE CENTER PANEL

1941-47	All	BOLT, center panel to support..... (Spec. $\frac{1}{4}$ "-20x $\frac{3}{8}$ ")	AR	505097
1946	All	SPACER, inner to outer grille..... R.H.	3	508628
1946	All	 L.H.	3	508629

Group 1.268 MOLDING-BRACE-SUPPORT-PLATE, RADIATOR GRILLE

1942	All	MOLDING, radiator grille..... R.H.	1	507168
1942	All	 L.H.	1	507169
1946	All	 R.H.	1	508623
1946	All	 L.H.	1	508624
1947	All	 R.H.	1	509566
1947	All	 L.H.	1	509567
1955	All	center bar..... Upper	1	520743
1955	All	center bar..... Center	1	519754
1955	All	center bar..... Outer R.H.	1	519755
1955	All	center bar..... Outer L.H.	1	519756
1953	All	BRACE ASSEMBLY, center bar to lower bar.....	1	515117
1955	All	center bar to fender supt.....	2	520224
1955	All	center bar..... Outer R.H.	1	519745
1955	All	center bar..... Outer L.H.	1	519746
1956	All	center bar to lower impact bar.....	2	521723
1956	All	center bar to hanger bar..... R.H.	1	522110
1956	All	center bar to hanger bar..... L.H.	1	522111
1942-47	All	SUPPORT, center panel to fender.....	1	507128
1948	All	SUPPORT ASSY., radiator grille to front fender.....	1	510526
1954	All A.C.	PLATE, rad. grille to rad. supt. brace tapping.....	1	518772

Group 1.269 SCREW, RADIATOR GRILLE

1941	All	grille to center panel..... (Hex. Hd. Tapping No. 10-12x $\frac{3}{8}$ ")	6	178781	(8.977)
1941-42	All	grille to fender..... (Spec. $\frac{1}{4}$ "-20x $\frac{3}{8}$ ")	4	504368	(8.309)
1941-47	All	grille to support..... (Spec. Hd. $\frac{1}{4}$ "-20x $\frac{3}{8}$ ")	AR	505097	(1.267)
1946-50	All	grille to fender..... (Hex. Hd. Tapping No. 15-10x $\frac{1}{8}$ ")	2	426648	
1946-47	All	grille to fender..... (Hex. Hd. Spec. No. 14-10x1")	2	3651216	(8.206)
1949-50	All	grille to fender..... (Hex. Hd. Tapping No. 10-12x $\frac{3}{8}$ ")	4	178781	(8.977)
1950-52	All	center bar to lower bar.....	AR	426648	
1951-52	All	grille to fender..... (Hex. Hd. No. 14-10x $\frac{1}{2}$ ")	10	189694	(8.977)
1951-52	All	grille to spinner..... (Hex. Hd. Tapping No. 14-10 x $\frac{1}{4}$ ")	4	3650059	(8.143)
1953	All	grille to fender..... (Hex. Hd. Tapping No. 10-12x $\frac{3}{8}$ ")	16	451625	(8.977)
1953	All	center bar to outer bar..... (Hex. Hd. Tapping No. 10-12x $\frac{3}{8}$ ")	10	451625	(8.977)
1953	All	lower bar to outer bar..... (Hex. Hd. Tapping No. 10-12x $\frac{5}{8}$ ")	6	451625	(8.977)
1953	All	extension to outer bar..... (Hex. Hd. Tapping No. 10-12x $\frac{3}{8}$ ")	8	451625	(8.977)
1954	All	 (Hex. Hd. Tapping No. 10-12x $\frac{5}{8}$ ")	AR	444267	(8.977)
1954	All	center bar to outer center bar.....	6	444267	(8.977)
1954	All	center bar to upper outer bar.....	4	444267	(8.977)
1954	All	lower bar ext. to lower and center outer bar.....	8	444267	(8.977)
1954	All	end plate to lower bar, center bar and ext.....	10	444267	(8.977)
1955	All	mdg. to center bar.....	5	444267	(8.977)
1955	All	outer brace to center bar.....	8	3650059	(8.143)
1955	All	outer bar to fender.....	4	3650059	(8.143)
1947	All	NUT, radiator grille to fender..... (Spec. No. 14-10)	2	509573	
1948	All	grille to fender..... Spring type	16	509862	
1951-52	All	grille lower bar to apron..... Spring type (No. 14-10)	4	514310	
1953-54	All	outer bar to apron..... Spring type (No. 14-10)	6	514310	
1955	All	upper mdg. to center bar..... Spring type (No. 10-12)	5	445401	

Group 1.272 BAFFLE, RADIATOR SUPPORT TO FENDER

1942-47	All	 R.H.	1	517036
1942-47	All	 L.H.	1	517037

Group 1.272 Baffle, Radiator Support to Fender (Continued)

1948	All	R.H.	1	510503
1948	All	L.H.	1	510504
1949-52	All	R.H.	1	513763
1949-52	All	L.H.	1	513764
1953-54	All	R.H.	1	515638
1953-54	All	L.H.	1	515639
1955-56	All	R.H.	1	519292
1955-56	All	L.H.	1	519293

Group 1.273 CLAMP, Radiator Grille

1939	All	outer grille	R.H.	4	503287
1939	All	outer grille	L.H.	4	503288

Group 1.277 SHROUD, Radiator Fan

1941-48	P/6			1	505355
1941-48	P/8			1	505436
1949-54	P/6			1	511378
1949-54	P/8			1	517406
1955-56	P/8 exc. A.C.			1	519329
1955	P/8 A.C.			1	520973
1956	P/8 A.C.			1	522489

Group 1.285 Baffle—Brace—Cover—Seal—Support, Radiator (Upper)

1947	All	BAFFLE		1	510012
1948	All	also support for hood catch plate, see Group 8.080		1	510534
1949-50	All	also support for hood catch plate, see Group 8.080		1	511761
1951-52	All			1	514569
1953-54	All exc. A.C.			1	515175
1954	All A.C.			1	518788
1956	All A.C.	hood to radiator brace		1	521787
1954	All A.C.	BRACE ASSY. , radiator support to fender		1	518777
1953-54	All	COVER , radiator upper baffle hole		2	516790
1948	All	FILLER , rad. baffle to frt. fender		2	510579
1949-52	All	SUPPORT , rad. baffle to front fender	Upper	1	511931
1953-54	All	radiator baffle to front fender	Upper	1	515370
1947-48	All	BOLT , baffle to fender support		2	132259 (8.907)
		brkt. (Fl. Hd. 1/4"-20x3/8")		2	509862 (1.259)
1949-50	All	NUT , rad. supt. baffle to inner baffle—spring type		7	516618 (1.264)
1953-54	All	radiator upper baffle seal to baffle—spring type		1	516622
1953-54	All	SEAL , radiator upper baffle to radiator upper tank		4	3650059 (8.143)
1949-54	All	SCREW , upper baffle to frt. fender		7	444267 (8.977)
		support (No. 14-10x3/4")			
1954	All	upper baffle seal to baffle			

Group 1.286 WELT, Radiator Support to Fender Baffle

1942-47	All			2	506975
---------	-----	--	--	---	--------

Group 1.303 PLATE, Radiator Grille Emblem

1942	All	on radiator center panel		1	507091
1953	All	BEZEL , radiator grille emblem		1	516770
1946	All	EMBLEM , radiator grille name plate		1	508941
1949	All	on radiator grille ornament	Lucite	1	512099
1950	All	on radiator grille ornament	Lucite	1	513703
1951	All	on radiator grille spinner	Lucite	1	514692
1952	All	on radiator grille spinner	Lucite	1	516466
1953	All	on radiator grille center bar	Lucite	1	514692
1950	All	NUT , radiator grille emblem plate to ornament—spring type		4	513704
1951-52	All			4	514130
1953	All	bezel to center bar		3	120361 (8.915)
1949	All	RETAINER , radiator grille emblem		1	512176

Group 1.303 PLATE, Radiator Grille Name

1941	All	on hood front		1	505353
1946	All	on radiator grille		1	508940
1947	All	on radiator grille		1	509565
1948	All	on radiator grille		1	510524

Group 1.303 PLATE, RADIATOR GRILLE NAME (Continued)

1951	All	on upper center bar	1	515771	
1952	All	on upper center bar	1	516482	
1953	All	on hood front—red	1	516773	
1953	All	on hood front—black	1	517417	
1954	All	on hood front	1	517548	
1954	All	BAR, hood front name plate	1	517544	
1954	All	BEZEL, hood front name plate	1	517546	
1940	All	CLAMP, hood center grille name plate	2	494157	(3.483)
1952	All	NUT, name plate to center bar—spring type	2	516934	
1953-54	All	name plate to hood	AR	446059	(8.148)
1948	All	RETAINER, radiator grille name plate to grille	1	510525	
1954	All	hood front name plate	2	518822	
1954	All	SPACER, hood front name plate stud	2	517600	
1947	All	SUPPORT, radiator grille name plate	1	509572	
1953-54	All	WASHER, radiator grille name plate	4	511948	(8.039)

Group 1.303 ORNAMENT, RADIATOR GRILLE

1949	All	less lucite emblem plate	1	512164	
1950	All	less lucite emblem plate	1	513698	
1951-52	All	SPINNER, radiator grille—less lucite emblem	1	514634	
1949	All	BRACE, rad. grille ornament to fender support	1	512149	
1950	All		1	513739	
1951-52	All	BRACKET, rad. grille spinner to rad. supt. brace	1	514793	
1951-52	All	SPACER, rad. grille spinner retainer	2	514447	

Group 1.359 FAN, ENGINE

1937-40	All	with packless type pump	Standard	1	501398	
1941-48	All			1	505074	
1949-56	All exc. A.C.			1	519834	
1954	All A.C.	6 blades		1	518685	
1955-56	All A.C.	5 blades		1	520766	
1954	All A.C.	SPACER, engine fan		1	518770	
1955-56	All A.C.			1	520984	
1939-54	All	BOLT, engine fan attaching	(Hex. $\frac{5}{16}$ "-24x $\frac{5}{8}$ ")	4	181593	(8.900)
1955-56	All exc. A.C.		(Special Hex. $\frac{5}{16}$ "-24x $\frac{5}{8}$ ")	4	9409084	
1955-56	All A.C.		($\frac{5}{16}$ "-24x $\frac{3}{4}$ ")	4	128147	(8.900)

Group 1.363 HUB, WATER PUMP AND FAN

1937-54	All	with packless pump		1	507036	
1955-56	All			1	516100	

Group 1.406 PULLEY, WATER PUMP AND FAN

1937-48	All exc. P/6 1939-40	with packless type pump		1	500709	
1939-40	P/6	with packless type pump		1	501911	
1949-54	All	with packless type pump		1	512481	
1955-56	All exc. A.C.			1	518066	
1955-56	All A.C.			1	520983	
1953-54	All P.S.	PULLEY, steering gear oil pump guide—at fan		1	517340	(6.655)
1955-56	All P.S. exc. A.C.			1	519439	(6.655)

Group 1.416 BELT, FAN AND GENERATOR

1937-48	All	approximate length 22 $\frac{1}{2}$ "		1	500064	
1949-51	All w/police gen.			1	512361	
1949-54	All			1	516636	
1955-56	All w/police gen.	auxiliary 6-volt generator		1	518425	
1955-56	All exc. A.C.			1	518069	
1955	All A.C.			1	519335	
1956	All A.C.			1	522519	

Group 1.426 PAN, OIL

1935-38	P/6			1	497120	
1935-52	P/8	use 1—504093 oil level rod on 1935 thru 39		1	511310	
1939-54	P/6			1	515093	
1953-54	P/8			1	515096	
1955-56	P/8			1	518006	
1933-54	All	BOLT, oil pan to block	(Hex. $\frac{5}{16}$ "-18x $\frac{5}{8}$ ")	AR	180075	(8.900)
1955-56	All		(Hex. $\frac{5}{16}$ "-18x $\frac{3}{4}$ ")	AR	180077	(8.900)

Group 1.429 GASKET SET, OIL PAN					
1933-54	P/8		1	517100	
1935-54	P/6		1	517099	
1955-56	P/8		1	519978	
Group 1.430 BAFFLE, ENGINE OIL					
1955-56	P/8		1	518005	
Group 1.453 SCREW, OIL PAN DRAIN					
1935-56	All	less gasket	1	514395	
Group 1.456 GASKET, OIL PAN DRAIN SCREW					
1935-56	All		1	513975	
Group 1.516 ROD—TUBE, OIL LEVEL INDICATOR					
1935-52	All exc. P/8 1940-48	ROD	1	497109	
1940-48	P/8		1	504093	
1953-54	All		1	515091	
1955-56	All		1	518118	
1953-54	All	TUBE , oil level indicator rod	1	514989	
1955-56	All		Upper	518184	
1955-56	All		Lower	518117	
1955-56	All	lower tube to oil baffle	1	518269	
Group 1.519 NUT—SCREW, OIL SUCTION PIPE					
1933-54	All	NUT , oil suction pipe, 1/2" threaded sleeve	1	120243	(8.963)
1941	All	SCREW , suction pipe to cleaner. (Fil. Hd. 1/4"-20x5/8")	2	132259	(8.907)
Group 1.520 GASKET, OIL PUMP SUCTION PIPE FLANGE					
1941	All	at oil cleaner pipe flange	1	506119	
Group 1.565 DRAIN, CRANKSHAFT REAR BEARING OIL					
1936-49	All exc. P/6 1939-49	pipe	1	501723	
1936-49	All exc. P/6 1939-49	GASKET , rear bearing cap oil return pipe	1	498844	
Group 1.604 GASKET, OIL PRESSURE REGULATOR					
1933-54	All	round closed (5/8" I.D.)	1	105453	(8.955)
1955-56	All	(3/4" I.D.)	1	113897	(8.955)
Group 1.609 BALL, OIL PRESSURE REGULATOR					
1936-54	All	(3/16" Dia.)	1	104923	(8.899)
1955-56	All	(5/8" Dia.)	1	147495	(8.899)
Group 1.610 SPRING, OIL PRESSURE REGULATOR					
1936-54	All	use with 513603 Retainer prior to 1950	1	513604	
1955-56	All		1	518268	
Group 1.613 RETAINER, OIL PRESSURE REGULATOR SPRING					
1936-54	All		1	513603	
1955	All		1	518208	
1956	All		1	522632	
Group 1.639 SHAFT, OIL PUMP DRIVE					
1955-56	All		1	518022	
Group 1.643 GEAR, DISTRIBUTOR AND OIL PUMP DRIVE					
1948-54	All		1	505078	
1936-52	All	GEAR & SHAFT PKG., OIL PUMP (with dist. gear)	1	510942	(1.709)
1953-54	All		1	517183	(1.709)
Group 1.644 SPRING, DISTRIBUTOR DRIVE FLAT					
1933-54	All	in gear	3	495016	
1933-54	All	RING , distributor drive spring retainer	1	495061	
1933-47	All	PIN , distributor gear grooved (1/8" x 3/8")	1	142487	(8.940)

1.652-1.723

Group 1.652		PUMP ASSEMBLY, OIL			
1936-54	All			1	517091
1955	All			1	518012
1956	All			1	522635
Group 1.653		BODY, OIL PUMP			
1953-54	All			1	517092
1955-56	All			1	518013
Group 1.655		GASKET, OIL PUMP TO BLOCK			
1933-54	All			1	495009
1955-56	All			1	522103
Group 1.656		SCREEN, OIL CLEANER			
1933-40	All			1	494931
1942-54	All			1	507243
1955-56	All			1	516085
Group 1.658		SHAFT, OIL PUMP DRIVEN GEAR			
1948-52	All			1	511237
1953-54	All			1	517096
1955-56	All			1	518015
Group 1.659		GEAR, OIL PUMP DRIVEN			
NOTE: Do not use 525093 on P/6 1940 between Engine No. 662596 and 663049, use Oil Pump Assembly.					
1929-52	All			1	525093
1953-54	All			1	517093
1955-56	All			1	518016
Group 1.660		CLEANER ASSEMBLY, ENGINE OIL			
1941-54	P/6			1	508343
1941-54	P/8			1	508344
Group 1.660		COVER, OIL CLEANER SCREEN			
1942-54	P/6	includes oil line		1	508345
1942-54	P/8	includes oil line		1	508346
1933-40	All	RETAINER, OIL SCREEN		1	494932
1941	All			1	506180
Group 1.663		CUP, OIL CLEANER			
1942-54	All			1	507237
1942-54	All	GASKET, oil cleaner cup		1	507438
1941	All	SCREW, oil cleaner cup to cover			
		(Fil. Hd. No. 10-32x $\frac{3}{8}$ "	10	132119	(8.907)
1942-54	All	(Fil. Hd. No. 10-32x $\frac{3}{8}$ "	12	132105	(8.907)
Group 1.664		BOLT, OIL PUMP TO BLOCK			
1933-54	All	(Hex. $\frac{3}{8}$ "-16x1 $\frac{1}{4}$ "	2	180124	(8.900)
1955-56	All		2	500177	(0.862)
Group 1.709		GEAR AND SHAFT ASSY., OIL PUMP DRIVE			
1948-52	All		1	511234	
1953-54	All		1	517094	
1955-56	All		1	518018	
1936-52	All	GEAR & SHAFT PKG., OIL PUMP (with dist. gear)	1	510942	
1953-54	All		1	517183	
1928-47	All	KEY, oil pump drive gear (Woodruff $\frac{1}{8}$ "x $\frac{1}{2}$ "	1	106749	(8.960)
Group 1.723		COVER, OIL PUMP BODY			
1933-47	All		1	495021	
1948-54	All		1	511233	
1955-56	All		1	518021	

Group 1.724 GASKET, OIL PUMP COVER					
1933-54	All		1	495020	
Group 1.729 PIPE, OIL GAUGE					
1935-56	All	copper, cut to required length.....($\frac{1}{8}$ "x10 ft. coil)	AR	1399637	(8.964)
Group 1.737 ELBOW—NUT—UNION, OIL GAUGE PIPE					
1935-56	All	ELBOW, to block.....(Threaded sleeve $\frac{1}{8}$ ")	1	134251	(8.963)
1933-56	All	NUT, oil gauge pipe.....(Threaded sleeve $\frac{1}{8}$ " tubing)	2.4	121534	(8.963)
1938-54	All	UNION, oil gauge pipe.....(Threaded sleeve $\frac{1}{8}$ " tubing)	1	144414	(8.963)
Group 1.740 CONNECTOR, COMPRESSION COUPLING					
1934-56	All	distributor to carburetor line.....(Threaded sleeve $\frac{3}{16}$ " tubing)	1	152120	
1935-54	All	vac. pump to w/s cleaner.....(Threaded sleeve $\frac{1}{4}$ " tubing)	1	148330	(8.963)
Group 1.743 GROMMET, OIL GAUGE LINE					
1937-52	All	(2 hole type $\frac{1}{4}$ " dia.)	1	493908	(9.775)
Group 1.758 CAP, CRANKCASE BREATHER AND OIL FILLER					
1940-54	All	with heavy duty air cleaner.....	1	1529885	
1941-54	All	with Std. air cleaner.....	1	1529884	
1955	All	with heavy duty air cleaner.....	2	1551897	
1955	All	A.C. w/2 barrel carb. with heavy duty air cleaner.....	2	1551897	
1955-56	All	with Std. air cleaner.....	2	1552232	
1956	All	with heavy duty air cleaner.....	2	1551897	
Group 1.760 INLET ASSEMBLY, OIL FILLER AND VENTILATOR					
1940-51	P/6	except police car generator.....	1	506731	
1940-51	P/8		1	506731	
1941-51	P/6	for police car generator.....	1	506297	
1952-54	All		1	506731	
Group 1.762 PIPE—CLEANER, CRANKCASE VENTILATOR OUTLET					
1940-54	All	with Std. air cleaner.....	1	504081	
1941-54	All	with heavy duty air cleaner.....	1	506160	
1955	All	with heavy duty air cleaner.....	1	518277	
1955	All	with Std. air cleaner.....	1	518108	
1956	All	with Std. air cleaner.....	1	521816	
1956	All	w/4 barrel carb. with heavy duty air cleaner.....	1	521850	
1941-54	All	CLEANER, crankcase outlet air—w/heavy duty air cleaner.....	1	1529886	
1955-56	All	with heavy duty air cleaner.....	1	1551896	
Group 1.763 BRACKET, CRANKCASE VENT. OUTLET PIPE					
1955	All	Upper	1	519203	
1955-56	All		1	518284	
1956	All	H.T. exc. C.C.Upper	1	521846	
1956	All	S.T.Upper	1	521846	
1956	All	H.T. w/oil cooler.....Upper	1	521350	
Group 1.773 GASKET—SEAL, VENTILATOR OUTLET					
1933-39	All	outlet pipe screw.....(Rd. closed $\frac{5}{16}$ " I.D.)	1	114622	(8.955)
1955	All	SEAL, vent outlet.....	1	518109	
1956	All	L.H.D.	1	522232	
Group 1.779 SCREW, VENTILATOR OUTLET TO BLOCK					
1935-39	P/8	(Hex. $\frac{3}{16}$ "-18x3 $\frac{1}{8}$ ")	1	513564	(0.446)

Group 1.779		CLIP, VENTILATOR OUTLET PIPE				
1940-54	All L.H.D.	to pan	1	504082		
1940-54	All	CLAMP, ventilator outlet pipe (1 1/2")	1	111614	(8.948)	
1955-56	All	(1 3/8")	1	111612	(8.948)	
Group 1.780		BAFFLE, CRANKCASE VENTILATOR				
1955-56	All	Lower	1	518107		
1955-56	All	GASKET, crankcase vent. baffle	1	518162		
1955-56	All	SCREW, baffle to crankcase (5/16" x 3/8" drive)	2	521067		
Group 1.803		GAUGE, OIL PRESSURE				
1938	All		1	1505763		
1946	All		1	1506803		
1947	All		1	1507056		
1948	All		1	1507221		
1949-50	All		1	1507350		
1951-52	All		1	1507535		
1953-54	All		1	1507707		
1955	All		1	1508195		
1956	All		1	1508429		
1954	All A.C.	GAUGE ASSY., oil pressure and water temp.	1	1508227	(1.481)	
Group 1.835		FILTER ASSY., OIL				
1955-56	All	(A.C. type PM-9P)	1	5573599		
Group 1.836		ELEMENT PACKAGE, OIL FILTER				
1955-56	All	A.C. type PF-122	1	5572128		
Group 1.837		BOLT-COVER, OIL FILTER				
1955	All	BOLT, oil filter to block (Hex. 3/8"-16x1 5/8")	3	180127	(8.900)	
1956	All	(Hex. 3/8"-16x1 1/2")	3	456656	(8.900)	
1955-56	All without oil filter	COVER, oil filter pad	1	518166		
Group 1.844		GASKET, OIL FILTER				
1955-56	All without oil filter	oil filter pad cover	1	518167		
1955-56	All	oil filter to block	1	519458		