

YEAR	MODEL	PART NAME	PART NO.	PER CAR	PART NO.
------	-------	-----------	----------	---------	----------

Group 1.050 CLUTCH ASSY., ENGINE FAN

1959-60	All	thermostatic controlled-fluid	1	540055
---------	-----	-------------------------------	---	--------

Group 1.062 HUB-PULLEY, WATER PUMP AND FAN

1937-54	All	HUB, water pump and fan-with packless pump	1	507036
1955-60	All		1	516100
1937-48	All exc. P/6 1939-40	PULLEY, water pump and fan-with packless type pump	1	500709
1949-54	All	with packless type pump	1	512481
1955-57	All S.S. exc. A.C.		1	518066
1955-56	All A.C.		1	520983
1957	All A.C.		1	529555
1957	All P.S. w/F.I. or 3/2 B.C., exc. A.C.	single groove	1	518066
1957	All P.S.-2 B.C.-4 B.C.			
1958-60	All exc. A.C.-A.S.-P.S.	single groove	1	518066
1958	All A.C.	double groove (7-7/8" dia.)	1	530610
1958	All A.C.	single groove (▲▲)	1	532873
1958	All P.S.-A.S. exc. A.C. (6.655)	double groove (▲)	1	534583
1958-60	All A.C.	water pump, fan and accessory drive-double groove-w/6 cyl. comp.	1	538547
1959	All P.S.-A.S. exc. A.C. (6.655)	double groove	1	534583
1959-60	All A.C.	double groove for use w-50 amp. gen. (7-7-8" dia.)	1	530610
1959-60	All A.C.	water pump, fan and accessory drive-single groove (7-3/4" dia. x2-3/8" wide)	1	534307
1959-60	All A.C.	water pump, fan and generator drive-single groove (8-1/8" dia. x2-15/16" wide)	1	534309
1953-54	All P.S. (6.655)	PULLEY, steering gear oil pump guide-at fan	1	517340
1955-60	All P.S. exc. A.C. (6.655)		1	534583
1957	All P.S.-F.I.-3/2 B.C. (6.655)		1	524979
1958	All A.C.	water pump fan and compressor guide-(see note 2)	1	532134

▲NOTE: Use with 532492 Harmonic Balancer on cars with air suspension.

▲▲NOTE: For use with double groove compressor pulley.

Group 1.064 FAN, ENGINE

1941-48	All		1	505074
1949-60	All exc. A.C.	4 blades	1	519834
1954	All A.C.	6 blades	1	518685
1955-56	All A.C.	5 blades	1	520766
1957	All A.C.	5 blades	1	524389
1958	All A.C.	5 blades	1	530912
1959-60	All Circulaire A.C.	5 blades	1	530912
1959-60	All Cool Pack A.C.	6 blades	1	534337
1959-60	All	6 blades-w/fluid clutch	1	540168
1954	All A.C.	SPACER, engine fan	1	518770
1955-56	All A.C.		1	520984
1957	All P.S.-F.I.-3/2 B.C. exc. A.C.		1	529359
1957	All A.C.		1	523674
1958-59	All		1	530247
1960	All Circulaire A.C.		1	530247
1960	All exc. A.C.		1	535253
1955-57	All 2 B.C.-4 B.C. exc. A.C.	BOLT, engine fan attaching (Spec. Hex. 5/16"-24x5/8")	4	9409084
1955-56	All A.C. (8,900)	(5/16"-24x3-1/4")	4	128147
1957-58	All A.C. (8,900)	(Hex. 5/16"-24x2-1/4")	4	181621
1957	All P.S.-F.I.-3/2 B.C. exc. A.C.	(5/16"-24x2")	4	9410933
1958-59	All exc. A.C.	(5/16"-24x2-1/4")	4	9410936
1960	All Circulaire A.C.	(5/16"-24x2-1/4")	4	9410936
1960	All exc. A.C. (8,900)	(5/16"-24x3-1/4")	4	189322

Group 1.066 BELT, WATER PUMP, FAN AND ACCESSORY DRIVE

1937-48	All	engine fan	(approximate length 22-1/2")	1	500064
1949-51	All w/police gen.	generator, fan		1	512361
1949-54	All	engine fan		1	516636
1954	All A.C.	compressor drive		1	518689
1955-56	All A.C.	compressor drive		1	519317
1955-56	All w/police gen.	auxiliary 6-volt generator		1	518425
1955-57	All 2 B.C.-4 B.C. exc. A.C.	generator, fan		1	518069
1955	All A.C.	water pump, fan		1	519335
1956	All 2/4 B.C.	generator, fan	(3/8"x57-1/2" long)	1	522930
1956	All A.C.	water pump, fan		1	522519
1957	All A.C.	compressor drive		1	524434
1957	All A.C.-2 B.C.-4 B.C.	generator, fan		1	524601
1957	All A.C.-3/2 B.C.	generator, fan	(1/2"x57-1/2" long)	1	524603
1957	All 3/2 B.C.-F.I. exc. A.C.	generator, fan	(3/8"x56-7/8" long)	1	523915
1957	All A.C.-F.I.	generator, fan	(58-1/4" long)	1	524602
1957	All Cool Pack A.C.-H.T.	compressor drive	(1/2"x76" long)	1	531827
1957	All Cool Pack A.C.-H.T.	engine fan drive	(15/32"x51-1/2" long)	1	531828
1957	All Cool Pack A.C.-H.T.- 3/2 B.C.	engine fan drive	(15/32"x57-13/16" long)	1	531826
1958	All exc. A.C.	generator, fan	(3/8"x56-7/8" long)	1	523915
1958	All A.C.	compressor drive (▲)	(63-1/2" long)	1	532674
1958	All A.C.-P.S. exc. A.S.	compressor drive (▲)	(84-1/2" long)	1	532517
1958	All A.C.-A.S.	compressor drive (▲)	(85-1/2" long)	1	531942
1958	All A.C.	generator fan drive (▲)	(44-1/4" long)	1	532869
1958-60	All A.C.	generator, fan drive- w/6 cyl. comp.	(3/8"x55-1/2" long)	1	542512
1958	All A.C.-S.S.	water pump, fan and idle pulley- w/6 cyl. comp.	(15/32"x47-1/2" long)	1	537807
1958	All Circulaire A.C.	generator, fan and comp.	(66" long)	1	531669
1958	All Cool Pack A.C.	generator, fan and comp.	(67-5/8" long)	1	531559
1958	All Circulaire A.C. exc. A.S. & P.S.	engine fan drive	(1/2"x39-1/4" long)	1	530919
1958	All Cool Pack A.C. exc. A.S. & P.S.	engine fan drive	(3/8"x39-1/8" long)	1	531753
1958-60	All A.C.	compressor drive- w/6 cyl. comp.	(15/32"x58-1/2" long)	1	537097
1958-60	All A.C.-P.S.	compressor drive- w/6 cyl. comp.	(15/32"x62" long)	1	534311
1959-60	All Cool Pack A.C.	water pump, fan and generator- w/6 cyl. comp.	(3/8"x56" long)	1	537607
1959-60	All	water pump and fan	(3/8"x58-1/8" long)	1	534524
1959-60	All S.S.-A.C. exc. A.S.	water pump, fan and idler pulley	(1/2" x 46-1/4" long)	1	534376
1959-60	All A.C.	compressor drive	(1/2"x56-13/16" long)	1	534312
1959	All A.S. exc. A.C.	compressor drive	(1/2"x63-1/2" long)	1	532674

▲NOTE: For use with double groove compressor pulley.

Group 1.069 PUMP ASSEMBLY, WATER

1937-48	All exc. P/6 1939-40	w/gasket	1	522932
1949-54	All exc. P.G.	w/gasket	1	522933
1953	All P.G.	w/gasket	1	522938
1955-60	All	w/gasket	1	540069

Group 1.073 STUD, WATER PUMP TO SPROCKET COVER

1955-60	All	(5/16"-18x5/16"-24x1-13/64")	4	518172
---------	-----	------------------------------	---	--------

Group 1.079 GASKET, WATER PUMP TO BLOCK

NOTE: See Group 1.114 for body to plate gasket.

1937-48	All		1	503539
1949	All	use with 511242 pump	1	511247
1949-54	All	exc. with 511242 pump on 1949	1	513611
1955-60	All	water pump to cover	1	541180

Group 1.109 IMPELLER, WATER PUMP

1938-54	All	with packless pump	1	501182
---------	-----	--------------------------	---	--------

Group 1.113 PLATE, WATER PUMP BODY

1937-48	All	with service pump on 1940 thru 48	1	508968
1949-54	All	use 513611 gasket-Gr. 1.079	1	513610

Group 1.114 GASKET, WATER PUMP BODY TO PLATE

NOTE: See Group 1.079 for plate to block gasket.

1937-48	All		1	499887
1949-54	All		1	511245

Group 1.121 RING, WATER PUMP SEAL WASHER RETAINER

1933-48	All	with round seal washer	1	500580
---------	-----	------------------------------	---	--------

Group 1.123 REPAIR KIT, WATER PUMP

NOTE: The kits consist of gaskets, impeller, shaft and bearing, spring, seals, washers and retainers.

1939-40	P/6	for packless pump	1	509120
1938-48	All exc. P/6 1939-40		1	509119
1949-53	All		1	513164
1954	All		1	518764

Group 1.123 SEAL PACKAGE, WATER PUMP

NOTE: This package consists of 1 each: retainer, seal, spring, washer and wire.

1933-53	All		1	509121
1954	All	SEAL ASSY., water pump	1	518198

Group 1.135 TUBE, WATER INLET

1937-54	P/6	in cylinder block	1	508708
1937-54	P/8	in cylinder block	1	508710
1955-56	All	in cylinder head	2	518063
1957-59	All	in cylinder head	523327 RH	523328 LH

Group 1.148 GAUGE, WATER TEMPERATURE, INSTRUMENT PANEL

1947	All		1	1511874
1948	All		1	1512027
1949-50	All		1	1512126
1951-52	All		1	1512287
1953-54	All	w/tube and engine unit	1	1512458
1955	All		1	1513075
1956	All L.H.D. 2 B.C.-4 B.C.		1	1513171
1956	All 2/4 B.C.		1	1513172
1957	All L.H.D.		1	1513276
1958	All		1	1513500
1959	All		1	1586496
1954	All A.C.	GAUGE ASSY., water temp. and oil pressure- w/tube and engine unit	1	1508227

1956	All A.C.	water temp.-w/tube and engine unit	1	1513242
1960	All	hot	1	1587886
1960	All	cold	1	1587887

Group 1.150 THERMOGAUGE-SWITCH-FITTING, HEAT INDICATOR

1939-52	All	THERMOGAUGE, engine electric	1	1512015
1957-58	All		1	1513462
1959-60	All exc. A.C. & T425E	SWITCH, engine thermogauge-238°	1	1998189
1959-60	All A.C. & T425E	244°	1	1998746
1953-54	All	FITTING, thermogauge to motor	1	515385
1955-56	All		1	519822

Group 1.153 ELBOW, WATER INLET AND OUTLET

1937-54	All	to cylinder head	Outlet	1	499629
1955-57	All 2 B.C.-4 B.C.	to intake manifold	Outlet	1	524666
1955-56	All	to cylinder head	Inlet	2	518093
1955-56	All A.C.	radiator outlet to water pump		1	521427
1956	All H.T. w/oil cooler	to cylinder head		1	521365
1956	All 2/4 B.C.	to intake manifold	Outlet	1	522855
1957	All A.C. & F.I.	to cylinder head	Inlet 524436 RH		
1957	All	to cylinder head	Inlet		518093 LH
1957	All exc. A.C. & F.I.	to cylinder head	Inlet 518093 RH		
1957	All 3/2 B.C.	to intake manifold	Outlet	1	523921
1957	All A.C.	radiator outlet to water pump		1	529591
1957	All Cool Pack A.C.-H.T.	radiator outlet to water pump		1	531831
1958	All 3/2 B.C.	to intake manifold	Outlet	1	529220
1958-60	All 2 B.C.-4 B.C.	to intake manifold	Outlet	1	529219
1958-59	All 2 B.C.-4 B.C.	to intake manifold	Outlet	1	529219
1958	All F.I.	inlet to water outlet manifold		1	524666
1958	All A.C.	radiator outlet to water pump		1	530431
1959	All 3/2 B.C.	to intake manifold	Outlet	1	532649
1960	All 3/2 B.C.	to intake manifold	Outlet	1	536195
1960	All 2 B.C.-4 B.C.	water recirculation hose to timing chain cover (90° x 6-1/4" long)		1	536352
1960	All 2 B.C.-4 B.C. (8.866)	water recirculation hose to intake manifold (90° x 4-1/2" long)		1	524829
1960	All 3/2 B.C. (8.866)	water recirculation hose to timing chain cover (90° x 4-1/2" long)		1	524829
1960	All 3/2 B.C.	water recirculation hose to intake manifold		1	536536
1957	All A.C.	BRACE, intake manifold to rad. inlet hose		1	524591
1958	All	BOLT, intake manifold water outlet fitting (Spec. 3/8"-16x3/8"-24x1-3/4")		2	531008
1959-60	All (8.900)	intake manifold water outlet (3/8"-16x1")		2	180122
1957-58	All F.I.	COVER, cylinder head water outlet Rear 524855 RH			524856 LH
1960	All	NIPPLE, water recirculation hose to timing chain cover (3/8" x 1 3/4" long)		1	535408
1960	All 2 B.C.-4 B.C.	water recirculation hose to intake manifold (3/8"x1-3/4" long)		1	535408
1955-56	All A.C.	PIPE, radiator inlet		1	520990
1959	All A.S. exc. 3/2 B.C.	radiator inlet		1	534366
1959	All A.S.-3/2 B.C.	radiator inlet		1	534367

Group 1.154 GASKET, WATER INLET AND OUTLET ELBOW

1933-54	All	to cylinder head	1	494904
1955-59	All	to intake manifold	1	516111

1955-59	All	to cylinder head	2	518094
1960	All 2 B.C.-4 B.C.	to intake manifold	1	516111
1960	All 3/2 B.C.	to intake manifold	1	536684

Group 1.159 HOSE, RADIATOR

All	All	marked off in inches	(1-1/2"x3 ft.)	AR	3701363
All	All	marked off in inches	(1-3/4"x3 ft.)	AR	393881
1941-48	P/6	inlet to cylinder head, curved	(1-3/4"x13-1/2")	1	506226
1941-48	P/8	inlet to cylinder head, curved	(1-3/4"x8-1/2")	1	506227
1949-54	P/6	inlet to cylinder head, curved	(1-3/4"x13-9/16")	1	511596
1949-54	P/8 exc. A.C.	inlet to cylinder head, curved	(1-3/4"x8-15/16")	1	511597
1954	P/8 A.C.	inlet to cylinder head, curved	(1-3/4"x9-1/2")	1	518750
1955-56	All 2 B.C.-4 B.C. exc. A.C.	inlet to intake manifold, curved	(1-3/4"x12-3/4")	1	518188
1955-56	All A.C.-2 B.C.-4 B.C.	inlet to intake manifold	(1-3/4"x3-1/2")	2	519760
1956	All 2/4 B.C.	inlet to intake manifold	(1-3/4" I.D.x9-1/2")	1	522867
1956	All 2/4 B.C.	inlet to intake manifold	(1-3/4" I.D.x10")	1	522996
1957	All exc. A.C. & 3/2 B.C.	inlet to intake manifold, curved	(1-3/4" I.D.x12-3/4")	1	523919
1957	All A.C. exc. 3/2 B.C.	inlet to intake manifold, curved	(1-3/4" I.D.x22")	1	524592
1957	All 3/2 B.C. exc. A.C.	inlet to intake manifold	(1-3/4" I.D.x10")	1	523922
1957	All 3/2 B.C.-A.C.	inlet to intake manifold	(1-3/4" I.D.x15")	1	523923
1958	All 3/2 B.C.	inlet to intake manifold	(1-3/4" I.D.x13-1/2")	1	530082
1958	All F.I.	inlet to water outlet manifold	(1-3/4" I.D.x19-1/2")	1	531062
1958	All 2 B.C.-4 B.C.	inlet to intake manifold, curved	(1-3/4"x17")	1	530428
1959	All 2 B.C.-4 B.C. exc. A.S.	inlet to intake manifold	(1-3/4" I.D.x16-3/8")	1	532781
1959-60	All 3/2 B.C. exc. A.C.	inlet to intake manifold	(1-3/4" I.D.x13-3/4")	1	532650
1959	All A.S.	inlet to intake manifold	(1-3/4" I.D.x3-1/2")	2	534368
1955-59	All	pump to cyl. head inlet	(1-1/2" I.D.x3-1/2")	2	524631
1939-48	P/8	outlet to pump, curved	(1-1/2"x13-7/8")	1	502671
1941-48	P/6	outlet to pump, curved	(1-1/2"x16-1/2")	1	506228
1949-54	P/6	outlet to pump, curved	(1-3/4"x17-3/4")	1	511746
1949-52	P/8	outlet to pump, curved	(1-3/4"x15-1/8")	1	511747
1953	P/8	outlet to pump, curved	(1-3/4" x 16")	1	517411
1954	P/8 A.C.	outlet to pump, curved	(1-3/4"x15-1/8")	1	518751
1954	P/8 exc. A.C.	outlet to pump, curved	(1-3/4"x15-1/8")	1	511747
1955-58	All A.C.	outlet elbow to pump	(2"x3")	1	521428
1955-56	All A.C.	outlet to elbow	(2"x8")	1	521429
1955-56	All exc. A.C.	outlet to pump, curved	(2"x11")	1	518186
1956	All 2/4 B.C.	outlet to elbow	(2"x3-7/8")	1	522997
1957	All A.C.	outlet to pump	(2" I.D.x6-1/4")	1	529592
1957	All exc. A.C.	outlet to pump, curved	(2" I.D.x 10")	1	523920
1958	All exc. A.C.	outlet to pump, curved	(2" I.D.x 14")	1	530429
1958	All A.C.	outlet to pump	(2" I.D.x4-1/2")	1	530432
1959	All	outlet to pump	(2" I.D.x17-3/4")	1	532782
1960	All 2 B.C.-4 B.C.	inlet to intake manifold	(1-3/4 I.D. x 2-1/8" O.D.x 16-1/2" dev. length)	1	536679
1960	All	outlet to pump	(2" I.D. x 2-13/32" O.D. x 15-3/16" dev. length)	1	536680
1960	All 2 B.C.-4 B.C.	water recirculation-curved	(5/8" I.D.x1" O.D.x11-13/16" dev. lth.)	1	535407
1960	All 3/2 B.C.	water recirculation-curved	(5/8" I.D.x1" O.D.x10-1/2" dev. length)	1	535409
1960	All	water recirculation-cut to required length	(100 ft. roll)	AR	506531

Group 1.160 SPRING, RADIATOR OUTLET HOSE

1937-48	All	to pump	1	506229
1949-54	All exc. A.C.	to pump	1	511765
1954	P/8 A.C.	to pump	1	518752
1955-58	All exc. A.C.	to pump	1	518187
1955	All A.C.	to pump (13" long)	1	519762
1955-56	All A.C.	to pump (4-3/4" long)	1	522417
1959-60	All	to pump	1	532838
1957	All A.C.	BRACE, radiator outlet hose	1	524720

Group 1.166 CLAMP, RADIATOR HOSE

1933-60	All	inlet or outlet (1-1/2" to 2-3/4" I.D.)	AR	3692864
1946-58	All	inlet or outlet-aviation type (1-1/2" to 2-1/4" I.D.)	AR	1161694
		CLAMP (see Group 4.931 for use)		111603
		CLAMP (see Group 3.158 and 8.948 for use)		274461
		CLAMP (see Group 8.846 for use)		1162079

Group 1.203 CAP, RADIATOR FILLER

1937-40	P/6	except special	1	594498
1937-48	All	pressure valve type	1	850798
1949-50	All	pressure valve type	1	850796
1951-54	All exc. A.C.	pressure valve type	1	850795
1954	All A.C.	pressure valve type	1	850800
1955	All	pressure valve type	1	850795
1956	All exc. A.C.	pressure valve type	1	850795
1956	All A.C.	pressure valve type	1	850800
1957-58	All exc. A.C.	pressure valve type	1	850800
1957-58	All A.C.	pressure valve type	1	861050
1959-60	All exc. A.C.-taxi-police-H.D.C. & hvy. duty rad.-T425E	pressure valve type	1	850800
1959-60	All A.C.-taxi-police-H.D.C. & H.T. w/hvy. duty rad-T425E	pressure valve type	1	861050

Group 1.206 WASHER, RADIATOR FILLER CAP

1937-48	All	sealing	1	499561
---------	-----	---------	---	--------

Group 1.219 CORE, RADIATOR

1941-48	P/6	(2" thick)	1	3121015
1941-48	P/8	(2-1/2" thick)	1	3115919
1949-54	P/6	(2" thick)	1	3128996
1949-52	P/8	(2-1/2" thick)	1	3127575
1953-54	P/8 exc. A.C. & P.G.	(2" thick)	1	3133218
1953	P/8 P.G.	(2-1/2" thick)	1	3127575
1954	P/8 A.C.	(2" thick)	1	3132289
1955-56	All exc. A.C.	(2" thick)	1	3135948
1955	All A.C.	(2" thick)	1	3133609
1956	All A.C.	(1-3/4" thick)	1	3135833
1957	All exc. A.C. & heavy duty	(1-3/4" thick)	1	3136873

1957	All H.T. heavy duty exc. A.C.	(1-3/4" thick)	1	3138138
1957	All A.C.	(1-3/4" thick)	1	3136874
1958	All exc. A.C. & heavy duty	(1-3/4" thick)	1	3139960
1958	All A.C.	(1-3/4" thick)	1	3142657
1959-60	All S.T. exc. A.C. taxi, police, H.D.C. & heavy duty	(1-3/4" thick)	1	3147003
1959-60	All A.C. exc. taxi, police & H.D.C.	(1-3/4" thick)	1	3147002
1959-60	All H.T.-taxi-police & H.D.C. All heavy duty		1	3147006
1959-60	All H.T. exc. taxi, police & H.D.C.	(1-3/4" thick)	1	3147002
1959-60	All S.T. police	(1-3/4" thick)	1	3147002
1941-57	All (8.903)	BOLT, radiator to frame (Carr. 3/8"-16x1-3/4")	2	126416
1949-58	All (8.977)	SCREW, radiator to support (Hex. hd. 5/16"-18x3/4")	AR	171104
1959-60	All	radiator to support (Washer face hex. hd. 5/16"-18x3/4")	AR	533971

Group 1.229 DRAIN COCK, RADIATOR

1948-54	All	(1/4"x1-5/8" long-closed)	1	511771
1955-60	All (8.951)	(1/4" pipe thread)	1	455883

Group 1.240 HOSE, RADIATOR DRAIN

1955	All		1	519758
1939-54	All	PIPE, radiator drain-use w/111668 drain cock	1	505304
1959-60	All	TUBE, radiator overflow-rubber (3/4" O.D.x23-3/4")	1	534521
1959-60	All	CLIP, radiator overflow tube	1	534586

Group 1.246 THERMOSTAT, CYLINDER HEAD WATER OUTLET

1933-54	All	with permanent anti-freeze (160 degree)	1	3141725
1937-53	All	with permanent anti-freeze (180 degree)	1	3141726
1955	All	with permanent anti-freeze (160 degree)	1	3133596
1955	All	with permanent anti-freeze (180 degree)	1	3149016
1956	All exc. A.C.	(160 degree)	1	3133596
1956	All A.C.	(160 degree)	1	3136184
1956	All exc. A.C.	with permanent anti-freeze (180 degree)	1	3149016
1957-60	All	(170 degree)	1	3148225
1957-60	All	with permanent anti-freeze (180 degree)	1	3149016

Group 1.251 MANIFOLD-RETAINER, WATER OUTLET THERMOSTAT

1957	All F.I.	MANIFOLD, engine water outlet	1	524854
1958	All F.I.		1	530202
1937-54	All	RETAINER, thermostat	1	500171

Group 1.266 GRILLE, RADIATOR

1958	All exc. SD & H.D.C.		1	530354
1958	All SD & H.D.C.	528716 RH		528717 LH
1959	All	532189 RH		532190 LH

1960	All	536072 RH	536073 LH
1960	All	INSERT, rad. grille headlamp joint. Upper	2 535032
1960	All	Lower	2 536524

Group 1.266 PANEL, RADIATOR CENTER

1946	All	1 508656
1959	All	1 532199
1960	All	Upper 1 536151
1960	All	Lower 1 536044

Group 1.266 BLADE, RADIATOR GRILLE

1948	All	No. 1 1 510527
1948	All	No. 2 1 510528
1948	All	No. 3 1 510530

Group 1.266 BAR, RADIATOR GRILLE-CURVED

1949	All	Upper outer	511259 RH	511260 LH
1950	All	Upper outer	513717 RH	513718 LH
1951-52	All	Upper outer	514655 RH	514656 LH
1953	All	Upper outer	515173 RH	515174 LH
1954	All	Upper outer	517625 RH	517626 LH
1955	All	Outer	519731 RH	519732 LH
1956	All	Outer	522678 RH	522679 LH
1957	All	Outer	523713 RH	523714 LH
1958	All	Outer	529050 RH	529051 LH
1959	All	Upper	533298 RH	533299 LH
1959	All	Lower	532910 RH	532911 LH

Group 1.266 BAR ASSY., RADIATOR GRILLE-HORIZONTAL

1949	All	between curved bars-on hood Upper center	1 511994
1949	All	above vertical bars Center	1 512151
1949	All	below vertical bars Lower	1 512161
1950	All	between curved bars-on hood Upper center	1 513735
1950	All	behind vertical bars Center	513913 RH 513914 LH
1950	All	below vertical bars Lower	1 513746
1951	All	between curved bars-on hood Upper center	1 516245
1952	All	between curved bars-on hood Upper center	1 516450
1951-52	All	above parking lamp Center	514776 RH 514777 LH
1951-52	All	Lower	1 514623
1953	All	holds grille emblem Center	1 515109
1953	All	between curved bars-on hood Upper center	1 516762
1953	All	parking lamp mounted inside 515646 RH	515647 LH
1953	All	Lower	1 515110
1954	All	on hood Upper center	1 517630
1954	All	Center	1 517663
1954	All	Outer center	517665 RH 517666 LH
1954	All	Lower	1 517670
1955	All	on hood Upper center	1 519985
1955	All	Center	1 519982
1956	All	on hood Upper center	1 521452
1956	All	Center	1 521829

1957	All	on hood	Upper center	1	523580
1957	All		Inner center	1	523519
1957	All		Outer center	523726 RH	523727 LH
1958	All	on hood	Upper center	1	528600
1954	All	BRACKET, center bar to baffle brace		1	517741
1955	All	bumper to center bar outer brace		2	519747
1953	All	EXTENSION, outer bar	515179 RH		515180 LH
1954	All	lower bar	517677 RH		517678 LH
1954	All	INSERT, center bar		1	517639
1951-52	All	SUPPORT, lower bar to bumper apron		1	514791
1956	All	upper center bar to hood		2	521459

Group 1.266 BAR, RADIATOR GRILLE-VERTICAL

1949	All		512158 RH	4	512159 LH
1950	All		Inner 513723 RH		513724 LH
1950	All		Outer 513725 RH		513726 LH
1951-52	All		514627 RH	2	514628 LH

Group 1.266 PLATE, RADIATOR GRILLE

1949	All	center bar to upper curved bar	512087 RH		512088 LH
1950	All	center bar to upper curved bar	513719 RH		513720 LH
1950	All	grille to fender finish- outside parking lamp	513736 RH		513737 LH
1951	All	grille to fender finish- outside parking lamp	514631 RH		514632 LH
1951-52	All	center bar to upper curved bar	514629 RH		514630 LH
1953	All	center bar to upper curved bar	515181 RH		515182 LH
1954	All	center bar to lower bar	517738 RH		517739 LH
1958	All SD & H.D.C.	grille splice		2	528822

Group 1.266 RETAINER, RADIATOR GRILLE

1949	All	center bar to ornament		1	512100
1950	All	vertical bar to lower bar		4	513730
1950	All	vertical bar to center bar rear		4	513731
1950	All	vertical bar to center bar front		4	513732
1950	All	center bar to ornament		1	513740
1950	All	lower bar to ornament		1	513741
1951-52	All	center bar to lower bar		4	514633
1951-52	All	spinner to lower bar support		1	514790
1951-52	All	spinner to center bar		2	514829
1959	All	(8,204) radiator grille to grille bars	Lower inner	2	566097
1959	All	(8,204) radiator grille molding to fender	Lower outer	6	566097
1960	All	rad. grille outer mldg. to fender		6	536873
1960	All	center mldg. to upper grille panel		9	536873

Group 1.268 MOLDING-BRACE-SPACER-PLATE, RADIATOR GRILLE

1946	All	MOLDING, radiator grille	508623 RH		508624 LH
1955	All	center bar	Upper	1	520743
1955	All	center bar	Center	1	519754
1955	All	center bar	Outer 519755 RH		519756 LH

1959	All	stainless steel	Upper inner	532548 RH	532549 LH
1959	All	aluminum	Upper outer	532193 RH	532194 LH
1959	All	aluminum	Lower inner	532664 RH	532665 LH
1959	All	aluminum	Lower outer	532661 RH	532662 LH
1960	All		Outer	536681 RH	536682 LH
1960	All		Center	1	536845
1953	All	BRACE ASSEMBLY, center bar to lower bar		1	515117
1955	All	center bar to fender supt.		2	520224
1955	All	center bar	Outer	519745 RH	519746 LH
1956	All	center bar to lower impact bar		2	521723
1956	All	center bar to hanger bar		522110 RH	522111 LH
1957	All	center bar		523526 RH	523527 LH
1958	All	radiator grille		2	531219
1959	All	ESCUTCHEON, grille			
		molding	Upper and lower	533643 RH	533644 LH
1959	All	RETAINER, grille upper inner molding		2	533524
1958	All SD & H.D.C.	SLEEVE, radiator grille to front bumper		6	529141
1958	All SD & H.D.C.	SPACER, radiator grille to front bumper		6	529142
1959	All	grille upper inner molding retainer		2	533523
1954	All A.C.	PLATE, rad. grille to rad. supt. brace tapping		1	518772

Group 1.269 CLIP-SCREW-NUT, RADIATOR GRILLE

1959	All	CLIP, grille lower molding to bar	6	532884
1946-47	All	SCREW, grille to fender. (Hex. Hd. Spec. No. 14-10x1")	2	3651216
1951-52	All	grille to fender (Hex. Hd. No. 14-10x1/2")	10	189694
1951-52	All	grille to spinner (Hex. Hd. Tapping No. 14-10x3/4")	4	3650059
1953	All	grille to fender (Hex. Hd. Tapping No. 10-12x5/8")	16	451625
1953	All	center bar to		
		outer bar (Hex. Hd. Tapping No. 10-12x5/8")	10	451625
1953	All	lower bar to		
		outer bar (Hex. Hd. Tapping No. 10-12x5/8")	6	451625
1953	All	extension to		
		outer bar (Hex. Hd. Tapping No. 10-12x5/8")	8	451625
1954	All	(Hex. Hd. Tapping No. 10-12x5/8")	AR	444267
1954	All	center bar to outer center bar	6	444267
1954	All	center bar to upper outer bar	4	444267
1954	All	lower bar ext. to lower and center outer bar	8	444267
1954	All	end plate to lower bar, center bar and ext.	10	444267
1955	All	mldg. to center bar	5	444267
1955	All	outer brace to center bar (Hex. No. 14-3/4")	8	3650059
1955	All	outer bar to fender	4	3650059
1958	All SD & H.D.C.	splice plate (Hex. Hd. Tapping 1/4"-20x5/8")	8	9702410
1959	All	grille upper bar to fender		
		reinforcement (No. 14-10x3/4")	4	162080
1959	All	grille to fender		
		reinforcement (Flt. Hd. No. 10-12x3/4")	4	531934
1959	All	rad. grille to grille bars (No. 10-12x5/8")	24	451625
1960	All	rad. grille upper & lower panel to		
		fender (Hex. hd. 5/16"-18x7/8")	8	9411835
1960	All	rad. grille head lamp upper insert		
		to lamp (Hex. W. Hd. 10-24 x 1/2")	4	455380
1948	All	NUT, radiator grille to fender Spring type	16	509862
1951-52	All	grille lower bar to apron Spring type (No. 14-10)	4	514310
1953-54	All	outer bar to apron Spring type (No. 14-10)	6	514310

1955	All	upper mldg. to center bar . . . Spring type (No. 10-12)	5	445401
1959	All	grille to upper and lower grille bars . . . (No. 10-12)	24	534146
1959	All	grille inner mldg. to lower grille bars . . . (No. 10-24)	6	441239
1959	All	grille molding to bars and fenders (No. 10-24)	AR	446059
1959	All	grille upper bar to fender reinf. (No. 14-10)	4	454421
1959	All	grille lower bar to fender reinf. (No. 14-10)	2	454421
1959	All	grille panel to fender reinforcement . . . (No. 14-10)	2	454421
1959	All	upper and lower grille mldg. escutcheon . . (3/16")	4	274999
1960	All	rad. grille center mldg. to upper panel . . (No. 10-24)	9	441239
1960	All	rad. grille outer mldg. to fender (No. 10-24)	6	441239
1959	All	RIVET, grille upper and lower bar	24	534404
1958	All SD & H.D.C.	WASHER, radiator grille to upper impact bar (Spec. Flat 1")	2	1283465
1959	All	grille and bars to reinforcement	30	534166

Group 1.270 SUPPORT, RADIATOR

1942-47	All	with baffle	1	506967
1949-52	All	with baffle	1	513762
1953-54	All exc. A.C.	with baffle	1	515640
1954	All A.C.	with baffle	1	518789
1955-56	All	with baffle-use w/519236 reinf. for 1955	1	522700
1957	All A.C. exc. 2867SD	with baffle	1	524070
1957	All exc. A.C. & 2867SD	with baffle	1	523194
1957	All 2867SD-A.C.	with baffle	1	528390
1957	All 2867SD exc. A.C.	with baffle	1	528389
1959	All exc. A.S.	with baffle and seal	1	533125
1959	All A.S.	with baffle and seal	1	533512
1960	All	with baffle and seals	1	536356
1959-60	2167, 2867 & H.D.C.	CUSHION, radiator supt. to frame mounting	2	533404
1959-60	All exc. 2167, 2867 & H.D.C. (9.023)	INSULATOR, radiator supt. mtg. bracket to frame - rubber (1-3/4" O.D., x7/8" I.D., x9/16" thick)	2	530855
1959-60	2167, 2867 & H.D.C.	 (1-15/16" O.D., x35/64" I.D., x7/16" thick)	2	533403
1959-60	All exc. 2167, 2867 & H.D.C. (9.023)	w/washer and spacer-striped w/white paint	2	533658
1934-57	All	SHIM, radiator support cushion (.089" thick-w/two holes)	AR	499723
1949-57	All	 (.060" thick-slotted)	AR	513290
1958	All	 (.060" thick)	AR	530117
1959-60	All exc. 2167, 2867 & H.D.C. (9.023)	radiator supt. bracket to frame (.060")	AR	530117
1959-60	2167, 2867 & H.D.C.	radiator supt. to frame (.060")	AR	533010
1960	All exc. 2167, 2867 & H.D.C. (9.023)	rad. support to bracket (.120")	AR	530119
1949-55	All	SPACER, radiator support to frame	AR	513165
1959-60	2167, 2867 & H.D.C.	radiator supt. cushion	2	533405
1933-56	All	PLATE, radiator support cushion	2	495418
1957	All		AR	522435
1959-60	2167, 2867 & H.D.C.	RETAINER, radiator supt. mounting cushion	2	533401
1959-60	2167, 2867 & H.D.C.	radiator supt. mounting insulator	2	533402
1959	All A.S.	radiator baffle air suspension tank opening seal . . .	1	533315
1953	All	NUT, radiator supt. seal to radiator supt. (spring type)	6	516618
1959-60	2167, 2867	radiator supt. mtg. cushion retainer-spring type . . .	2	534471
1953	All	SEAL, radiator supt. to radiator lower tank	1	516621
1959	All A.S.	radiator baffle air suspension tank opening	1	533316

Group 1.272 BAFFLE, RADIATOR SUPPORT

1949-52	All	BAFFLE, radiator supt. to fender	513763 RH	513764 LH
1953-54	All		515638 RH	515639 LH
1955-57	All		519292 RH	519293 LH
1949-50	All	BAFFLE, radiator upper		1 511761
1951-52	All			1 514569
1953-54	All exc. A.C.			1 515175
1954	All A.C.			1 518788
1956	All A.C.	hood to radiator brace		1 521787
1958	All exc. A.C.	with reinforcement		1 529014
1958	All A.C.	with reinforcement		1 529252

Group 1.274 APRON, RADIATOR SPLASH

1949-54	All	to radiator cross member		1 517010
1949-52	All	to radiator support		1 511846
1953-54	All	to support and baffles		1 515031
1955	All			1 520005
1956	All			1 519235
1957	All			1 523688
1958	All			1 528636
1958	All exc. F.I.	w/radiator lower baffle		1 530412
1958	All F.I.	w/radiator lower baffle		1 530916
1959	All			1 534636
1955	All	REINFORCEMENT, splash apron		1 519236
1956	All A.C.	splash apron		1 519236
1958	All	splash apron to frame		1 530673
1960	All			1 536027

Group 1.274 BRACKET-COVER-SUPPORT-RETAINER-SEAL, RADIATOR

1958	All	BRACKET ASSY., radiator mounting		1 530186
1959-60	All exc. 2167, 2867 & H.D.C.	radiator supt. mounting	534192 RH	534193 LH
1953-54	All	COVER, radiator upper baffle hole		2 516790
1949-52	All	SUPPORT, rad. baffle to front fender	Upper	1 511931
1953-54	All	radiator baffle to front fender	Upper	1 515370
1958	All H.T. exc. D & SD	RETAINER, radiator upper baffle seal	531628 RH	531629 LH
1959	All A.C.	radiator splash apron seal	Inner	1 533511
1959	All A.C.	radiator splash apron seal	Outer 533694 RH	
1959	All A.C.	radiator splash apron seal	Outer	2 531928
1959	All A.C.	radiator splash apron seal	Intermediate	2 531929
1960	All A.C.	rad. splash apron seal	Inner 536340 RH	536341 LH
1960	All A.C.		Outer	2 536335
1960	All	SHIELD, radiator engine splash	535227 RH	535228 LH
1953-54	All	SEAL, radiator upper baffle to radiator upper tank		1 516622
1958	All H.T. exc. D & SD	radiator upper baffle		2 530403
1958	All	radiator lower baffle to fender	Upper	2 530408
1958	All	radiator lower baffle to fender	Lower	2 530407
1959	All	radiator baffle to fender	Upper	2 533073
1959	All	radiator baffle to fender	Lower	2 533074
1959	All A.C.	radiator splash apron to front bumper	Inner	1 533487
1959	All A.C.	radiator splash apron to bumper	Outer	2 533486
1959	All A.C.	radiator splash apron front bumper intermediate		2 532387
1959-60	All A.C.-taxi-police & hvy. duty rad.	radiator supt. to fender brace		1 533515
1960	All	rad. baffle to fender	Upper	2 536354
1960	All	rad. baffle to fender	Lower	2 536355
1960	All A.C.	rad. splash apron front bumper	Center	1 536334
1960	All A.C.	rad. splash apron front bumper	Intermediate	2 536347

1960	All A.C.	rad. splash apron front bumper	Outer	2	536337
1959-60	All A.C.-taxi, police, hvy. duty rad. & trailer	FASTENER, radiator supt. to fender brace seal	AR		533516
1959-60	All exc. 2167, 2867 & H.D.C. . .	WASHER, radiator supt. bracket to frame . (15/32" I.D. x 1-5/8" O.D. x 1/8" thick)	2	1310521	
1958-60	All A.C. (9,649)	rad. splash apron front bumper intermediate seal . .	12	533863	

Group 1.276 NUT-SCREW, RADIATOR BAFFLE

1949-50	All (1,269)	NUT, rad. supt. baffle to inner baffle-spring type . . .	2	509862	
1953-54	All (1,264)	radiator upper baffle seal to baffle-spring type . . .	7	516618	
1949-54	All (8,143)	SCREW, upper baffle to front fender support (No. 14-10x3/4")	4	3650059	

Group 1.277 SHROUD, RADIATOR FAN

1941-48	P/6		1	505355	
1941-48	P/8		1	505436	
1949-54	P/6		1	511378	
1955-57	All exc. A.C.-F.I.		1	519329	
1955-56	All A.C.		1	522459	
1957	All A.C.		1	523673	
1959-60	All A.C.-taxi-police-H.D.C. & heavy duty rad.		1	536651	
1959-60	All exc. A.C.-taxi-police- H.D.C. & heavy duty rad. . .	SHIELD, radiator fan top	1	536504	

Group 1.303 BEZEL-EMBLEM, RADIATOR GRILLE

1953	All	BEZEL, radiator grille emblem	1	516770	
1946	All	EMBLEM, radiator grille name plate	1	508941	
1949	All	on radiator grille ornament Lucite	1	512099	
1950	All	on radiator grille ornament Lucite	1	513703	
1951	All	on radiator grille spinner Lucite	1	514692	
1952	All	on radiator grille spinner Lucite	1	516466	
1953	All	on radiator grille center bar Lucite	1	514692	
1958	All	radiator grille	1	528599	
1950	All	NUT, radiator grille emblem plate to ornament- spring type	4	513704	
1951-52	All		4	514130	
1959	All (8,040)	radiator grille name plate (1/8")	3	572846	
1949	All	RETAINER, radiator grille emblem	1	512176	

Group 1.303 PLATE, RADIATOR GRILLE NAME

1946	All	on radiator grille	1	508940	
1948	All	on radiator grille	1	510524	
1951	All	on upper center bar	1	515771	
1952	All	on upper center bar	1	516482	

1959	21-24 All	Pontiac	1	532840
1959	27-28 All	Bonneville	1	532839
1960	27-28 All	Bonneville	1	535443
1952	All	NUT, name plate to center bar-spring type	2	516934
1951	All (8,039)	WASHER, radiator grille name plate	4	511948

Group 1.303 ORNAMENT, RADIATOR GRILLE

1949	All	less lucite emblem plate	1	512164
1950	All	less lucite emblem plate	1	513698
1951-52	All	SPINNER, radiator grille-less lucite emblem	1	514634
1949	All	BRACE, rad. grille ornament to fender support	1	512149
1950	All		1	513739
1951-52	All	BRACKET, rad. grille spinner to rad. supt. brace	1	514793
1951-52	All	SPACER, rad. grille spinner retainer	2	514447

Group 1.426 PAN, OIL

1935-52	P/8	use 1-504093 oil level rod on 1935 thru 39	1	511310
1939-54	P/6		1	515093
1953-54	P/8		1	515096
1955-58	All		1	518006
1959-60	All		1	536368
1955-58	All (8,900)	BOLT, oil pan to block (Hex. 5/16"-18x3/4")	AR	180077
1959-60	All	oil pan to block (5/16"-18x1/2" w/face)	14	504256

Group 1.429 GASKET SET, OIL PAN

1933-54	P/8		1	517100
1935-54	P/6		1	517099
1955-58	All		1	519978
1959-60	All		1	533409

Group 1.430 BAFFLE, ENGINE OIL

1955-58	All		1	518005
1959	All	use w/532014 pan	1	532219
1959	All	use w/536368 pan	1	536367
1960	All		1	536367

Group 1.453 SCREW, OIL PAN DRAIN

1935-60	All	less gasket	1	529752
---------	-----	-------------	---	--------

Group 1.456 GASKET, OIL PAN DRAIN SCREW

1935-60	All		1	513975
---------	-----	--	---	--------

Group 1.516 ROD-TUBE, OIL LEVEL INDICATOR

1935-52	All exc. P/8 1940-48	ROD	1	497109
1940-48	P/8		1	504093
1953-54	All		1	515091
1955-56	All		1	518118
1957	All A.C. exc. F.I.		1	524804
1957	All F.I. exc. A.C.		1	524804
1957-58	All exc. A.C.		1	523706
1958	All A.C.	also use with spec. eqpt. 45 amp. low cut-in D.C. gen.	1	530333
1959-60	All exc. A.C.		1	532779
1959-60	All A.C.		1	533257
1959-60	All A.C.	w/6 cyl. comp. (▲)	1	541242
1953-54	All	TUBE, oil level indicator rod	1	514989
1955-56	All	Upper	1	518184
1955-56	All	Lower	1	518117
1955-58	All	lower tube to oil baffle	1	518269
1957-58	All		1	523707
1957	All A.C. exc. F.I.	Upper	1	524612
1957	All F.I. exc. A.C.	Upper	1	529691
1958	All A.C.	w/6 cyl. comp. Upper	1	543190
1958	All A.C.	also use with spec. eqpt. 45 amp. low cut-in D.C. gen. Upper	1	530371
1959-60	All exc. A.C.	Upper	1	518184
1959-60	All A.C.	Upper	1	533258
1959-60	All A.C.	w/6 cyl. comp. (▲)	1	541243
1959-60	All	Lower	1	518117
1959-60	All	cyl. block to baffle	1	532780
1958	All A.C.	CLAMP, upper tube-also use with spec. eqpt. 45 amp. low cut-in D.C. gen.	1	530332

▲NOTE: Use w/cars equipped w/541754 & 541755 compressor adapter pkg.

Group 1.565 DRAIN, CRANKSHAFT REAR BEARING OIL

1936-49	All exc. P/6 1939-49	pipe	1	501723
1936-49	All exc. P/6 1939-49	GASKET, rear bearing cap oil return pipe	1	498844

Group 1.609 BALL-GASKET-RETAINER-SPRING, OIL PRESSURE REGULATOR

1955-60	All	(8.899) BALL, oil pressure regulator (5/8" Dia.)	1	147495
1955-56	All	(8.955) GASKET, oil pressure regulator (3/4" I.D.)	1	113897
1936-54	All	SPRING, oil pressure regulator-use with 513603		
		Retainer prior to 1950	1	513604
1955-60	All		1	518268
1936-54	All	RETAINER, oil pressure regulator	1	513603
1955	All		1	518208
1956	All		1	522632
1957-60	All		1	523478

Group 1.639 GEAR-SHAFT, OIL PUMP DRIVE AND DRIVEN

1948-52	All	GEAR AND SHAFT ASSY., oil pump drive	1	511234
1953-54	All		1	517094
1955-60	All		1	534589
1929-52	All	GEAR, oil pump driven (▲)	1	525093

1953-54	All		1	517093
1955-59	All		1	518016
1955-60	All	SHAFT, oil pump drive	1	518022
1948-52	All	SHAFT, oil pump driven gear	1	511237
1953-54	All		1	517096
1955-56	All		1	518015
1957-60	All		1	523476

▲NOTE: Do not use 525093 on P/6 1940 between Engine No. 662596 and 663049, use Oil Pump Assembly.

Group 1.643 GEAR, DISTRIBUTOR AND OIL PUMP DRIVE

1948-54	All	(▲)	1	505078
1936-52	All	GEAR & SHAFT PKG., oil pump (with dist. gear)	1	510942
1953-54	All		1	517183

▲NOTE: See group 2.374 for 1955-60 usage.

Group 1.644 SPRING, DISTRIBUTOR DRIVE FLAT

1933-54	All	in gear	3	495016
1933-54	All	RING, distributor drive spring retainer	1	495061

Group 1.652 PUMP ASSEMBLY, OIL

1946-54	All		1	517091
1955-58	All		1	523473
1959-60	All		1	536424
1955-58	All	(0.862) BOLT, oil pump to block (Hex. 3/8"-16x1-1/16")	2	500177
1960	All	(8.900) oil pump to block (Hex. 3/8"-16 x 1-1/2")	2	454906

Group 1.653 BODY, OIL PUMP

1953-54	All		1	517092
1955-56	All		1	518013
1957-58	All		1	523474
1959-60	All		1	532003

Group 1.655 GASKET, OIL PUMP TO BLOCK

1933-54	All		1	495009
1955-58	All		1	522103
1959-60	All		1	532001

Group 1.656 SCREEN, OIL CLEANER

1942-54	All		1	507243
1955-60	All		1	516085

Group 1.657 CLEANER ASSEMBLY, ENGINE OIL

1941-54	P/6		1	508343
1941-54	P/8		1	508344

Group 1.657 COVER-CUP-GASKET-RETAINER, OIL CLEANER

1942-54	P/6	COVER, oil cleaner screen-includes oil line	1	508345
1942-54	P/8	includes oil line	1	508346
1942-54	All	CUP, oil cleaner	1	507237
1942-54	All	GASKET, oil cleaner cup	1	507438

Group 1.723 COVER, OIL PUMP BODY

1933-47	All		1	495021
1948-54	All		1	511233
1955-56	All		1	518021
1957-60	All		1	523477

Group 1.724 GASKET, OIL PUMP COVER

1933-54	All		1	495020
---------	-----	--	---	--------

Group 1.745 INLET ASSEMBLY, OIL FILLER AND VENTILATOR

1940-51	P/6	except police car generator	1	506731
1940-51	P/8		1	506731
1941-51	P/6	for police car generator	1	506297
1952-54	All		1	506731
1957	All F.I.	EXTENSION, oil filler tube	529192 RH	
1957	All 3/2 B.C.		524596 RH	
1958	All		524596 RH	
1958	All Circulaire A.C.	with generator cooler	531814 RH	

Group 1.750 CLAMP, ENGINE OIL FILLER TUBE

1957	All 3/2 B.C.-F.I.		1	524595
1958	All		1	524595

Group 1.758 CAP, CRANKCASE BREATHER AND OIL FILLER

1940-54	All	with heavy duty air cleaner	1	1529885
1941-54	All	with std. air cleaner	1	1529884
1955-57	All	with std. air cleaner	2	1552232
1955-57	All exc. F.I. & 3/2 B.C.	with heavy duty air cleaner	2	1551897
1957-58	All 3/2 B.C.-F.I.		2	1553179
1958	All exc. A.S.	with std. air cleaner	1	1552233
1958	All	with heavy duty air cleaner	2	1553179
1959-60	All	with std. air cleaner	2	1552232
1959-60	All	with heavy duty air cleaner	2	1554521

Group 1.762 PIPE-CLEANER, CRANKCASE VENTILATOR OUTLET

1940-54	All	PIPE, crankcase outlet with std. air cleaner	1	504081
1941-54	All	with heavy duty air cleaner	1	506160
1955	All	with heavy duty air cleaner	1	518277
1955-57	All	with std. air cleaner	1	521816

1956-57	All 2 B.C.-4 B.C.	with heavy duty air cleaner	1	521850
1957	All 3/2 B.C.	Lower	1	528784
1957-58	All 3/2 B.C.	Upper	1	528783
1957	All F.I.		1	524858
1958	All	with std. air cleaner	1	529565
1958	All	with heavy duty air cleaner	1	529566
1958	All 3/2 B.C.	Lower	1	529801
1958	All F.I.		1	531466
1959-60	All	crankcase outlet-with std. air cleaner	1	533546
1959-60	All	with heavy duty air cleaner	1	533547
1941-54	All	CLEANER, crankcase outlet air-w/heavy duty air cleaner	1	1529886
1955-60	All	with heavy duty air cleaner	1	1551896
1957-60	All	HOSE, pos. crankcase vent. (29" long)	AR	535450
1957-58	All 3/2 B.C.	KIT, pos. crankcase vent. (type CV-54)	1	5646698
1957-60	All 4 B.C.	(type CV-13)	1	5646088
1957-60	All 2 B.C.	(type CV-12) exc. 1959 w/T420E	1	5646087
1959	All T420E	(type CV-38)	1	5646515
1959-60	All 3/2 B.C.	(type CV-33)	1	5646237

Group 1.763 BRACKET, CRANKCASE VENT. OUTLET PIPE

1955	All	Upper	1	519203
1955-57	All		1	518284
1956	All 2 B.C.-4 B.C. exc. C.C.- H.T.	Upper	1	521846
1956	All H.T. w/oil cooler	Upper	1	521350
1956	All 2/4 B.C.		1	522850
1957-58	All exc. 3/2 B.C.	Upper	1	521846
1957-58	All 3/2 B.C.	Upper	1	528785
1958-60	All	Lower	1	529564
1959-60	All	Upper	1	533545
1957-60	All	PACKAGE, pos. crankcase vent. bracket. (type CV-296)	1	5646419

Group 1.764 SPACER-VALVE, POSITIVE CRANKCASE VENT.

1957-58	All 3/2 B.C.	SPACER PKG., pos. crankcase vent.- carb. (type CV-405)	1	5646804
1957-60	All 2 B.C.	(type CV-297)	1	5646420
1957-60	All 3/2 B.C.	(type CV-332) Center	1	5646482
1957-60	All 4 B.C.	(type CV-293)	1	5646416
1959	All T420E	(type CV-332)	1	5646482
1959-60	All 3/2 B.C.	(type CV-331)	2	5646481
1957-60	All	VALVE PKG., pos. crankcase vent. outlet (type CV-273)	1	5646286

Group 1.773 RING-SEAL, VENTILATOR OUTLET PIPE

1956-58	All 2/4 B.C.-3/2 B.C.	RING, vent pipe seal retaining	1	520587
1955	All	SEAL, vent outlet	1	518109
1956-58	All L.H.D. exc. 3/2 B.C.		1	522232
1957-58	All 3/2 B.C.		1	518109
1959-60	All		1	522232
1940-54	All L.H.D.	CLIP, vent outlet pipe to pan	1	504082
1955-60	All (8.948)	CLAMP, ventilator outlet pipe (1-3/8")	1	111612
1957-60	All	GROMMET PKG., pos. crankcase vent. outlet (type CV-295)	1	5646418

Group 1.780 BAFFLE, CRANKCASE VENTILATOR

1955-56	All	Lower	1	518107
1955-57	All	GASKET, crankcase vent baffle	1	518162
1955-56	All	SCREW, baffle to crankcase (5/32"x3/8" drive)	2	521067

Group 1.800 SWITCH ASSEMBLY, ENGINE OIL PRESSURE

1959-60	All		1	534598
---------	-----	--	---	--------

Group 1.803 GAUGE, OIL PRESSURE

1949-50	All		1	1507350
1951-52	All		1	1507535
1953-54	All		1	1507707
1955	All		1	1508195
1956	All		1	1508429
1957	All		1	1508548
1958	All		1	1508697
1959	All		1	1586498
1960	All		1	1587888
1954	All A.C.	(1.148) GAUGE ASSY., oil pressure and water temp.	1	1508227
1959	All	SLEEVE, oil pressure tell tale	1	1586324

Group 1.835 FILTER ASSY., OIL

1955-59	All	(A.C. type PM-9P-2)	1	5575890
1955-60	All	(A.C. type PM-502) w/disposable element	1	5575870

Group 1.836 ELEMENT PACKAGE, OIL FILTER

1955-59	All	(A.C. type PF-122)	1	5572128
1960	All	(A.C. type PF-5) disposable type	1	5575198

Group 1.837 OIL FILTER PARTS

1955-59	All	BALL, oil filter by-pass	1	5572147
1955	All	BOLT, oil filter to block (Hex. 3/8"-16x1-5/8")	3	180127
1956-59	All	(8.900) (Hex. 3/8"-16x1-1/2")	3	454906
1955-60	All without oil filter	COVER, oil filter pad	1	518166
1955-59	All	GASKET, oil filter center stud-copper	1	5572799
1955-59	All	oil filter center stud spring retainer-rubber	1	5572800
1959-60	All	(8.963) ELBOW, oil pressure switch to oil filter	1	9409931
1955-59	All	RETAINER, oil filter center stud spring	1	5572935
1955-59	All	oil filter by-pass spring	1	5573696
1955-59	All	RING, oil filter center stud ret.	1	5572936
1955-59	All	SHELL, oil filter	1	5573691
1955-59	All	SPRING, oil filter center stud	1	5572933
1955-59	All	oil filter by-pass	1	5573694
1955-59	All	STUD, oil filter Center	1	5572798
1955-59	All	WASHER, oil filter center stud-steel	1	5572934

Group 1.844 GASKET, OIL FILTER

1955-60	All without oil filter	oil filter pad cover	1	518167
1955-59	All	oil filter to block	1	519458
1955-58	All	oil filter base to shell	1	5572162
1960	All	oil filter to cylinder block	1	536841
		GASKET (see Group 1.837 for use)		5572800