

YEAR	MODEL	PART NAME	PART NO.	PER CAR	PART NO.
Group 3.001 TANK, FUEL					
1939	25 All			1	501944
1939-40	26-28 All			1	501945
1940	29 All			1	504095
1941-48	All exc. sta. wag.			1	505089
1941-48	Sta. wag.			1	506415
1949-52	All exc. 2561-62-71			1	514301
1949-52	2561-62-71 All			1	512217
1953-54	All exc. 2562-71			1	515310
1953-54	2562-71 All			1	515319
1955-56	All exc. 25/2762-63-64			1	521251
1955-57	25/2762DF-62SDF-63F			1	521936
1955-56	25/2764 All			1	521937
1956-57	2762FC			1	522401
1957	All exc. 2762-63-64			1	523696
1957	2764 DF			1	523140
1958	All exc. 2793-94			1	528682
1958	2793-94			1	528685
1959	All exc. 2135-45, 2735 & H.D.C.			1	533753
1959-60	2135-2735			1	533786
1959-60	2145, H.D.C. All			1	533769
1960	All exc. 2135-45, 2735 & H.D.C.			1	536114

Group 3.003 PIPE, FUEL TANK FILLER

1941-48	All exc. sta. wag.			1	505093
1949-52	All exc. 2561-62-71			1	511256
1949-52	2561-62-71 All			1	512222
1953-54	All exc. 2562-71			1	515315
1953-54	2562-71 All			1	515316
1955	All exc. 2562-63-64			1	519120
1955-57	25/2762-63 All			1	521019
1955-56	25/2764 All			1	521021
1956	All exc. 2762-63-64			1	521717
1957	2711-19-37-39 All			1	523157
1957	2764DF			1	523141
1957	2819-37-39-67 All			1	523159
1958	25/2731-39-41-47-49-67 All			1	529866
1958	2793-94			1	529867
1958	2831-39-49 & H.D.C. All			1	529940
1959	All exc. 2135-45, 2735 & H.D.C.			1	533300
1959	2135, 2735			1	533549
1959	2145, H.D.C. All			1	533773
1960	All exc. 2135-45, 2735 & H.D.C.	(15 3/8" dev. lgth.)		1	536111
1960	All exc. 2135-45, 2735 & H.D.C.	(16" dev. lgth.)		1	535561
1960	2135, 2735			1	536162
1960	2145, H.D.C.			1	536164
1958	2793-94 All	PIPE, fuel tank outer vent.		1	531384
1958	All exc. 2793-94	GUARD, fuel tank filler pipe splash-exc. dual exh.		1	531575
1949-52	2561-62-71 All	HOSE, fuel tank filler pipe		1	512248
1953-54	2562-71 All			1	516713

Group 3.004 CLAMP, FUEL TANK FILLER PIPE HOSE

1949-54	2561-62-71 All	2	432737
1957-58	All exc. 2762-63-64 . . (1.166)	1	1161694

Group 3.006 PLUG, FUEL TANK DRAIN

1937-52	All	(Hex. head 1/8")	1	508220
1953-59	All	(1.453) less gasket	1	529752
1953-59	All	(1.456) GASKET, drain plug	1	513975

Group 3.008 GROMMET-SEAL, FUEL TANK FILLER PIPE

1949-52	2561-62-71 All	GROMMET, through fender	1	3688073
1949-52	2561-62-71 All	through body	1	512433
1957	All exc. 2762-63-64	SEAL, fuel tank filler pipe	1	3710537
1958-60	All		1	3710537

Group 3.010 BRACKET, FUEL TANK FILLER PIPE SUPPORT

1949-54	2561-62-71 All	1	512225
1955-57	25/2762-63-64 All	1	519125

Group 3.022 STRAP, FUEL TANK

1941-48	All exc. sta. wag.	Lower	2	505338
1949-52	All exc. 2561-62-71		2	513600
1949-52	2561-62-71 All		1	513287
1953-54	All 2511-37-67-69		2	515327
1953-55	2562-63-64-71 All		2	515329
1954	28 All		2	517559
1955-57	All exc. 25/2762-63-64		2	519128
1956-57	2762 FC	Front	1	522407
1956-57	2762 FC	Rear	1	522409
1956-57	2762 DF-63F-64DF		2	515329
1958	All exc. 2793-94	with shim	2	528691
1958-60	2135, 2735-93-94 All		AR	528694
1959-60	All exc. 2135-45, 2735		2	532785
1959-60	2145		2	533903
1960	2135, 2735		2	535360
1941-54	Sta. wag. & 2571	BRACKET, fuel tank strap	2	506472
1955	2562-63-64 All		2	519127
1956-57	2762 FC	Front	1	522406
1956-57	2762DF-63F-64DF		2	519127
1958-59	2135, 2735-93-94 All		2	529439
1959-60	All exc. 2135-45, 2735 & H.D.C.	INSULATOR, fuel tank strap	2	533057

Group 3.023 BOLT, FUEL TANK LOWER STRAP END

1936-48	All			2	517883
1949-53	2561-62-71 All			1	517883
1949-53	All exc. 2561-62-71	support hook		1	556014
1954	All exc. 2562	support hook		2	517884
1954-57	25/2762-63-64-93-94 All	strap end		2	517883
1958-60	2135, 2735-93-94 All	strap bracket		2	535359

Group 3.028 CAP, FUEL TANK FILLER

1940-60	All exc. 1940 25-26	1	534509
---------	---------------------	---	--------

Group 3.107 GAUGE, FUEL (TANK UNIT)

1939-40	All	1	1515481
1941-48	All exc. sta. wag.	1	1516316
1941-50	Sta. wag. & 2571 All	1	1517122
1949-50	All exc. 2561-62-71	1	1517249
1951-55	All exc. 2562-63-64-71	1	1518093
1951-55	2562-63-64-71 All	1	1518250
1956	2762 FC less filter	1	1518813
1956	2762DF-63F-64DF less filter	1	1518812
1956-57	All exc. 2762-63-64 less filter-w/5/16" fuel line	1	1518394
1957	2762FC less filter-w/5/16" fuel line	1	1518813
1957	2762DF-63F-64DF less filter-w/5/16" fuel line	1	1518812
1957	All exc. 2762-63-64 w/filter-w/3/8" fuel line	1	1518885
1957	2762FC w/filter-w/3/8" fuel line	1	1518887
1957	2762DF-63F-64DF w/filter-w/3/8" fuel line	1	1518886
1958	All exc. 2793-94-A.C. & F.I.	1	5640191
1958	All A.C. exc. 2793-94 & F.I.	1	5640192
1958	2793-94 All A.C. exc. F.I.	1	5640210
1958	2793-94 All exc. A.C.	1	5640209
1958	2793-94 All F.I.-A.C.	1	5640209
1959-60	All exc. 2135-45, 2735, Circulaire A.C. & H.D.C.	1	5640329
1959-60	All Circulaire A.C. exc. 2135-45, 2735	1	5640330
1959-60	2135, 2735 All Circulaire A.C.	1	5640210
1959-60	2135, 2735 All exc. Circulaire A.C.	1	5640209
1959-60	2145 All exc. Circulaire A.C.	1	5640357
1959-60	2145 All Circulaire A.C.	1	5640358
1956-57	All SPRING, gauge positioning-w/gauge less filter	1	523083
1951-54	All exc. 2562 SCREW AND WASHER, fuel gauge to tank (Spec. No. 10-24x7/16")	5	569147
1955-60	All (Spec. No. 10-24x7/16")	5	569147

Group 3.108 GAUGE, INSTRUMENT PANEL (FUEL)

1947	All	1	1516946
1949-50	All	1	1517117
1951-52	All	1	1517378
1953-54	All	1	1517603
1955	All	1	1518131
1956	All	1	1518504
1957	All L.H.D.	1	1518594
1958	All	1	1518952
1959	All	1	5640287
1960	All exc. safeguard speedometer	1	5643163
1960	All w/safeguard speedometer	1	5643582
1960	All CAP AND SLEEVE ASSY., fuel tell tale-w/safeguard speedometer	1	1588498

Group 3.110 FILTER ASSY., FUEL TANK OUTLET

1956	All		1	854332
1957-60	All	w/3/8" fuel line	1	854409

Group 3.112 GASKET, FUEL GAUGE (TANK UNIT)

1935-60	All	outlet fitting	1	1516395
---------	-----	----------------	---	---------

Group 3.158 CLAMP, FUEL LINE

1958	2793-94 All	(1.166) CLAMP, fuel tank vent hose	(9/16")	3	274461
1958-60	All	(1.166) fuel tank fuel pipe hose	(9/16")	AR	274461

Group 3.162 BRACKET-CLIP, FUEL LINE

1956	All 2/4 B.C.	BRACKET, fuel pump to filter pipe	1	523035
1957	All 4 B.C.-3/2 B.C.	w/3/8" fuel line	1	528197
1959	All A.C.-2 B.C. exc. A.S.		1	533762
1959	All exc. 2 B.C. & A.S.		1	534385
1960	All exc. A.C.	fuel filter to carb. pipe	1	536586
1960	All A.C.-P.S.	fuel filter to carb. pipe (▲)	1	536586
1960	All A.C. exc. P.S.	fuel filter to vapor separator pipe	1	536627
1939-57	All exc. 1939 25	CLIP, fuel line to frame, bolt on type (5/16")	1	502896
1957-59	All	bolt on type (3/8")	1	528290
1958	All	snap on type	1	530601
1958	2793-94 All	vent pipe to frame	2	531467
1958-60	All A.C.	vapor return pipe to fuel pipe	AR	531433
1960	All P.S.	fuel filter to carb. pipe (▲▲)	1	536359

▲NOTE: Used w/1st type steel oil pump mtg. bracket.

▲▲NOTE: Used w/2nd type cast iron oil pump mtg. bracket.

Group 3.163 HOSE-TUBING-FITTING-AIR DOME, FUEL LINE

1958-60	All A.C. exc. F.I.	AIR DOME ASSY., fuel tank to fuel pump line	1	1523319
1958	All A.C. exc. F.I. . . . (8.963)	BUSHING, air dome to tee pipe reducer . (1/4"x1/8")	1	141539
1959-60	All Circulaire A.C.	FITTING, fuel hose and airdrome to fuel pump	1	532904
1958-59	All exc. Circulaire A.C. . . .	fuel pump to fuel hose Inlet	1	530664
1958-60	All 3/2 B.C.	fuel filter to carb.-four way	1	530508
1959	All 4 B.C.-3/2 B.C.	fuel pump to fuel hose Outlet	1	530664
1960	All exc. Circulaire A.C.	to fuel hose Inlet	1	530664
1960	All	to fuel hose Outlet	1	530664
1935-36,				
1939-50	All	HOSE, fuel line to pump with		
		compression nut (10-13/16" long)	1	503485
1951-54	All	 (10-13/16" long)	1	514607
1955-56	All	 (7" long)	1	519575
1957	All exc. A.C.	 (7" long)	1	519575
1957	All	w/3/8" fuel line	1	528415
1958-59	All	fuel tank vent. (19" long)	1	531419
1958-60	All	fuel tank to rear pipe	1	531419
1958-60	All	frt. pipe to rear pipe	1	531419
1958	All A.C. exc. F.I.	front fuel pipe to fuel pump	1	531645
1959-60	All	fuel pipe to fuel pump Front	1	531419
1933-58	All (8.964)	PIPE, fuel tank to hose, cut copper tubing to required		
		length (5/16")	AR	348750

1957-58	All (8.964)	cut to required length (3/8")	AR	3847597
1960	All (8.964)	fuel tank to pump-cut to required length (3/8")	AR	3847597
1958	All A.C. exc. F.I. . . . (8.963)	TEE, fuel hose and air dome to fuel pump	1	444254

Group 3.201 PIPE, FUEL PUMP TO CARBURETOR

1935-58	All (8.964)	cut copper tubing to required length (5/16")	AR	348750
1955	P/8 A.C.-2 B.C.		1	521094
1935-48	All	ELBOW, threaded sleeve, carburetor inlet (5/16"x90°)	1	504500
1953-54	P/6	carburetor inlet (5/16"x90°)	1	504500
1956-57	All 2/4 B.C.-3/2 B.C.	front carb. to rear carb. (5/16"x90°)	1	504500
1958	All F.I.	HOSE, fuel filter to fuel meter assy.	1	530831
1959-60	All (3.158)	fuel pump to fuel filter and carb.	2	531419
1957	All 3/2 B.C.	TEE, front carb. to center carb. pipe . (3/8" to 5/16")	1	528199
1957	All 3/2 B.C.	fuel filter front carb. (3/8")	1	528727
		ELBOW (see Group 3.890 for use)		573646

Group 3.264 TUBE, INTAKE MANIFOLD RISER

1940	P/8	with single carburetor (2-13/16"x1.690)	1	503603
1946-52	P/6	 (2-7/8"x1.690)	1	508526

Group 3.265 MANIFOLD, INTAKE

1940-54	P/8 exc. 1940 28		1	518878
1953-54	P/6		1	517316
1955	All 2 B.C.		1	520733
1955	All 4 B.C.		1	520735
1956	All 2 B.C.		1	522515
1956	All 4 B.C.		1	522516
1956	All 2/4 B.C.		1	523550
1957	All 2 B.C.		1	523811
1957	All 4 B.C.		1	523824
1957	All 3/2 B.C.		1	528786
1957	All F.I.		1	7014374
1958	All 2 B.C.		1	529580
1958	All 4 B.C.		1	529581
1958	All 3/2 B.C.		1	529528
1958	All F.I.		1	7014861
1959	All 2 B.C. exc. T420E		1	532117
1959-60	All 4 B.C.		1	536516
1959	All 3/2 B.C.		1	534959
1959	All T420E		1	534317
1960	All 2 B.C.		1	536515
1960	All 3/2 B.C.		1	536193

Group 3.270 GASKET SET, INTAKE AND EXHAUST MANIFOLD

1933-54	P/8		1	503434
1935-54	P/6		1	503433

1934-39	All exc. P/6 1939	GASKET, intake to exhaust	1	496215
1939-54	P/6	intake to exhaust	1	502288
1940	28 All	intake to exhaust	1	508248
1940-54	P/8 exc. 1940-28	intake to exhaust	1	504610
1955	All	intake manifold to cyl. head	2	519416
1955-56	All	exhaust manifold to cyl. head	2	518203
1956	All	intake manifold to cyl. head	2	521567
1957-58	All exc. F.I.	intake manifold to cyl. head	2	534501
1957	All	exhaust manifold to cyl. head	2	523536
1957-58	All F.I.	insulator to cyl. head	2	524891
1957-58	All F.I.	insulator to lower housing	2	524892
1957-58	ALL F.I.	intake manifold to lower housing	2	7014432
1958	All	exhaust manifold to cyl. head	2	529048
1959-60	All	intake manifold to cyl. head	2	534501
1959-60	All	exhaust manifold to cyl. head	2	532020
1957-58	All F.I.	INSULATOR, housing to cyl. head	2	524894

Group 3.273 CLAMP, MANIFOLD

1957	All F.I.	manifold to cyl. head	4	524938
1958	All F.I.		4	530554

Group 3.275 STUD-GROMMET-LOCK, MANIFOLD

1955-60	All exc. F.I.	STUD, manifold to carb. (5/16"x1-3/8")	AR	518101
1933-54	All	manifold to block (3/8"x1-13/16")	10	494520
1955-60	All exc. F.I.	intake manifold to cyl. head (3/8"x2")	4	520619
1957-58	All F.I.	manifold to cyl. head (3/8"x1-13/16")	4	528330
1957-60	All (8.981)	manifold to carb. (5/16"x1-5/8")	AR	191991
1957-58	All F.I.	GROMMET, lower housing clamp	4	524893
1933-54	All	WASHER, small (13/32" I.D.x3/4" O.D.)	2	502306
1933-60	All	large (13/32" I.D.x1" O.D.)	8	501215
1955-56	All	LOCK, exhaust manifold bolt	4	520731
1957-60	All		8	523540

Group 3.278 ELBOW-CONNECTOR-FITTING-NUT-PLUG-TEE, INTAKE MANIFOLD

1934-58	All (8.963)	CONNECTOR, carb. to dist.-carb. end (3/16")	AR	152120
1957-58	All 3/2 B.C.	ELBOW, vacuum pipe to front carb. (3/8"x90°)	1	528721
1957-58	All 3/2 B.C.	vacuum pipe to center carb. (1/4"x90°)	1	528722
1958	All H.T.-3/2 B.C.	vacuum pipe to center carb.-three openings	1	531325
1959	All 3/2 B.C.	vacuum pipe to front carb.	1	533225
1954	All P.B. & A.C.	FITTING, vacuum pump to manifold pipe-four openings	1	518747
1955-58	All P.B. exc. F.I. & 3/2 B.C. (4.930)	vac. pipes to carb.-three openings (1-29/32" long)	1	520012
1958	All H.T.-4 B.C.	vac. pipes connector-four openings (2-11/16" long)	1	531326
1959	All 2 B.C.-4 B.C. exc. P.B.-T420E	vacuum pipe to carb.-three openings (1-17/32" long)	1	533689
1959-60	All 2-B.C.-4 B.C.-P.B.	vacuum pipe to carb.-four openings (1-11/16" long)	1	533690
1959-60	All 3/2 B.C.	vacuum pipe to center carb.-three openings (1-17/32" long)	1	533689
1959-60	All	vacuum pipe hose to distributor (1-1/16" long)	1	533688
1960	All 2 B.C.-4 B.C.-P.B.	vacuum pipe to carb.	1	535247
1960	All H.T.-4 B.C.	carb. to diaphragm vacuum	1	533688
1934-60	All (8.963)	NUT, carb. to dist. line (3/16")	2	114962
1955-57	All (8.963)	vac. pump pipe to carb. (1/4")	1	114963
1955-56	All (8.971)	PLUG, manifold thermogauge hole (1/2" pipe thd.)	1	444788
1959-60	All	carb. fitting-exc. heater (5/16"-24 slotted hd.)	1	533698
1954	All A.C.	TEE, vac. pump to manifold pipe	1	120124

Group 3.288 BOLT, MANIFOLD

1955-56	All	(8,900)	BOLT, exhaust manifold to cyl. head (Hex. 3/8"-16x2-1/4")	2	180132 LH
1955-58	All	(8,900)	exhaust manifold to cyl. head . . . (Hex. 3/8"-16x1")	AR	180122
1955-56	All	(8,900)	intake manifold to cyl. head . . . (Hex. 3/8"-16x1")	3	180122
1955-60	All H.T.	(8,900)	intake manifold to cyl. head . . (Hex. 3/8"-16x1-1/8")	1	180123
1955-60	All		intake manifold to cyl. head . . (Hex. 3/8"-16x1-1/2")	AR	522871
1957-60	All	(8,900)	exhaust manifold to cyl. head (Hex. 3/8"-16x2-1/2")	AR	180134
1957-60	All	(8,900)	exhaust manifold to cyl. head . . (Hex. 3/8"-16x2")	AR	427559
1957-58	All F.I.		manifold to cyl. head . . . (Hex. 3/8"-16x1-3/4")	4	524904
1959-60	All exc. 3/2 B.C.		intake manifold to cyl. head . . (Hex. 3/8"-16x2")	1	533713

Group 3.304 GASKET KIT, AIR METER AND FUEL METER

1957	All F.I.		air meter	1	7014825
1957-58	All F.I.		fuel meter	1	7014486

Group 3.308 PUMP AND GASKET ASSY., FUEL METER GEAR

1957	All F.I.			1	7014815
1958	All F.I.			1	7017069
1957-58	All F.I.		GASKET, fuel meter gear pump	1	7014104
1957	All F.I.	(8,907)	BOLT, fuel meter gear pump . . . (No. 10-32x1/2")	1	120216
1957-59	All F.I.			4	7014280

Group 3.310 METER AND NOZZLES ASSY., FUEL

1957	All F.I.			1	7014811
1958	All F.I.			1	7017068

Group 3.312 BODY-SPACER-NUT, FUEL METER

1957	All F.I.		BODY ASSY., fuel meter	1	7014813
1958	All F.I.			1	7017067
1957	All F.I.		SPACER, fuel meter mounting bracket	2	7014297
1957	All F.I.	(8,915)	NUT, fuel meter mounting (No. 8-32)	2	120622

Group 3.314 SOLENOID-SWITCH-LEAD-BRACKET, AIR METER AND FUEL METER

1957	All F.I.		SOLENOID ASSY., fuel meter	1	7014516
1957-58	All F.I.		fuel meter by-pass line	1	7014762
1957-58	All F.I.		SWITCH, air meter solenoid cut off	1	7014228
1957-58	All F.I.		SHIELD, air meter solenoid switch	1	7014534
1957	All F.I.		SPACER, fuel meter solenoid bracket	2	7014761
1957	All F.I.		LEAD ASSY., solenoid switch	1	7014535
1958	All F.I.			1	7017010
1957-58	All F.I.		BRACKET, air meter solenoid switch mounting	1	7014229
1957	All F.I.		fuel meter solenoid mounting	1	7014763
1958	All F.I.		fuel meter solenoid mounting	1	7014976

1957-58	All F.I.	BOLT, air meter solenoid switch attaching (No. 4-48x5/8")	2	7014480
1957-58	All F.I.	air meter solenoid switch bracket (No. 10-32x3/8")	2	7014349
1957	All F.I.	fuel meter solenoid (No. 8-32x5/16")	2	131958
1957-58	All F.I.	fuel meter solenoid bracket (No. 10-32x3/8")	2	7014349

Group 3.316 ROD-SHAFT AND LEVER, FUEL METER SOLENOID

1957	All F.I.	ROD, fuel meter solenoid	1	7014163
1957	All F.I.	SHAFT AND LEVER ASSY., fuel meter solenoid	1	7014148
1957	All F.I.	LEVER, fuel meter solenoid-internal	1	7014162
1957	All F.I.	NUT, fuel meter solenoid lever shaft	1	7014551
1957	All F.I.	WASHER, fuel meter solenoid lever	1	7014281

Group 3.318 DIAPHRAGM-COVER-GASKET-GROMMET, FUEL METER CONTROL

1957-58	All F.I.	DIAPHRAGM, fuel meter control	1	7014193
1957	All F.I.	COVER, fuel meter control diaphragm	1	7014152
1958	All F.I.	DIAPHRAGM, fuel meter control diaphragm	1	7014781
1957-58	All F.I.	GASKET, fuel meter diaphragm anchor	1	7014715
1957-58	All F.I.	fuel meter control diaphragm cover	1	7017084
1957-58	All F.I.	GROMMET, fuel meter control diaphragm link	1	7014268
1957-58	All F.I.	NUT, fuel meter control diaphragm (Spec. No. 5-44)	1	7014191
1957-58	All F.I.	WASHER, fuel meter control diaphragm	1	7014168

Group 3.320 DIAPHRAGM-COVER-LEVER-ROD-SPRING, FUEL METER ENRICHMENT

1957-58	All F.I.	DIAPHRAGM, fuel meter enrichment	1	7017083
1957-58	All F.I.	COVER, fuel meter enrichment diaphragm	1	7014780
1958	All F.I.	DIAPHRAGM, fuel meter enrichment diaphragm	1	7014780
1957-58	All F.I.	LEVER AND SHAFT ASSY., fuel meter diaphragm	1	7014167
1957-58	All F.I.	LEVER, fuel meter ratio	1	7014617
1957-58	All F.I.	NUT, fuel meter enrichment rod (No. 10-24)	1	445483
1957-58	All F.I.	fuel meter mixture stop set screw (No. 10-32)	2	120614
1957-58	All F.I.	ROD, fuel meter enrichment control	1	7014131
1957-58	All F.I.	SPRING, fuel meter enrichment diaphragm	1	7014773
1958	All F.I.	SUPPORT, fuel meter enrichment diaphragm	1	7014896
1957	All F.I.	BOLT, fuel meter diaphragm cover (No. 8-32x1/2")	5	131970

Group 3.322 VALVE KIT-COVER-SCREEN-SPRING, FUEL METER FUEL VALVE

1957	All F.I.	VALVE KIT, fuel meter high pressure fuel	1	7014814
1957	All F.I.	COVER, fuel meter fuel valve	1	7014624
1958	All F.I.	fuel meter filter	1	7014893
1957	All F.I.	KIT, fuel meter fuel valve inlet filter	1	7017085
1958	All F.I.	pump outlet filter	1	7017085
1958	All F.I.	PLUNGER AND SLEEVE ASSY., fuel meter spill	1	7017081
1957	All F.I.	SPRING, fuel meter high pressure fuel valve retaining	1	7014141

1958	All F.I.	STOP, fuel meter spill plunger	1	7014892
1957-58	All F.I.	"O" RING, fuel meter fuel valve cover . (63/64" I.D.)	1	7014546
1958	All F.I.	fuel meter spill sleeve (7/16" I.D.)	1	7014889
1957	All F.I. (8.907)	BOLT, fuel meter valve cover (Fill. Hd. No. 10-32x1/2")	4	120216

Group 3.328 DIAPHRAGM-COVER-PLATE-SPRING-VALVE, FUEL METER COASTING SHUTOFF

1957	All F.I.	DIAPHRAGM, fuel meter coasting shutoff	1	7014125
1957	All F.I.	COVER ASSY., fuel meter coasting shutoff	1	7014530
1957	All F.I.	PLATE, fuel meter coasting shutoff diaphragm . Upper	1	7014197
1957	All F.I.	Lower	1	7014097
1957	All F.I.	SPRING, fuel meter coasting shutoff-primary . . Lower	1	7014311
1957	All F.I.	fuel meter coasting shutoff-secondary	1	7014106
1957	All F.I.	VALVE, fuel meter coasting shutoff	1	7014722
1957	All F.I.	SCREW, fuel meter coasting shutoff cover (No. 10-32x7/8")	1	7014698
1957	All F.I.	NUT, fuel meter coasting shutoff diaphragm (No. 10-32)	1	7014266

Group 3.330 FERRULE-HOSE-LINE-RESTRICTION-TEE-TUBE, FUEL METER FUEL LINE

1957-58	All F.I.	FERRULE, fuel meter nozzle line	AR	7014720
1957	All F.I.	FITTING, fuel line	1	7014478
1957-58	All F.I. (3.740)	fuel meter enrichment cover	1	7006854
1957-58	All F.I.	HOSE, coupling (3/16" dia.)	2	7014461
1957-58	All F.I.	1/4" dia.)	AR	7014012
1957	All F.I.	3/8" dia.)	1	7014459
1957	All F.I.	DISTRIBUTOR AND LINE KIT, fuel meter	1	7014819
1957	All F.I.	FUEL LINE KIT, starting by-pass	1	7014824
1958	All F.I.		1	7017071
1958	All F.I.	LINE AND FITTING ASSY., distributor	2	7014982
1958	All F.I.	LINE KIT, fuel meter nozzle	8	7014485
1957	All F.I.	RESTRICTION, signal modifier	1	7014646
1957	All F.I.	RESTRICTION AND TEE ASSY., fuel control . . (.017)	1	7014807
1957	All F.I.	 (.018)	1	7014808
1957	All F.I.	 (.019)	1	7014809
1957	All F.I.		1	7014948
1957	All F.I.	RETAINER, fuel line fitting spring	1	7014479
1957	All F.I.	TEE ASSY., venturi signal	1	7014642
1958	All F.I.	fuel meter signal line	1	7017031
1958	All F.I.	"O" RING, fuel meter distributor line . . (1/8" I.D.)	2	7014985
1957	All F.I.	TUBE ASSY., coasting shutoff	1	7014471
1957	All F.I.	enrichment	1	7014467
1957	All F.I.	fuel inlet	1	7014464
1957	All F.I.	idle signal	1	7014469
1957	All F.I.	signal modifier	1	7014641
1957	All F.I.	spark vacuum	1	7014463
1958	All F.I.	enrichment	1	7017001
1958	All F.I.	fuel filter to fuel meter	1	530832
1958	All F.I.	fuel inlet	1	7014980
1958	All F.I.	idle signal	1	7014992
1958	All F.I.	spark vacuum	1	7014996
1957	All F.I. (9.786)	CLAMP, air inlet hose to air cleaner	2	513479
1957-58	All F.I. (8.963)	CONNECTOR, starting by-pass line	2	140284
1957-58	All F.I.	GROMMET, lower housing (3 hole)	1	7014717
1958	All F.I.	lower housing fuel line . . (9/16" I.D.x1-1/16 O.D.)	1	530929

1958	All F.I.	lower housing vacuum pipe . (1/4" I.D.x5/8" O.D.)	1	530930
1958	All F.I.	vacuum pipe to lower housing (3/8" I.D.x1-1/16" O.D.)	1	530577
1958	All F.I.	air meter spark vacuum tube (3/16" I.D.x9/16" O.D.)	1	7017000
1957	All F.I.	NUT, fuel meter distributor line	2	7014269
1957-58	All F.I.	nozzle line	AR	7014108

Group 3.332 NOZZLE AND LINE-BLOCK-GASKET-RETAINER-SLEEVE, FUEL METER

1957	All F.I.	NOZZLE AND LINE ASSY., fuel meter-		
		code Q-9 (see note 1)	8	7014820
1957	All F.I.	code P-10 (see note 2)	8	7014821
1957	All F.I.	code Q-11 (see note 3)	8	7014822
1957	All F.I.	code R-12 (see note 4)	8	7014823
1958	All F.I.	code Q-12 (see note 5)	8	7014856
1958	All F.I.	code R-13 (see note 6)	8	7014857
1958	All F.I.	code S-14 (see note 7)	8	7014858
1957	All F.I.	BLOCK, fuel meter nozzle	4	7014389
1957-58	All F.I.	GASKET, fuel meter nozzle	8	7014787
1957	All F.I.	fuel meter nozzle block	4	7014397
1958	All F.I.	fuel meter nozzle holder	8	7014883
1958	All F.I.	HOLDER ASSY., fuel meter nozzle	8	7014872
1957	All F.I.	RETAINER, fuel meter nozzle	4	7014523
1958	All F.I.		4	7014871
1957	All F.I.	SLEEVE, fuel meter nozzle	8	7014114
1957	All F.I.	"O" RING, fuel meter nozzle sleeve	8	7014093
1957	All F.I.	(8.907) SCREW, nozzle retainer to holder . . (No. 6-32x1/4")	4	131880
1958	All F.I.		4	7010433

NOTE 1: For replacing nozzle and line assy. code N-8-N-9-Q-8-Q-9.

NOTE 2: For replacing nozzle and line assy. code Q-10-P-9-P-10.

NOTE 3: For replacing nozzle and line assy. code P-11-Q-10-Q-11.

NOTE 4: For replacing nozzle and line assy. code Q-12-R-10-R-11-R-12.

NOTE 5: For replacing nozzle and line assy. code Q-11-Q-12.

NOTE 6: For replacing nozzle and line assy. code R-12-R-13.

NOTE 7: For replacing nozzle and line assy. code S-13-S-14.

Group 3.335 BODY-CONE-GASKET-RING-SPACER-VALVE, AIR METER

1957	All F.I.	BODY ASSY., air meter	1	7014712
1958	All F.I.		1	7017009
1957	All F.I.	CONE, air meter venturi	1	7014007
1958	All F.I.		1	7014653
1957	All F.I.	GASKET, air meter bleed valve	1	7014622
1957-58	All F.I.	air meter venturi ring	1	7014053
1957-58	All F.I.	air meter to intake manifold	1	7014016
1958	All F.I.	air meter thermostatic valve	1	7014622
1957-58	All F.I.	RING, air meter venturi	1	7014474
1957-58	All F.I.	SPACER, air meter venturi cone	4	7014338
1957	All F.I.	VALVE ASSY., air meter thermostatic air bleed	1	7014618
1958	All F.I.		1	7014999
1957-58	All F.I.	SCREW, air meter bleed valve . . (No. 6-40x5/16")	2	7014645
1957-58	All F.I.	air meter venturi cone (No. 10-32 x 2")	AR	7014070

Group 3.340 DRIVE-CABLE-SEAL, FUEL METER PUMP

1957-58	All F.I.	DRIVE ASSY., fuel meter and distributor	1	1938797
1957-58	All F.I.	CABLE ASSY., pump drive	1	1585264
1957-58	All F.I.	SEAL, fuel meter pump drive	1	7014416

Group 3.402 CLEANER AND SILENCER, CARBURETOR AIR

1940	P/8	standard, 1940 28 with dual carburetor, 1941 thru 48 with die cast carburetor	1	1544256
1941-50	P/6	standard	1	1529871
1941-54	P/8	standard	1	1544256
1949-50	P/6	heavy duty	1	1544486
1949-50	P/8	heavy duty	1	1544530
1951-52	P/6	standard	1	1544966
1951-52	P/6	heavy duty	1	1544967
1951-54	P/8	heavy duty	1	1551930
1953-54	P/6	heavy duty	1	1551931
1955	All	standard	1	1551977
1955	All exc. A.C.-2 B.C.	heavy duty	1	1551978
1955-56	All A.C.-2 B.C.	heavy duty	1	1552388
1955-56	All 4 B.C.	heavy duty	1	1552321
1956	All 2 B.C.	standard	1	1551977
1956	All exc. A.C.-2 B.C.	heavy duty	1	1551978
1956	All 2/4 B.C.		2	1552799
1957	All 2 B.C.	standard	1	1552984
1957	All 2 B.C.	heavy duty	1	1552985
1957	All 4 B.C.	standard	1	1552930
1957	All 4 B.C.	heavy duty	1	1552929
1957	All 3/2 B.C.		1	1553222
1957	All F.I. exc. A.C.		1	1552925
1958	All A.S.-2 B.C.	heavy duty	1	1553852
1958	All A.S.-4 B.C.	heavy duty	1	1553853
1958	All 2 B.C. exc. A.S.	standard	1	1553476
1958	All 2 B.C. exc. A.S.	heavy duty	1	1553400
1958	All 4 B.C. exc. A.S.	standard	1	1553477
1958	All 4 B.C. exc. A.S.	heavy duty	1	1553401
1958	All 3/2 B.C. exc. A.S.		1	1553402
1958	All 3/2 B.C.-A.S.		1	1553854
1958	All F.I.		1	1553697
1959	All 2 B.C. exc. A.S.-T420E	standard	1	1554159
1959	All 2 B.C. exc. A.S.-T420E	heavy duty	1	1554158
1959	All 2 B.C.-A.S. exc. T420E	heavy duty	1	1554160
1959-60	All 4 B.C. exc. A.S.	standard	1	1554057
1959-60	All 4 B.C. exc. A.S.	heavy duty	1	1554058
1959	All 4 B.C.-A.S.	heavy duty	1	1554059
1959-60	All 3/2 B.C.		1	1554060
1959	All 2 B.C.-T420E-A.S.	standard	1	1554300
1959	All 2 B.C.-T420E exc. A.S.	heavy duty	1	1554299
1959	All T420E exc. A.S.	standard	1	1554298
1960	All S.T.-2 B.C.	standard	1	1554298
1960	All S.T.-2 B.C.	heavy duty	1	1554299
1960	All H.T.-2 B.C. exc. T420E	standard	1	1554159
1960	All H.T.-2 B.C. exc. T420E	heavy duty	1	1554158
1960	All H.T.-2 B.C.-T425E	standard	1	1554298
1960	All H.T.-2 B.C.-T425E	heavy duty	1	1554299

Group 3.403 GASKET-PLATE-STUD, AIR CLEANER TO CARBURETOR

1955-60	All 4 B.C.	GASKET, air cleaner to carburetor	AR	561624
1957-59	All 2 B.C. exc. T420E		1	535620
1957-58	All 3/2 B.C.		3	3708408
1957-58	All F.I.		1	1552967
1959-60	All 3/2 B.C.	Front and rear	2	535620
1959-60	All 3/2 B.C.	Center	1	3708408
1959	All T420E		1	3708408
1960	All H.T.-2 B.C. exc. T425E		1	535620
1960	All S.T.-2 B.C.-T425E		1	3708408

1959	All T420E	PLATE AND GASKET ASSY., air cleaner to carb. connection (▲)	1	1554062
1955-56	All 4 B.C.	STUD, air cleaner to carb. (7-7/16" long)	1	521636
1957	All 4 B.C.	w/standard air cleaner (6-3/4" long)	1	523747
1957	All H.T.-4 B.C.	w/heavy duty air cleaner (7-7/16" long)	1	521636
1957	All 2 B.C.-3/2 B.C.	w/standard air cleaner (5-1/2" long)	AR	523746
1957	All 2 B.C.	w/heavy duty air cleaner (5" long)	1	524548
1957-58	All F.I.	air cleaner to housing (5" long)	1	524548
1958	All 4 B.C.	(5-1/2" long)	1	523746
1958	All 2 B.C.	(3-1/2" long)	1	530282
1958	All 3/2 B.C.	(2-13/16" long)	3	530540
1959	All 2 B.C. exc. T420E	(2-13/16" long)	1	530540
1959-60	All 4 B.C.	(5" long)	1	524548
1959-60	All 3/2 B.C.	(2-5/16" long)	3	533243
1959-60	All T420E-T425E	(3-13/32" long)	1	534325
1960	All H.T.-2 B.C. exc. T425E	air cleaner to carb. (2-13/16" long)	1	530540
1960	All S.T.-2 B.C.		1	534325
1955-60	All (8.920)	NUT, air cleaner to carb. (1/4"-20 wing)	AR	148312

▲NOTE: For use when changing from std. 2 B.C. to T420E carb.

Group 3.405 BRACE, AIR CLEANER TO ENGINE

1946-52	P/6 exc. taxi	w/standard air cleaner	1	508757
1947-48	P/8	use with WCD-630S carb. after engine 12,387	1	509509
1949-54	P/8	w/standard air cleaner	1	509509
1949-52	P/6 taxi	w/heavy duty air cleaner	1	512438
1949-50	P/8	w/heavy duty air cleaner	1	512573
1951-54	P/8	w/heavy duty air cleaner	1	514885
1953-54	P/6	w/standard air cleaner	1	509509
1953	P/6	w/heavy duty air cleaner	1	517281
1954	P/6	w/heavy duty air cleaner	1	518439
1955-56	All 4 B.C.		1	521160
1957	All exc. F.I.		1	524576
1936-54	All	RETAINER, air cleaner brace insulator	1	499466
1955-57	All 4 B.C.		1	499466

Group 3.406 GASKET, AIR CLEANER ELEMENT TO OIL SUMP

1955-56	All	w/heavy duty air cleaner-neoprene (5-9/16" I.D.)	1	1551322
---------	-----	--	---	---------

Group 3.407 BOLT-ELBOW, AIR CLEANER TO CARBURETOR

1949-52	P/6	w/heavy duty air cleaner	Eye bolt	1	1551281
1951-54	P/8	w/heavy duty air cleaner	Eye bolt	1	1551197
1953	P/6	w/heavy duty air cleaner	Eye bolt	1	1551197
1954	P/6	w/heavy duty air cleaner	Eye bolt	1	1551281
1955-59	All 2 B.C.	w/heavy duty air cleaner	Eye bolt	1	1551995
1956	All 2/4 B.C.	ELBOW, carb. air cleaner and silencer		1	1552797
1957	All F.I.-A.C.	air cleaner and silencer		1	1553151

Group 3.410 ELEMENT, AIR CLEANER

1937-54	P/6	standard-type No. 1	1	1528439
1937-48	P/8	standard-type No. 3	1	1528441

1937-38	All	heavy duty-type No. 7S	1	1529681
1939-40	28 All	heavy duty-type No. 7S	1	1529681
1949-50	P/8	heavy duty-type No. 7S	1	1529681
1949-54	P/8	standard-type No. 6	1	1528698
1955-56	All	heavy duty-type No. 33	1	1551879
1957	All 2 B.C.	standard-type No. 30	1	1551752
1957	All 2 B.C.-4 B.C.	heavy duty	1	1552313
1957-60	All 3/2 B.C.	type No. A-59C	1	1553443
1957	All F.I.	type No. A-107C	1	1553172
1955-60	All 2 B.C.-4 B.C.	standard-type A-109C	1	1553782
1958	All 2 B.C.-4 B.C.	heavy duty-type A-63C	1	1553695
1958	All F.I.	type No. A-79C	1	1553922
1959-60	All 2 B.C.	heavy duty-type A-86C	1	5645017
1959-60	All 4 B.C.	heavy duty-type A-63C	1	1553695
1959-60	All 2 B.C.-4 B.C.	standard or heavy duty-type A-119-C (Polyurethane)	1	1554864

Group 3.417 HOUSING-GASKET-BOLT, FUEL INJECTOR UNIT

1957	All F.I.	HOUSING ASSY., fuel injector unit	Upper	1	531342
1957	All F.I.		Lower	1	7014450
1958	All F.I.		Upper	1	531209
1958	All F.I.		Lower	1	7017002
1957-58	All F.I.	GASKET, upper housing to lower housing		1	1553086
1957	All F.I. (8.906)	BOLT, lower housing to manifold		4	120628
					(Rd. Hd. 1/4"-20x3/8")

Group 3.417 COVER-GASKET, AIR METER ADJUSTMENT

1957-58	All F.I.	COVER, air meter adjustment	1	1553156
1957-58	All F.I.	GASKET, air meter adjustment cover	1	1553157

Group 3.417 HEATER-HOUSING-BRACE-DUCT-HOSE, INTAKE AIR HEATER

1957	All F.I. exc. A.C.	HEATER ASSY., engine intake air	1	529037	
1957	All F.I. exc. A.C.	HOUSING AND CONTROLS ASSY., intake air heater	1	529038	
1958	All F.I.		1	531046	
1957	All F.I. exc. A.C.	BRACE, intake air housing	1	529493	
1957	All F.I. exc. A.C.	DUCT, intake air heater	1	529040	
1958	All F.I.	intake air to baffle	1	531037	
1958	All F.I.	intake air heater	Upper	1	531058
1958	All F.I.	intake air heater	Lower	1	531059
1957	All F.I. exc. A.C.	HOSE ASSY., air cleaner air inlet	(10-1/2" long)	1	529030
1957	All F.I.-A.C.		(14-1/2" long)	1	528391
1958	All F.I.	air intake duct connector	(3-1/4" long)	1	530857
1957	All F.I.	RETAINER, air intake tube screen		1	528397
1958	All F.I.	SEAL, air intake to radiator lower baffle		1	530654
1957	All F.I.	SCREEN, air intake tube		1	528396
1957	All F.I. exc. A.C.	SPRING, air heater valve return		1	529065
1957	All F.I.	TUBE assy., air cleaner and silencer inlet		1	528392

Group 3.425 TRUNNION, CARBURETOR ROD

1940-57	All L.H.D., S.T.	accelerator control rod	1	504300
1948-55	All H.T. & P.G.	carburetor throttle rod	1	512476
1948-49	All H.T.	throttle control rear rod	1	512476

1950-54	All H.T. & P.G.	accelerator pedal rod	1	512397
1954	P/8 S.T.	accelerator pedal rod	1	512397
1956	All H.T.	throttle control intermediate rod	1	522289
1956-58	All H.T., exc. 2/4 B.C.	carburetor throttle rod	1	522288
1956	All 2/4 B.C.	carburetor throttle rod	1	522860
1958	All S.T.	carburetor throttle rod	1	522289
1960	All H.T.-2 B.C.-4 B.C. exc. T425E	to lever-ball type	1	523178
1960	All H.T.-2 B.C.-T425E	ball type	2	531034
1955-56	All H.T.	BUSHING, dash bracket pedal rod lever	2	520401
1958	All H.T. exc. F.I.	throttle control lever (3/8" long x 3/8" dia.)	1	531171
1958-60	All	BUSHING, accelerator pedal rod-nylon	2	529878
1957-60	All 3/2 B.C.	CLIP, carburetor rod to front carburetor	1	554285
1957-60	All 3/2 B.C. (4.054)	carburetor rod to rear carburetor	1	2294788
1959-60	All	PIN, pedal rod to shaft	2	9409665
1957	All	RETAINER, throttle rod ball joint stud	AR	529475
1957	All	accelerator rod ball joint stud	AR	529475
1933-37	All	SPRING, anti-rattle throttle & acc. trunnion	AR	495472
1937-57	All S.T.	throttle control lever (3/8" long x 3/8" dia.)	1	499991
1940	29 All	throttle control idler (1/2" long x 1/4" dia.)	AR	504288
1940	All L.H.D.	accelerator pedal-accelerator control rod	2	504288
1950-54	All H.T. & P.G.	accelerator pedal rod to throttle idler lever	1	504288
1957	All	STUD, throttle control rod to lever-ball	1	523178
1957-58	All F.I.	throttle control rod to lever-ball	1	523178
1958	All S.T.	throttle control rod to lever-ball	1	523178
1959	All exc. 3/2 B.C. & T420E	throttle control rod to lever-ball	1	523178
1959-60	All 3/2 B.C. & T420E	throttle control rod to lever-ball	1	531034
1958	All	SUPPORT AND BUSHING ASSY., accelerator pedal rod	1	529877
1948-54	P/8 H.T.	WASHER, intermediate rod to lever (1/4" I.D.x1/2" O.D.)	2	510851

Group 3.429 LINKAGE PACKAGE, ACCELERATOR

1941-48	25 S.T.	accelerator pedal rod	1	513607
1941-48	26 S.T.	throttle control lever (3/8" long x 3/8" dia.)	1	513667

Group 3.430 ROD, CARBURETOR TO IDLER LEVER THROTTLE

NOTE: C to C means center to center of holes.

1946-52	P/6 S.T.	carburetor throttle	1	514827
1947-53	P/8 S.T.	9" C to C of holes, with WCD 630S carburetor	1	509501
1953-54	P/6 L.H.D., S.T.	carburetor throttle	1	515229
1960	All	carburetor throttle	1	536616
1960	All H.T.	trans. carburetor throttle	1	536616
1956	All 2/4 B.C.	PIN, front carburetor throttle lever	1	522862
1956	All 2/4 B.C.	rear carburetor throttle lever	1	522861

Group 3.430 ROD, THROTTLE CONTROL

1948-52	P/6 H.T.	carburetor throttle	1	510842
1948-53	P/8 H.T. & P.G.	carburetor throttle	1	510843
1953-54	P/6 H.T. & P.G.	carburetor throttle	1	517256

1954	P/8	carburetor throttle	1	510843
1955	All L.H.D., S.T.,-B.C.	carburetor throttle	1	519061
1955	All H.T.-2 B.C.	carburetor throttle	1	519485
1955	All H.T.-4 B.C.	carburetor throttle	1	521162
1955	All S.T.-4 B.C.	carburetor throttle	1	521163
1956	All L.H.D., S.T.-2 B.C.	carburetor throttle	1	521782
1956	All S.T.-2 B.C.-4 B.C.	carburetor throttle	1	521531
1956	All H.T.-2 B.C.	carburetor throttle	1	521746
1956	All H.T.-2 B.C.-4 B.C.	carburetor throttle	1	521533
1956	All 2/4 B.C.	front carburetor throttle	1	522857
1956	All 2/4 B.C.	carburetor interconnecting	1	522859
1957	All S.T.-2 B.C.	carburetor throttle	1	523177
1957	All S.T. exc. 3/2 B.C.	carburetor throttle	1	523176
1957	All H.T.-2 B.C.-4 B.C.	carburetor throttle	1	524097
1957	All S.T.-3/2 B.C.	carburetor throttle	1	528756
1957	All H.T.-3/2 B.C.	carburetor throttle	1	528720
1958	All S.T.-2 B.C.	carburetor throttle	1	529889
1958	All S.T.-4 B.C.	carburetor throttle	1	529890
1958	All H.T.-2 B.C.	carburetor throttle	1	531176
1958	All H.T.-4 B.C.	carburetor throttle	1	531177
1958	All S.T.-3/2 B.C.	carburetor throttle	1	530735
1959	All 2 B.C.-3/2 B.C.	carburetor throttle	1	533631
1959	All 4 B.C.	carburetor throttle-use w/534513 extension	1	534518
1958	All H.T. exc. F.I.	trans. carburetor throttle	1	529793
1959	All 2 B.C.-3/2 B.C.	trans. carburetor throttle	1	533631
1959	All H.T.-4 B.C.	trans. carburetor throttle	1	532595
1948,				
1950-54	P/6 H.T. & P.G.	intermediate	1	510857
1949	P/6 H.T.	intermediate	1	511443
1949-53	P/8 H.T. & P.G.	intermediate	1	511444
1954	P/8	intermediate	1	511444
1955-57	All L.H.D., S.T.-2 B.C.-4 B.C.	intermediate	1	519671
1955	All H.T.	intermediate	1	519472
1956	All H.T.-2 B.C.-4 B.C.	intermediate	1	522196
1957	All H.T. exc. F.I.	intermediate	1	524098
1957-58	All F.I.	intermediate-to cross shaft	1	528311
1957	All F.I.	throttle control	Inner	1 528311
1958	All F.I.	throttle control	Inner	1 530526
1949	All H.T.	rear	1	511446

Group 3.431 ROD, ACCELERATOR PEDAL

1941-48	All exc. 25-27 L.H.D., S.T.	(4-1/2" long)	1	505837
1941-48	25-27 L.H.D., S.T.	(4-1/2" long)	1	506694
1949	All L.H.D.		1	511299
1950-52	All H.T.		1	513954
1950-52	All L.H.D., S.T.		1	514004
1953	All L.H.D., S.T.		1	515225
1954	P/6 S.T.		1	515225
1953-54	All H.T. & P.G.		1	515246
1954	P/8 S.T.		1	515246
1955-56	All L.H.D.		1	519470
1957	All L.H.D., S.T.		1	519470
1957	All H.T.		1	524096
1958	All		1	529771
1959-60	All		1	533054
1941-48	P/6 L.H.D., S.T.	ROD, cross shaft to idler lever (11-7/32" long)	1	505848
1949-52	All L.H.D., S.T.		1	511300
1953	P/8 S.T.		1	517285
1953-54	P/6 S.T.		1	517285
1959-60	All	BRACKET ASSY., pedal rod	1	532581
1958	All	PLATE, accelerator pedal anti-squeak-nylon	1	529767
1959-60	All	SHAFT, pedal	1	532586
1938-57	All (3.425)	SPRING, accelerator pedal rod anti-rattle	AR	495472

Group 3.440 DIAPHRAGM-STRUT, THROTTLE RETURN CHECK

1958-59	All H.T.-4 B.C.	DIAPHRAGM, throttle return check-anti-stall	1	7015573
1960	All H.T.-4 B.C.	throttle return check-anti-stall (see note)	1	7017806
1958	All H.T.-2 B.C.	DIAPHRAGM PKG., carb. anti-stall	1	531331
1958	All H.T.-3/2 B.C.	carburetor anti-stall	1	531332
1958-60	All H.T.-4 B.C.	STRUT, throttle return check diaphragm	1	531579

NOTE: Use w/533688 fitting & 533816 hose to replace pipe.

Group 3.444 BRACKET, THROTTLE RETURN CHECK DIAPHRAGM

1958	All H.T.-4 B.C.		1	531578
1958	All H.T.-2 B.C.		1	531227
1959-60	All H.T.-4 B.C.		1	532852

Group 3.450 LEVER, THROTTLE CONTROL IDLER

1948	All H.T.	trans. throttle rod idler	1	510839
1949-51	All H.D.	trans. throttle rod idler	1	511441
1952-54	All H.T. & P.G.	trans. throttle rod idler	1	516651
1937-53	All S.T.	PIN, throttle idler lever manifold	1	496784
1954	P/6 S.T.		1	496784

Group 3.451 PEDAL, ACCELERATOR

1940	29 All		1	504294
1941-42	All L.H.D.		1	505730
1946-54	All L.H.D.		1	511007
1955-56	All L.H.D.		1	519360
1957	All L.H.D. exc. P.B.		1	519360
1957	All P.B.		1	524150
1958	All S.B.		1	529768
1958	All H.T.-P.B.		1	530015
1959-60	All S.T.	use w/533054 rod w/nylon roller	1	532590
1959-60	All H.T.-S.B.	use w/533054 rod w/nylon roller	1	532590
1959-60	All H.T.-P.B.		1	532597

Group 3.452 STUD-SUPPORT-BRACKET-PIN, ACCELERATOR

1933-39	All	pedal to floor anchor	2	499977
1940	26 All	pedal to floor anchor	2	499977
1941-42	All	pedal to floor anchor	2	499977
1959-60	All	pedal to floor anchor	2	532593
1949-52	All L.H.D.	SUPPORT, accelerator pedal	1	4562315
1953-54	All		1	4599925
1955-57	All L.H.D.		1	519356
1958	All	BRACKET, accelerator pedal to floor	1	529764
1946-48	All L.H.D.	PIN, accelerator pedal hinge	1	508930
1949-54	All		1	508930
1955-57	All L.H.D.		1	519362
1958	All		1	529770
1953-54	All	GUARD, accelerator pedal	1	515214
1955-57	All (8.934)	RETAINER, hinge pin	1	148148

Group 3.454 LEVER ASSEMBLY, THROTTLE CONTROL

1948	All H.T.	to dash rocker	1	510833
1949	All H.T.	to dash rocker	1	511435
1955-57	All L.H.D., S.T.	to dash rocker	1	519466
1955-56	All H.T.	to dash rocker	1	520400
1958	All S.T. exc. F.I.		1	531630
1958	All H.T. exc. F.I.		1	531632
1959-60	All	use w/534513 extension	1	534515
1941-54	P/6 S.T.	LEVER, accelerator idler, L.H.D. only on 1950 thru 54	1	505846
1941-53	P/8 S.T.		1	505847
1942-48	All L.H.D., S.T.	LEVER, accelerator cross shaft throttle cracker	1	507566
1941-53	All L.H.D., S.T.	SPRING, throttle cracker lever anti-rattle cross shaft anti-rattle (7/16" I.D.x19/32")	1	505836
1954	P/6 S.T.		1	505836
1949	All H.T.	LEVER, throttle control idler	1	511438
1950-54	All H.T. & P.G.		1	513951
1954	P/8 S.T.		1	513951
1948-54	P/6 H.T. & P.G.	STUD, throttle control idler lever to cylinder block . .	1	510817
1959	All 4 B.C.	EXTENSION ASSY., carb. lever	1	534513
1960	All 4 B.C.	carb. lever	1	536613
1958	All H.T. exc. F.I.	INSULATOR, throttle control rod lever	1	531172
1948	All H.T.	PIN, dash rocker lever to bracket	1	510837
1955-56	All L.H.D.	accel. pedal rod pivot	1	519469
1957	All L.H.D., S.T.		1	519469*

Group 3.459 SPRING, THROTTLE CONTROL RETURN

1941-48	All exc. 25 L.H.D., S.T.		1	505835
1941-48	25 L.H.D., S.T.		1	506697
1948-54	All H.T. & P.G.		2	510877
1949-53	All S.T.		1	505835
1954	P/6 S.T.		1	505835
1954	P/8 S.T.		1	518435
1955-57	All L.H.D., S.T.		1	519672
1955-57	All H.T.		2	519468
1958	All		1	531483
1959-60	All		1	534403
1958	All F.I.	BRACKET, air meter throttle return check mtg.	1	7017055
1958	All F.I.	DIAPHRAGM ASSY., throttle return check	1	7017052
1958	All F.I.	TUBE ASSY., air meter throttle return check	1	7017053
1948-52	All H.T.	CLIP, throttle control return spring	1	511418
1953	All P.G.		1	5843674
1948-54	All H.T. & P.G.	STUD, return spring anchor	1	510878
1958	All F.I.	VALVE ASSY., air meter throttle return check	1	7017058

Group 3.463 LEVER-SHAFT-BRACKET, ACCELERATOR

1942-48	All L.H.D., S.T.	SHAFT, accelerator cross	1	507568
1949	All L.H.D., S.T.		1	511302
1950-52	All L.H.D., S.T.		1	513766
1953	All L.H.D., S.T.		1	515230
1954	P/6 S.T.		1	515230
1957	All H.T. exc. F.I.	engine throttle control cross	1	524101
1949	P/6 H.T.	SHAFT AND BRACKET, throttle control intermediate		
1950-54	P/6 H.T. & P.G.		1	513957
1948-54	P/8 H.T. & P.G.	throttle cross	1	510831
1954	P/8 S.T.		1	510831

1942-48	All L.H.D., S.T.	BRACKET, accelerator cross shaft	2	507656
1949-53	All L.H.D., S.T.		2	511297
1954	P/6 S.T.		2	511297
1948-54	All H.T. & P.G.	BRACKET ASSY., throttle rod idler lever	1	514388
1949	All H.T.		1	511433
1955-57	All L.H.D., S.T.	throttle control dash	1	519463
1956	All H.T.	throttle control dash	1	522193
1957	All H.T.	throttle control dash	1	524083
1957	All H.T. (3.585)	BUSHING, throttle control dash bracket	1	524086
1949-53	All L.H.D., S.T.	SPACER, accelerator cross shaft	1	511306
1954	P/6 S.T.		1	511306
1949-50	All L.H.D., S.T.		1	511297
1948-53	P/8 H.T. & P.G.	BRACKET, throttle control idler lever	1	514355
1954	P/8		1	514355
1955	All L.H.D., S.T.	engine throttle control	1	519057
1955	All H.T.	engine throttle control	1	521986
1956-57	All L.H.D., S.T.	engine throttle control	1	522269
1956	All H.T. exc. C.C.	engine throttle control	1	522190
1956	All C.C.-H.T.	engine throttle control	1	521514
1957	All H.T. exc. F.I.	engine throttle control	1	524089
1957	All H.T.	engine throttle control cross shaft	1	524087
1958	All H.T. exc. F.I.	engine throttle control	1	529773
1959-60	All H.T.	engine throttle control	1	533619
1957	All F.I.	BRACKET AND LEVER ASSY., engine throttle control	1	524859
1958	All F.I.		1	530517
1956-60	All H.T. exc. F.I.	BUSHING, engine throttle control bracket (5/16" I.D.)	2	522277
1956	All H.T. (3.425)	engine throttle control lever Inner and Outer	2	520401
1957	All H.T.	engine throttle control bracket (9/16" I.D.)	1	524086
1957-60	All H.T. exc. F.I. (3.425)	engine throttle control lever	1	520401
1957-58	All F.I. (3.425)	engine throttle control lever Outer	1	520401
1957-58	All F.I.	GASKET, throttle control bracket to housing	1	524864
1955-57	All L.H.D., S.T.-2 B.C.-4 B.C.	LEVER, engine throttle control	1	519060
1956	All 2/4 B.C.		1	522911
1957	All H.T. exc. F.I.		1	524091
1958	All H.T. exc. F.I.		1	529781
1958	All F.I.	accelerator control rod	1	530523
1959	All H.T.	engine throttle control	1	533620
1960	All H.T.	engine throttle control	1	536609
1955-57	All L.H.D., S.T. (3.452)	PIN, throttle control engine lever pivot	1	519362
1955-58	All S.T. (8.934)	RETAINER, throttle control engine lever		
		pivot pin (1/4")	1	148148
1957	All H.T. (8.934)	throttle control cross shaft-spring type (7/16")	2	455565
1957-58	All F.I. (8.934)	throttle control engine bracket shaft (5/16")	1	455563
1957	All H.T.	SHAFT, engine throttle control lever to bracket	1	524095
1957	All F.I.	throttle control cross	1	524990
1959-60	All H.T.	engine throttle control lever to bracket	1	533623
1958	All H.T. exc. F.I.	SPRING, throttle control lever over center return	1	529794
1958	All H.T. exc. F.I.	BOLT, throttle control overtravel lever	2	529780
1958	All H.T. exc. F.I.	throttle control overtravel spring	1	529787

Group 3.469 BELLOWS, ACCELERATOR ROD TOE BOARD

1937-38	All		1	500207
1939-40	P/6		1	500207
1941-48	All L.H.D.		1	505779
1949	All L.H.D.		1	512652
1950-52	All L.H.D.		1	514003
1953-54	All L.H.D.		1	515244
1955-57	All L.H.D.		1	519357

Group 3.481 CONTROL ASSEMBLY, THROTTLE HOLDING

1959-60	All	throttle holding-w/Magi-Cruise	1	533670
1959-60	All	KNOB ASSY., throttle holding control-w/Magi-Cruise	1	534563

Group 3.483 BRACKET-COVER-LEVER-SPRING, THROTTLE HOLDING CONTROL

1959-60	All	BRACKET, release chain brake pedal-w/Magi-Cruise	1	534587
1959-60	All	throttle holding control lever dash-w/Magi-Cruise	1	534527
1959-60	All	COVER, throttle holding control-w/Magi-Cruise	1	534572
1959-60	All	LEVER AND SHAFT ASSY., throttle holding control-w/Magi-Cruise	1	534565
1959-60	All	SPRING AND CONNECTOR ASSY., throttle holding control release-w/Magi-Cruise	1	534668
		TRUNNION (see Group 8.077 for use)		375437

Group 3.601 MANIFOLD, EXHAUST

1941-52	P/6		1	516167
1941-54	P/8		1	516168
1953-54	P/6		1	517273
1955	All	522837 RH		518089 LH
1956	All	521624 RH		521630 LH
1957	All exc. F.I.	523537 RH		
1957	All F.I.	524883 RH		
1957	All			523539 LH
1958	All exc. F.I.-T395A	528595 RH		
1958	All F.I.	530374 RH		
1958	All exc. T395A			528598 LH
1958	All T395A	530961 RH		530965 LH
1959-60	All exc. T402A-T425A	537508 RH		532312 LH
1959-60	All T420A-T425A	532021 RH		532216 LH

Group 3.602 COVER-BAFFLE-DEFLECTOR, MANIFOLD

1935-54	All exc. P/6 1935	choke heat	1	497612
1955-60	All	BAFFLE, intake manifold choke heat tube	1	518220
1939-50	P/6	DEFLECTOR, carb. heat	1	505251
1947-54	P/8	with WCD-630S carburetor on 1947	1	518567
1953-54	P/6		1	517278
1954	P/8		1	518567

Group 3.603 TUBE, INTAKE MANIFOLD CHOKE HEAT

1937-58	All	(8.964)	TUBE, automatic choke to manifold-cut copper tubing to required length. (1/4")	AR	364934
1955-60	All			1	518256
1959	All	T420E		1	534323
1937-60	All	(8.963)	NUT, carburetor to heat tube coupling (1/4")	1	114627
1937-60	All	(8.963)	SLEEVE, carburetor to heat tube coupling (1/4")	1	114628
1955	All	2 B.C.	(Carter) carburetor to heat tube insulating	1	518222

Group 3.609 PIPE, EXHAUST

1941-48	25 S.T.		(35-11/16" long)	1	505276
1941-48	27 S.T.		(38" long)	1	505277
1941-48	24-26 S.T.		(36-3/16" long)	1	505278
1941-48	28-29 S.T.		(38-1/2" long)	1	505279
1948	27 L.H.D., H.T.			1	510948
1948	28 L.H.D., H.T.			1	510950
1949-54	P/8		(34-19/32" long)	1	511279
1949-54	P/6		(32-1/4" long)	1	511278
1955	All		(29-1/4" long)	1	519002
1956	All	exc. dual exh.	(29-5/8" long)	1	521684
1956-57	All	w/dual exh.			524220 LH
1957	All	exc. dual exh.		1	523571
1956-57	All exc. F.I.	w/dual exhaust	524219 RH		
1957	All F.I.	w/dual exh.	528615 RH		
1958	All	exc. dual exh.	Rear	1	529524
1958	All exc. F.I. & T395A	w/dual exhaust	529522 RH		
1958	All F.I.	w/dual exhaust	530576 RH		
1958	All exc. T395A	w/dual exh.			529523 LH
1958	All T395A	w/dual exh.	530968 RH		530969 LH
1959	All	exc. dual exh.		1	534435
1959	All exc. T420A	w/dual exh.	532825 RH		532826 LH
1959	All T420A	w/dual exh.	533075 RH		533076 LH
1960	All exc. T425A	exc. dual exh.		1	536580
1960	All exc. T425A	w/dual exh.	536582 RH		536583 LH
1960	All T425A	w/dual exh.	536713 RH		536714 LH
1955	All	PIPE, crossover		1	518995
1956	All	crossover		1	521678
1957	All	crossover-exc. dual exh.		1	523569
1957	All F.I.	crossover exh. equalizer-w/dual exh.	Front	1	528613
1958	All	crossover-exc. dual exh.		1	529544
1958	All F.I.	crossover-w/dual exh.	Front	1	530574
1959-60	All exc. T425A	crossover-exc. dual exh.		1	532787
1956	All	ADAPTER, exhaust pipe to manifold-w/dual exh.		1	521701
1957-58	All exc. F.I.	to L.H. manifold-w/dual exh.		1	529549
1957	All F.I.	to L.H. manifold-w/dual exh.		1	528612
1958	All T395A	to R.H. manifold-w/dual exh.		1	530966
1958	All F.I.	to L.H. manifold-w/dual exh.		1	530573
1957	All	CONNECTOR, R.H. manifold to exh. pipe-exc. dual exh.		1	523566
1957	All F.I.	w/dual exh.		1	523566
1958	All	exc. dual exhaust	529540 RH		
1958	All F.I.	w/dual exh.		1	529540
1959-60	All exc. T425A	R.H. manifold to exh. pipe-exc. dual exh.		1	532363

Group 3.610 FLANGE, EXHAUST PIPE

1933-54	All			1	501719
1955	All			1	519005

1956	All	to connector-exc. dual exh.	1	521674
1957-60	All exc. F.I.	w/dual exh.	1	533632
1957	All exc. F.I.	exh. pipe to connector-w/dual exh.	2	501719
1957-58	All F.I.	exc. pipe to adapter-w/dual exh.		501719 LH
1957	All F.I.	to manifold-w/dual exh.	2	501719
1959-60	All exc. T420A-T425A	to manifold-w/dual exh.	2	533632
1959-60	All T420A-T425A			

Group 3.611 GASKET, EXHAUST PIPE FLANGE

1935-54	All	exhaust pipe flange	2	496783
1955-57	All	crossover pipe to manifold	2	522771
1955	All	exhaust pipe to adapter-w/dual exh.	1	518991
1956-57	All	exhaust pipe to crossover pipe-exc. dual exh.	1	522771
1956	All	to connector-exc. dual exh. (9/64" thick)	1	521676
1957-58	All	exhaust pipe connector to R.H. manifold-exc. dual exh.	1	523420
1957	All	adapter to manifold-w/dual exh.	1	523568
1957	All	exhaust pipe connector to R.H. manifold-exc. dual exh.	1	523568
1958-60	All exc. T425A	adapter to manifold-w/dual exh.	1	529542
1958	All	exhaust pipe to connector-exc. dual exh. (5/64" thick)	1	529542
1958-60	All	crossover pipe to manifold-exc. dual exh.	2	496783
1958-60	All exc. T425A	exhaust pipe to adapter-w/dual exh.	2	496783
1958	All	exhaust pipe to R.H. manifold-w/dual exh.	2	496783
1958	All T395A	exhaust manifold to adapter-w/dual exh.	1	530967
1959-60	All exc. T425A	exh. pipe to manifold-exc. dual exh. (9/64" thick)	1	523420
1959-60	All exc. T420A	exh. pipe to manifold-w/dual exh.	4	496783
1959-60	All T420A-T425A	exh. pipe to manifold-w/dual exh.	2	523420

Group 3.616 BRACE, EXHAUST PIPE

1939-40	26 All	to clutch housing	1	502768
1941-48	All	to clutch housing	1	502768
1949-54	All S.T.	to clutch housing	1	511277
1949-54	All H.T.	to flywheel housing	1	511646
1953	All P.G.		1	518455

Group 3.640 THERMOSTAT, MANIFOLD HEAT CONTROL VALVE

1939-51	P/6	3-1/2 coils	1	502453
1940-50	P/8	3-1/2 coils	1	502453
1951	P/8		1	516304
1952	P/6		1	516177
1952-54	P/8		1	516303
1953-54	P/6 H.T.		1	517276
1953-54	P/6 S.T. & P.G.		1	517009
1955-58	All exc. F.I.		1	520135
1959-60	All		1	531972

Group 3.641 DEFLECTOR-SPRING, MANIFOLD HEAT CONTROL VALVE

1941-51	All	DEFLECTOR, heat control thermostat	1	505575
1952-54	All		1	516166
1955	All	SPRING, anti-rattle	1	519253
1956-60	All exc. F.I.		1	521580

Group 3.646 BUSHING, MANIFOLD HEAT CONTROL VALVE

1933-51	All exc. P/6 1939	2	497586
---------	-------------------	---	--------

Group 3.647 BIN, HEAT CONTROL VALVE ANCHOR

1940-54	All exc. P/8 1940	1	502293
1955-60	All exc. F.I.	1	518209

Group 3.701 MUFFLER

1934-54	All	1	500867
1955	All	1	518992
1956	All	1	521677
1956-57	All	2	524742
1957	All	1	524806
1958	All	1	529543
1958	All	2	528560
1959-60	All	1	532390
1959-60	All T420-T425A	2	532391
1959-60	All T420A-T425A	2	532390
1958	All 25-27-T395A	1	530995
1958	All 28-T395A	1	530996

Group 3.702 RESONATOR ASSY., MUFFLER

1957	All F.I.	2	528964
1958	All	2	529151

Group 3.704 INSULATOR-STRAP-SUPPORT-WASHER, MUFFLER

1959	All	INSULATOR, tail pipe rear supt. to frame	AR	519014
1959	2145		1	531856
1935-55	All	STRAP, fabric	2	497935
1939,				
1941-48	26-28 All	SUPPORT	1	502776
1940	All		1	502776
1941	29 All		1	502776
1941-48	25 All		1	505288
1949-54	All		1	502776
1955	All exc. 2867		1	519010
1955	2867		1	519459
1956	All exc. 2867		1	521692
1956	2867		1	521693
1956-57	All	w/dual exh. Front		521713 LH
1957	All exc. 2867	exc. dual exh.	1	524812
1957	All exc. 2867	w/dual exhaust		521692 RH
1957	2867	exc. dual exhaust	1	524813
1957	2867	w/dual exhaust		521693 RH
1958	All			529700 RH
1958	All	w/dual exh.		530096 LH
1958	All	muffler and tail pipe	2	529700 RH
1958	All	resonator-w/dual exh.		529704 LH
1959	All (8.977)	SCREW, tail pipe rear supt. (Hex. hd. 5/16"-18x1-1/4")	AR	177902
1939-56	All exc. 1939 25	WASHER, tail pipe supt. ins. reinf.	1	502780
1957	All	exc. dual exhaust	1	502780
1959	All		AR	502780

Group 3.705 PIPE, MUFFLER TAIL

1941-48	26-29 All exc. sta. wag.	(94-1/8" long)	1	508602
1941-48	25 All	(80-11/32" long)	1	508601
1946-48	Sta. wag.	(91-15/16" long)	1	508603
1949-52	All exc. 2561-62-71	(85-1/2" long)	1	511282
1949-52	2561-62-71 All	(86-7/16" long)	1	511522
1953-54	2511-37-67-69 All	(87-1/2" long)	1	515265
1953-54	2562-71 All	(86-1/2" long)	1	518642
1954	28 All	(97-1/2" long)	1	517562
1955	2511-19-37 All	(96-1/2" long)	1	519006
1955	28 All	(103-1/2" long)	1	519008
1955	2562-63-64 All	(115" long)	1	519743
1956	2711-19-37-39 All	w/dual exhaust (93-3/8" long) 522128 RH		
1956	2711-19-37-39 All	w/dual exhaust (60" long)		521711 LH
1956	2711-19-37-39 All	exc. dual exhaust (96-1/16" long)	1	521689
1956	2762-63-64 All	exc. dual exhaust (96-5/16" long)	1	521981
1956	2762DF-63F-64DF	w/dual exhaust (96-5/16" long) 522430 RH		
1956	2762DF-63F-64DF	w/dual exhaust (62-3/4" long)		521982 LH
1956	28 All	exc. dual exhaust (103-1/16" long)	1	521691
1956	28 All	w/dual exhaust (100-3/8" long) 522129 RH		
1956	28 All	w/dual exhaust (67" long)		521712 LH
1957	2711-19-37-39-62DF-63F-64 All	exc. dual exhaust (92-3/4" long)	1	523246
1957	2711-19-37-39 All	w/dual exhaust (97" long) 523244 RH		
1957	2711-19-37-39 All	w/dual exhaust (63-1/2" long)		523250 LH
1957	2762DF-63F-64DF	w/dual exhaust (92-3/4" long) 523247 RH		
1957	2762DF-63F-64DF	w/dual exhaust (59" long)		523251 LH
1957	2762FC	exc. dual exhaust (83" long)	1	523943
1957	2762FC	w/dual exhaust 528480 RH		528481 LH
1957	2819-37-39-67 All	exc. dual exhaust (100" long)	1	523248
1957	2819-37-39-67 All exc. F.I.	w/dual exhaust (104" long) 523249 RH		
1957	2819-37-39-67 All exc. F.I.	w/dual exhaust (70-1/2" long)		523252 LH
1957	All F.I.	w/dual exh. (21" long)-front 528906 RH		
1957	All F.I.	w/dual exh. (47-1/2" long)-front		528909 LH
1957	All F.I.	w/dual exh. (74-5/8" long)-rear 528907 RH		
1957	All F.I.	w/dual exh. (14-5/8" long)-rear		528910 LH
1958	25-27 All	w/dual exh. (46-1/2" dev. lth.) Front 529645 RH		
1958	25-27 All exc. T395A	w/dual exh. (47-1/2" dev. lth.) Front		529648 LH
1958	25-27 All T395A	w/dual exh. (47-1/2" dev. lth.) Front		530970 LH
1958	2547 SD-67 SD, 2793 SD	exc. dual exh. (46-1/2" dev. lth.) Front	1	529729
1958	2567, 2731-39-41-49-93-94	exc. dual exh. (46-1/2" dev. lth.) Front	1	529644
1958	2831-39-49 All	exc. dual exh. (48-1/2" dev. lth.) Front	1	529646
1958	2831-39-49 All	w/dual exh. (48-1/2" dev. lth.) Front 529647 RH		
1958	2831-39-49 All exc. T395A	w/dual exh. (49-1/2" dev. lth.) Front		529649 LH
1958	2831-39-49 All T395A	w/dual exh. (49-1/2" dev. lth.) Front		530971 LH
1958	All exc. T395A	w/dual exh. Intermediate 529697 RH		529698 LH
1958	2547SD-67SD, 2793SD	exc. dual exh. (92-1/2" dev. lth.) Rear	1	531480
1958	25-27 All	w/dual exh. (14" dev. lth.) Rear 529748 RH		
1958	25-27 All exc. T395A	w/dual exh. (14" dev. lth.) Rear		529749 LH
1958	25-27 All T395A	w/dual exh. (92-1/2" dev. lth.) Rear		531516 LH
1958	2567, 2731-39-41-49-93-94	exc. dual exh. (92-1/2" dev. lth.) Rear	1	531479
1958	2831-39-49 All	exc. dual exh. (92-1/2" dev. lth.) Rear	1	531481
1958	2831-39-49 All	w/dual exh. (17" dev. lth.) Rear 529750 RH		
1958	2831-39-49 All exc. T395A	w/dual exh. (17" dev. lth.) Rear		529751 LH
1958	2831-39-49 All T395A	w/dual exh. (95-1/2" dev. lth.) Rear		531517 LH
1959-60	21-23 All exc. T425A	exc. dual exh. (54" dev. lth.) Front	1	532790
1959-60	21-23-27 All exc. T420A-T425A	w/dual exh. Front 532793 RH		532794 LH
1959-60	2735	exc. dual exh. (54" dev. lth.) Front	1	532791
1959-60	21-23-27 All T420A-T425A	w/dual exh. Front		533077 LH
1959-60	24-28 All	exc. dual exh. (56" dev. lth.) Front	1	532792
1959-60	24-28 All exc. T420A-T425A	w/dual exh. Front 532795 RH		532796 LH

1959-60	24-28 All T420A-T425A . . .	w/dual exh. Front	532792 RH	533078 LH
1959	21-All T420A	w/dual exh. (54" dev. lth.) Front	532791 RH	
1959	21 All exc. 2135-45	exc. dual exh. (62" dev. lth.) Rear	1 536701	
1959	21 All exc. 2135-45	w/dual exh. Rear	536706 RH	532802 LH
1959	21 All T420A exc. 2135-45	w/dual exh. Rear	536702 RH	536703 LH
1959	2135, 2735	exc. dual exh. (50" dev. lth.) Rear	1 534493	
1959	2135, 2735 All exc. T420A	w/dual exh. (50" dev. lth.) Rear	534494 RH	
1959	2135-45, 2735 All exc. T420A	w/dual exh. (50" dev. lth.) Rear	534495 LH	
1959	2135, 2735 All T420A	w/dual exh. (50" dev. lth.) Rear	534493 RH	
1959	2135-45, 2735 All T420A	w/dual exh. (50" dev. lth.) Rear	531845 LH	
1959	2145	exc. dual exh. (46" dev. lth.) Rear	1 534497	
1959	2145 All exc. T420A	w/dual exh. (46" dev. lth.) Rear	534498 RH	
1959	2145-T420A	w/dual exh. (46" dev. lth.) Rear	534497 RH	
1959-60	24-28 All	exc. dual exh. Rear	1 536704	
1959-60	24-28 All T420A-T425A	w/dual exh. Rear	536704 RH	536705 LH
1960	21-23 All T425A	w/dual exh. Front	532791 RH	
1960	21-23 All exc. 2135-45	exc. dual exh. Rear	1 * 536701	
1960	21-23 All exc. 2135-45	w/dual exh. Rear	536706 RH	536707 LH
1960	21-23 All T425A exc. 2135-45	w/dual exh. Rear	536702 RH	536703 LH
1960	2135-45, 2735	exc. dual exh. Rear	1 536693	
1960	2135-45, 2735 All	w/dual exh. Rear	536694 RH	
1960	2135-45, 2735 All exc. T425A	w/dual exh. Rear	1 536695 LH	
1960	2135-45, 2735 All T425A	w/dual exh. Rear	1 536696 LH	
1959-60	24-28 All exc. T420A-T425A	w/dual exh. Rear	536708 RH	536709 LH
1956	All exc. 2762-63-64	BEZEL ASSY., tail pipe outlet-w/dual exhaust	2 522119	
1956-57	All	EXTENSION, w/dual exhaust (25" long)	524743 LH	
1957	All	w/dual exhaust and tire carrier (13-5/16" long)	2 524469	
1959	2135-45, 2735	exc. dual exh. (9" long)	1 531920	
1959-60	2135-45 2735 All exc. T420A	w/dual exh. (9" long)	2 536691	
1959	2135-45, 2735 All T420A	w/dual exh. (9" long)	2 531920	
1960	2135-45, 2735	exc. dual exh.	1 536690	
1960	2135-45, 2735 All T425A	w/dual exh.	1 536690 LH	
1957	All	OUTLET AND PIPE ASSY., exhaust-simulated	2 528535	
1958	All	PORT, exhaust-simulated-w/dual exh.	530260 RH	530261 LH

Group 3.706 BRACKET-OUTLET-SUPPORT, MUFFLER TAIL PIPE

1956	All exc. 2762-63-64	CLAMP, tail pipe support-w/dual exhaust	2 522123	
1949	All exc. 2561-62-71	BRACKET	1 512565	
1957	All exc. 2762	CLIP, tail pipe rear support-w/dual exhaust	2 1464098	
1956	All exc. 2762-63-64	OUTLET ASSY., tail pipe-w/dual exhaust	2 522124	
1958	All	RETAINER, simulated exhaust port to rear bumper-w/dual exh.	2 530262	
1939-40	All exc. 29 and 1939 25	SUPPORT, tail pipe	1 502778	
1941	29 All		1 505290	
1941-48	25 All		1 502778	
1941-58	26-28 All exc. sta. wag.		1 505290	
1942-48	Sta. wag.		1 502778	
1949-52	2561-62-71 All		1 505290	
1949-54	All exc. 2561-62-71		1 512322	
1953	2562-71 All		1 516292	
1954	2562		1 518644	
1955	All exc. 2562-63-64		1 519012	
1955	2562-63-64 All		1 519740	
1956-57	All	w/dual exhaust Front	522812 LH	
1956	All exc. 2762-63-64	exc. dual exhaust	1 521699	
1956	2762-63-64 All	exc. dual exhaust	1 521992	
1956	2762DF-63F-64DF	w/dual exhaust	522432 RH	

1956	2762DF-63F-64DF	w/dual exhaust	Rear	521993	LH
1956	All exc. 2762-63-64	w/dual exhaust-at bumper	Rear	2	522125
1957	All exc. 2762	exc. dual exhaust		1	524801
1957	2762	exc. dual exhaust		1	523941
1957	2762FC	w/dual exhaust	Rear	528482	RH
1957	All exc. 2762-63	w/dual exhaust	Rear	2	523258
1957	2762DF-63F	w/dual exhaust	Rear	523946	RH
1958	All	tail pipe junction		529650	RH
1958	All	tail pipe junction-w/dual exh.			529650 LH
1959	All exc. 2135-45, 2735	tail pipe	Rear	534557	RH
1959	All exc. 2135-45, 2735	w/dual exhaust	Rear	2	534558 LH
1959-60	2135, 2735	exc. dual exh.	Rear	2	534558
1959-60	2135, 2735 All exc. T420A-T425A			1	534480
1959-60	2135-45, 2735 All exc. T420A	w/dual exh.	Rear	1	534481
1959-60	2135-45, 2735 All T420A-T425A	w/dual exh.	Rear		534482 LH
1959	2145	exc. dual exh.	Rear		531846 LH
1959	2145 All exc. T420A	w/dual exh.	Rear	1	534484
1959	2145-T420A	w/dual exh.	Rear		534485 RH
1959-60	2135-45, 2735	tail pipe junction		534484	RH
1959-60	All	muffler	Rear	534557	RH
1960	All exc. 2135-45, 2735	exc. dual exh.		534550	RH
1960	All exc. 2135-45, 2735	w/dual exh.		534557	RH
1960	2135, 2735 All T425A	w/dual exh.	Rear	2	534558 LH
1960	2145	exc. dual exh.	Rear	1	536698
1960	2145	w/dual exh.	Rear	1	536699

Group 3.708 CLAMP, MUFFLER

1933-55	All	to exhaust pipe		1	502392
1937-55	All exc. 1939 25	muffler support		1	499952
1956-60	All	to exhaust pipe-exc. dual exhaust		1	529521
1956-57	All	muffler support	AR		529519
1957	All	muffler support-w/dual exhaust			529520 LH
1958-60	All	muffler and tail pipe support-w/dual exhaust	AR		529520
1958-60	All	muffler tail pipe-exc. dual exh.	AR		529519
1958-60	All	muffler to exh. pipe-w/dual exh.		2	529519
1959-60	All T420A-T425A	to exhaust pipe-w/dual exh.		2	529521
1959-60	All T420A-T425A	muffler tail pipe-w/dual exh.		4	529519
1960	All exc. 2135-45, 2735	muffler tail pipe rear supt.-exc. dual exh.		1	535269
1960	All exc. 2135-45, 2735	muffler tail pipe rear supt.-w/dual exh.		1	535270
1960	All T425A	muffler tail pipe rear supt.-w/dual exh.			535269 LH
1956-59	All	U BOLT, muffler support	AR		521673
1956-60	All	to exhaust pipe-exc. dual exh.		1	529518
1959-60	All	muffler support-w/dual exhaust		2	521673
1957-59	All	muffler support-w/dual exhaust			(2-31/64" C. to C. of studs)
1959-60	All T420A-T425A	exhaust	AR		522429
1959-60	All T420A-T425A	to exhaust pipe-w/dual exh.		2	529518
1960	All	tail pipe support-w/dual exh.		4	521673
1960	All	tail pipe support-exc. dual exh.	AR		521673
1960	All	tail pipe support-w/dual exh.			(2-15/64" C. to C. of studs)

Group 3.724 GASKET PACKAGE, CARBURETOR

1940	28 All	(Carter 146)	1	7001334
1941-50	P/6	(Carter 146) w/426S, 494S, 537S, 717S & 718S carb.	1	7001334
1947	P/8	(Carter 190) used after 12388 engines used w/630S, SA & SB carb.	1	7001346

1948-54	P/8	(Carter 190) w/719S, SA, 720S, SA, 2122S carb.	1	7001346
1951-52	P/6	(Rochester) w/7002870 carb.	1	7009294
1953-54	P/6	(Carter 231)	1	7006044
1955	All	(Carter 254) 2207S, SB, 2182S, SA and SB carb.	1	7007949
1955	All 4 B.C.	(Carter 267)	1	7008364
1955-56	All 2 B.C.	(Rochester) w/7006100, 7008695 & 7008696 carb.	1	7009945
1955	All 4 B.C.	(Rochester) w/7007800 carb.	1	7009154
1956	All 4 B.C.	(Rochester) w/7007900 & 7008697 carb.	1	7009944
1956	All 4 B.C.	(Carter 279A)	1	7011922
1956	All 2/4 B.C.	(Rochester) w/7009820 & 7010600 carb.	2	7009952
1957	All 2 B.C.	(Rochester) w/7009831 & 7009832 carb.	2	7015963
1957-60	All 4 B.C.	(Carter 293A)	1	7017740
1957-60	All 3/2 B.C.	(Rochester) w/7011350, 7011500, 7011709, 7013064, 7013067, 7011706, 7015066, 7015068, 7015076 carb.	Center	1 7015962
1957-58	All 3/2 B.C.	(Rochester) w/7011351, 7011352, 7011705 & 7011707 carb.	Front and rear	2 7015753
1957-58	All 4 B.C.	(Rochester) w/7011701 carb.	1	7015849
1958-59	All 2 B.C., exc. T420E	(Rochester) w/7011702, 7011703, 7012702, 7012703, 7013060 & 7013061 carb.	1	7016041
1959	All 2 B.C.-T420E	(Rochester) w/7013069 & 7013075 carb.	1	7015962
1959-60	All 3/2 B.C.	(Rochester) w/7013063 & 7013065	Front and rear	1 7015957
1960	All S.T.-2 B.C. & T425E	(Rochester) w/7015062 & 7015073 carb.	1	7016043
1960	All H.T.-2 B.C., exc. T425E	(Rochester) w/7015070 & 7015072 carb.	1	7016041
1960	All H.T.-3/2 B.C.	(Rochester) w/7015076 carb.	Center	1 7016148

Group 3.725 CARBURETOR ASSEMBLY

1955	All H.T.-2 B.C.	(Rochester 7006100)	1	7006100
1955	All H.T.-4 B.C.	(Rochester 7007800)	1	7007800
1956	27 H.T.-2 B.C.	(Rochester 7008695)	1	7009907
1956	27 S.T.-2 B.C.	(Rochester 7008696)	1	7009908
1956	All H.T.-4 B.C.	(Rochester 7008697)	1	7009906
1956	All S.T.-4 B.C.	(Rochester 7007900)	1	7009905
1956	All S.T.-2/4 B.C.	(Rochester 7010600)	2	7010600
1956	All H.T.-2/4 B.C.	(Rochester 7009820)	2	7009820
1957	All H.T.-2 B.C.	(Rochester 7009831)	1	7015707
1957	All S.T.-2 B.C.	(Rochester 7009832)	1	7015708
1957	All H.T.-4 B.C.	(Rochester 7009830)	1	7015706
1957	All S.T.-4 B.C.	(Rochester 7009829)	1	7015705
1957	All H.T.-4 B.C.	(Carter 2506S)	1	523700
1957	All 3/2 B.C.	(Rochester 7011351)	Front	1 7011351
1957	All S.T.-3/2 B.C.	(Rochester 7011500)	Center	1 7011500
1957	All H.T.-3/2 B.C.	(Rochester 7011350)	Center	1 7011350
1957	All 3/2 B.C.	(Rochester 7011352)	Rear	1 7011352
1958	All S.T.-2 B.C.	(Rochester 7012703)	1	7015863
1958	All H.T.-2 B.C.	(Rochester 7012702)	1	7015862
1958	All S.T.-4 B.C.	(Carter AFB 2768S)	1	531416
1958	All H.T.-4 B.C.	(Carter AFB 2767S)	1	531417
1958	All H.T.-4 B.C.	(Rochester 7011701)	1	7015816
1958	All 3/2 B.C.	(Rochester 7011705)	Front	1 7011705
1958	All S.T.-3/2 B.C.	(Rochester 7011709)	Center	1 7011709
1958	All H.T.-3/2 B.C.	(Rochester 7011706)	Center	1 7011706
1958	All 3/2 B.C.	(Rochester 7011707)	Rear	1 7011707
1959	All S.T.-2 B.C. exc. T420E	(Rochester 7013061)	1	7015910
1959	All H.T.-2 B.C. exc. T420E	(Rochester 7013060)	1	7015909
1959	All S.T.-2 B.C.-T420E	(Rochester 7013075)	1	7015982
1959	All H.T.-2 B.C.-T420E	(Rochester 7013069)	1	7015958
1959	All S.T.-4 B.C.	(Carter AFB 2820S)	1	532301
1959	All H.T.-4 B.C.	(Carter AFB 2819S)	1	532302
1959-60	All 3/2 B.C.	(Rochester 7013063)	Front	1 7013063
1959	All S.T.-3/2 B.C.	(Rochester 7013067)	Center	1 7013067
1959	All H.T.-3/2 B.C.	(Rochester 7013064)	Center	1 7013064

1959-60	All 3/2 B.C.	(Rochester)	Rear	1	7013065
1960	All S.T.-2 B.C.	(Rochester)		1	7016010
1960	All H.T.-2 B.C. exc. T425E	(Rochester)		1	7016009
1960	All H.T.-2 B.C. T425E	(Rochester)		1	7016011
1960	All S.T.-4 B.C.	(Carter AFB 2975S)		1	536519
1960	All H.T.-4 B.C.	(Carter AFB 2976S)		1	536520
1960	All S.T.-3/2 B.C.	(Rochester)	Center	1	7015068
1960	All H.T.-3/2 B.C.	(Rochester)	Center	1	7015076

Group 3.725 REPAIR KIT, CARBURETOR (MAJOR OVERHAUL)

NOTE: Repair kits listed below consist of necessary parts to completely overhaul one carburetor.

1946-50	P/6 S.T.	(Carter 1366A) 46 thru 48 use w/537S carb.; 49-50 use w/717S carb.		1	7001370
1947-48	P/8 All	(Carter 1369) used after 12388 engines on 1947- used with 630S, SA, SB and 653S carb. on 1948		1	7001337
1949-54	P/8	(Carter 1507N) w/719-720, S and SA carb.		1	7012151
1948-50	P/6 H.T.	(Carter 1388A) w/652S carb. 1948 and 718S carb. 1949-50		1	7001371
1951-52	P/6	(Rochester)		1	7001392
1953-54	P/6	(Carter 1731)		1	7006045
1954	P/8	(Carter 1750) w/2122S carb.		1	7006549
1955	All 2 B.C.	(Rochester)		1	7009321
1955	All 4 B.C.	(Rochester)		1	7009153
1955	All H.T.-2 B.C.	(Carter 1777N) w/2182S, SA and SB carb.		1	7012153
1955	All S.T.-2 B.C.	(Carter 1778) w/2207S and SB carb.		1	7007952
1955	All H.T.-4 B.C.	(Carter 1796)		1	7008910
1956	All 2 B.C.	(Rochester)		1	7009925
1956	All 4 B.C.	(Rochester)		1	7009924
1956	All 4 B.C.	(Carter 1821N) w/2364S carb.		1	7012155
1956	All 2/4 B.C.	(Rochester)		2	7009932
1957	All 2 B.C.	(Rochester)		1	7015728
1957	All 4 B.C.	(Rochester)		1	7015725
1957	All 4 B.C.	(Carter 1852)		1	7011206
1957-58	All 3/2 B.C.	(Rochester)	Front and rear	2	7015832
1957-58	All S.T.-3/2 B.C.	(Rochester)	Center	1	7015830
1957	All H.T.-3/2 B.C.	(Rochester)	Center	1	7015735
1958	All 2 B.C.	(Rochester) w/7011702 and 7011703 carb.		1	7015821
1958	All 2 B.C.	(Rochester) w/7012702 and 7012703 carb.		1	7015856
1958	All 4 B.C.	(Carter 1935-N) w/2740S carb.		1	7012580
1958	All 4 B.C.	(Rochester)		1	7015835
1958	All H.T.-4 B.C.	(Carter 1946-N) w/2767S carb.		1	7012844
1958	All H.T.-3/2 B.C.	(Rochester)	Center	1	7015829
1959	All 2 B.C. exc. T420E	(Rochester)		1	7015929
1959	All 2 B.C.-T420E	(Rochester)		1	7015959
1959	All H.T.-4 B.C.	(Carter 1972N)		1	7015144
1959-60	All 3/2 B.C.	(Rochester)	Front and rear	2	7015939
1959	All S.T.-3/2 B.C.	(Rochester)	Center	1	7015931
1959	All H.T.-3/2 B.C.	(Rochester)	Center	1	7015930
1960	All S.T.-2 B.C. & T425E	(Rochester)		1	7016023
1960	All H.T.-2 B.C. exc. T425E	(Rochester)		1	7016021
1960	All S.T.-3/2 B.C.	(Rochester)	Center	1	7016025
1960	All H.T.-3/2 B.C.	(Rochester)	Center	1	7016024
1960	All 4 B.C.	(Carter 5017N)		1	7019363

Group 3.725 CLEANOUT KIT, CARBURETOR (MINOR REPAIR)

NOTE: Rochester Cleanout Kits consist of pump, needle and seat unit, air horn and stat. cover gaskets, clips, float gauge and cleaner.

Carter Cleanout Kits consist of pump, needle and seat unit, gasket set and float gauge.

1949-54	P/8	(Carter 900-17) exc. 2122 carb.		1	7016963
---------	-----	---------------------------------	--	---	---------

1954	P/8	(Carter 900-42) w/2122 carb.	1	7016965
1955	All 2 B.C.	(Carter 900-28)	1	7016964
1955	All 2 B.C.	(Rochester)	1	7018016
1955	All 4 B.C.	(Carter 900-43)	1	7016966
1955	All 4 B.C.	(Rochester)	1	7018054
1956	All 2 B.C.	(Rochester)	1	7018021
1956	All 4 B.C.	(Rochester)	1	7018051
1957	All 2 B.C.	(Rochester)	1	7018022
1957	All 4 B.C.	(Rochester)	1	7018055
1957-58	All 4 B.C.	(Carter 900-57)	1	7016967
1958-59	All 2 B.C. exc. T420E	(Rochester)	1	7018024
1958-59	All 4 B.C.	(Carter 900-74)	1	7016968
1959	All 2 B.C.-T420E	(Rochester)	1	7018025
1960	All H.T.-2 B.C. exc. T425E	(Rochester)	1	7018024
1960	All S.T.-2 B.C.-T425E	(Rochester)	1	7018025
1960	All 4 B.C.	(Carter 900-74A)	1	7019364

Group 3.726 GASKET, CARBURETOR TO MANIFOLD

1933-40	All exc. P/8 1940		1	504279
1940	28 All		1	504279
1940-46	P/8 exc. 1940 28		1	504601
1941-52	P/6		1	504279
1947-53	P/8	thin	1	509507
1953-54	P/6	thick	1	509506
1953-54	P/6	thin	1	509507
1954	P/8	thick	1	518568
1954	P/8	thin	1	518569
1955-56	All 2 B.C.		1	518189
1955	All 4 B.C.		1	521157
1956	All 4 B.C.		1	521241
1957-58	All 2 B.C.		1	523650
1957-58	All 3/2 B.C.		3	518569
1957-59	All 4 B.C.		1	524039
1959	All 2 B.C. exc. T420E		1	523650
1959	All 2 B.C.-T420E		1	518569
1959-60	All 4 B.C.		1	524039
1959	All 3/2 B.C.	Front and rear	2	523650
1959-60	All 3/2 B.C.	Center	1	518569
1960	All 2 B.C.		1	536477
1960	All 3/2 B.C.	Front and rear	2	536477
1957-60	All 2 B.C.	GASKET PKG., pos. crankcase vent. (type CV-298)	2	5646421
1957-60	All 3/2 B.C.	(type CV-329) Center	2	5646479
1959	All T420E	(type CV-329)	2	5646479
1959-60	All 3/2 B.C.	(type CV-298)	4	5646421
1957-60	All 4 B.C.	(type CV-294)	2	5646417

Group 3.729 BODY ASSY., CARBURETOR THROTTLE

1941-50	P/6 S.T.	(Carter 1-389S) used with 537S or 717S-1946 thru 50	1	7001475
1947-54	P/8 S.T.	(Carter 1-551S) w/630S, 719S & SA carb.	1	7001457
1948-50	P/6 H.T.	(Carter 1-560S) w/652S or 718S carb.	1	7001462
1948-54	P/8 H.T.	(Carter 1-559S) w/635S or 720S, & SA carb.	1	7001469
1951-52	P/6	(Rochester) w/7002870 Carb.	1	7003192
1953-54	P/6	(Carter 1-1070S)	1	7005913
1954	P/8	(Carter 1-1153S) w/2122S carb.	1	7006347
1955	All	(Carter 1-1187S) w/2182SB carb.	1	7007276
1955	All S.T.	(Carter 1-1230S) w/2207S carb.	1	7007277
1955	All 4 B.C.	(Carter 1-1282S)	1	7008342
1955	All 2 B.C.	(Rochester)	1	7001724
1955	All 4 B.C.	(Rochester)	1	7008491
1956	All 2 B.C.	(Rochester)	1	7009501

1956	All 4 B.C.	(Rochester)	1	7009456
1956	All 4 B.C.	(Carter 1-1337S)	1	7009558
1957	All S.T.-2 B.C.	(Rochester)	1	7010802
1957	All H.T.-2 B.C.	(Rochester)	1	7010905
1957	All H.T.-4 B.C.	(Rochester)	1	7010807
1957	All S.T.-4 B.C.	(Rochester)	1	7011064
1957	All 3/2 B.C.	(Rochester) Front	1	7011090
1957	All 3/2 B.C.	(Rochester) Center	1	7011638
1957	All 3/2 B.C.	(Rochester) Rear	1	7011639
1958	All S.T.-2 B.C.	(Rochester)-w/7011703 carb.	1	7012257
1958	All H.T.-2 B.C.	(Rochester)-w/7011702 carb.	1	7012256
1958	All S.T.-2 B.C.	(Rochester)-w/7012703 carb.	1	7012918
1958	All H.T.-2 B.C.	(Rochester)-w/7012702 carb.	1	7012917
1958	All 3/2 B.C.	(Rochester) Front	1	7012878
1958	All 3/2 B.C.	(Rochester) Center	1	7012269
1958	All 3/2 B.C.	(Rochester) Rear	1	7012170
1958	All 4 B.C.	(Rochester)	1	7012244
1959	All S.T.-2 B.C. exc. T420E	(Rochester)	1	7013557
1959	All H.T.-2 B.C. exc. T420E	(Rochester)	1	7013556
1959	All S.T.-2 B.C.-T420E	(Rochester)	1	7013813
1959	All H.T.-2 B.C.-T420E	(Rochester)	1	7015146
1959-60	All 3/2 B.C.	(Rochester) Front	1	7013561
1959	All S.T.-3/2 B.C.	(Rochester) Center	1	7013562
1959	All H.T.-3/2 B.C.	(Rochester) Center	1	7013813
1959-60	All 3/2 B.C.	(Rochester) Rear	1	7013563
1960	All S.T.-2 B.C. exc. T425E	(Rochester)	1	7016794
1960	All H.T.-2 B.C.	(Rochester) w/7015072 carb.	1	7019252
1960	All H.T.-2 B.C. exc. T425E	(Rochester)	1	7016793
1960	All H.T.-2 B.C. T425E	(Rochester)	1	7016795
1960	All S.T.-3/2 B.C.	(Rochester) Center	1	7016787
1960	All H.T.-3/2 B.C.	(Rochester) w/7015066 carb. Center	1	7016788
1960	All H.T.-3/2 B.C.	(Rochester) w/7015076 carb. Center	1	7017454
1957	All H.T.	THROTTLE BODY PKG., carburetor	1	7012600

Group 3.730 AIR HORN, CARBURETOR

1951-52	P/6	w/main well support	1	7003454
1955	All	(Carter 6-986S) w/2207S and 2182SB carb.	1	7007280
1955	All 2 B.C.	(Rochester)	1	7001722
1955	All 4 B.C.	(Rochester)	1	7008489
1955	All H.T.-4 B.C.	(Carter 6-1042S)	1	7008345
1955	All S.T.-4 B.C.	(Carter 6-1052S)	1	7009045
1956	All 2 B.C.	(Rochester)	1	7009460
1956	All 4 B.C.	(Rochester)	1	7009454
1956	All	(Carter 6-1137S) w/2364S carb.	1	7009755
1956	All	(Carter 6-1183S) w/2364SA)	1	7010461
1956	All S.T.-2/4 B.C.	(Rochester)	2	7010455
1956	All H.T.-2/4 B.C.	(Rochester)	2	7009868
1957	All 2 B.C.	(Rochester)	1	7010799
1957	All 4 B.C.	(Rochester)	1	7010804
1957	All 4 B.C.	(Carter 6-1266S)	1	7011136
1957-58	All 3/2 B.C.	(Rochester) Front	1	7011381
1957-58	All 3/2 B.C.	(Rochester) Center	1	7011380
1957-58	All 3/2 B.C.	(Rochester) Rear	1	7010962
1958	All 2 B.C.	(Rochester)	1	7016789
1958	All 4 B.C.	(Carter 6-1372S)	1	7012402
1958	All 4 B.C.	(Rochester)	1	7012242
1959	All 2 B.C. exc. T420E	(Rochester)	1	7016789
1959	All 2 B.C.-T420E	(Rochester)	1	7012444
1959-60	All 4 B.C.	(Carter 6-1400S)	1	7013751
1959-60	All 3/2 B.C.	(Rochester) Front	1	7013900
1959-60	All 3/2 B.C.	(Rochester) Center	1	7012444
1959-60	All 3/2 B.C.	(Rochester) Rear	1	7013885

All S.T.-2 B.C.	(Rochester)	1	7012444
All H.T.-2 B.C. exc. T425E .	(Rochester)	1	7016789
All H.T.-2 B.C. T425E	(Rochester)	1	7012444
All 3/2 B.C.	SCREW, carb. air horn-long Front and rear	2	855493

Group 3.730 AIR HORN AND CLIMATIC CONTROL ASSY., CARBURETOR

P/6	(Carter 6-532S)	1	7000423
P/8	(Carter 6-576S) w/630S, 630SA, 630SB and 653S carb.	1	7001477
P/8	(Carter 6-674S) w/719SA carb.	1	7002752
P/8	(Carter 6-675S) w/720S & 720SA carb.	1	7002753
P/6	(Carter 6-868S)	1	7005857
P/2	(Carter 6-958S) w/2122S carb.	1	7006383
P/8	SCREW AND WASHER, air horn		
P/6	(Carter 101-152S) (No. 10-32x15/16")	4	7000744
P/6	(Rochester) (No. 10-32x5/8")	4	7002879
P/6	(Rochester) (No. 8-32x1")	2	451910
P/6	(Carter 101-151S) (No. 10-32x15/16")	4	7000744
All 4 B.C.	(Carter 101-307S) (No. 10-32x5/8")	8	1346866
All 4 B.C.	(Carter 101-152S) (No. 10-30x15/16")	1	7000744
All 4 B.C.	(Carter 101-335S) (No. 10-32x1-1/4")	6	563126
All 2 B.C.	(Rochester) (No. 10-32x1-3/8")	1	426422
All 2 B.C.-3/2 B.C.	(Rochester) (No. 10-32x15/16")	7	7006119
All H.T.-4 B.C.	(Rochester) (No. 10-32x3/4")	13	7000249
All 4 B.C.	(Rochester) (No. 8-32x1")	6	451910
All 4 B.C.	(Rochester) (No. 10-32x3/4")	13	7000249
All 2 B.C.-3/2 B.C.	(Rochester) (No. 10-32x1-3/8")	AR	7010432
All 4 B.C.	(Carter 101-362S)	8	1461360
All 4 B.C.	(Carter 101-431S)	1	7011180
P/8	SCREW AND WASHER, bowl cover to bowl (Carter 101-160S) (No. 10-32x9/16")	6	7000745
P/6	main well support (No. 10-32x5/8")	1	7002879
P/6	(Carter 101-160S) (No. 10-32x9/16")	6	7000745

Group 3.731 GASKET, CARB. AIR HORN TO FLOAT BOWL COVER

P/8	(Carter 121-80)	1	7000688
P/6	(Carter 121-80)	1	7000688
	GASKET (see Group 3.738 for use)		3721037

Group 3.732 COVER, CARBURETOR DUST

P/8	(Carter 118-39)	1	7000685
P/6	(Carter 118-39)	1	7000685
All 4 B.C.	(Carter 118-116)	1	7008358
All	(Carter 118-102S) w/2364S and 2364 SA carb.	1	566252
P/8	GASKET, cover (Carter 121-116) w/630S carb.)	1	7000756
P/8	SCREW AND WASHER		
	(Carter 101-161S) (No. 10-32x3/8")	2	7000746

Group 3.734 BOWL ASSY., CARBURETOR FLOAT

All 4 B.C.	(Rochester)	1	7009455
All 2/4 B.C.	(Rochester)	2	7009873

1957	All 4 B.C.	(Rochester)	1	7010805
1957-58	All 3/2 B.C.	(Rochester) Front and rear	2	7011088
1957	All 3/2 B.C.	(Rochester) Center	1	7011637
1958	All S.T.-2 B.C.	(Rochester)-w/7011703 carb.	1	7012255
1958	All H.T.-2 B.C.	(Rochester)-w/7011702 carb.	1	7012254
1958	All S.T.-2 B.C.	(Rochester)-w/7012703 carb.	1	7012916
1958	All H.T.-2 B.C.	(Rochester)-w/7012702 carb.	1	7012915
1958	All 3/2 B.C.	(Rochester) Center	1	7012397
1958	All 4 B.C.	(Rochester)	1	7013791
1959	All S.T.-2 B.C. exc. T420E	(Rochester)	1	7013907
1959	All H.T.-2 B.C. exc. T420E	(Rochester)	1	7013672
1959	All S.T.-2 B.C.-T420E	(Rochester)	2	7015575
1959	All H.T.-2 B.C.-T420E	(Rochester)	1	7015145
1959-60	All 3/2 B.C.	(Rochester) Front and rear	2	7013552
1959	All S.T.-3/2 B.C.	(Rochester) Center	1	7013673
1959	All H.T.-3/2 B.C.	(Rochester) Center	1	7013734
1960	All S.T.-2 B.C. exc. T425E	(Rochester)	1	7016791
1960	All H.T.-2 B.C.	(Rochester) w/7015070 carb.	1	7016790
1960	All H.T.-2 B.C. T425E	(Rochester)	1	7016792
1960	All H.T.-2 B.C.	(Rochester) w/7015072 carb.	1	7019620
1960	All S.T.-3/2 B.C.	(Rochester) Center	1	7016786
1960	All H.T.-3/2 B.C.	(Rochester) w/7015066 carb. Center	1	7016688
1960	All H.T.-3/2 B.C.	(Rochester) w/7015076 carb. Center	1	7017453

Group 3.735 GASKET, CARB. THROTTLE BODY

1941-50	P/6 S.T.	(Carter 121-72) w/537S carb.	1	1875150
1947-54	P/8	(Carter 121-79) to bowl	1	7000689
1951-52	P/6	(Rochester) to bowl	1	7002156
1953-54	P/6	(Carter 121-79) to bowl	1	7000689
1955	All	(Carter 121-240) w/2207S and 2182SB carb.	1	566018
1955-56	All 2 B.C.	(Rochester) to bowl	1	7000298
1955	All 4 B.C.	(Rochester)	1	7006887
1955	All 4 B.C.	(Carter 121-249)	1	566254
1956	All 4 B.C.	(Rochester)	1	7009762
1956	All 4 B.C.	(Carter 121-277)	1	1465398
1956	All 2/4 B.C.	(Rochester)	2	7009256
1957	All 2 B.C.	(Rochester) to bowl	1	7015345
1957	All 4 B.C.	(Rochester) to bowl	1	7010356
1957	All 4 B.C.	(Rochester) to bowl-w/by-pass idle type throttle body	1	7013580
1957-59	All 3/2 B.C.	(Rochester)	3	7015148
1958	All 2 B.C.	(Rochester) to bowl-w/7011702 and 7011703 carb.	1	7015345
1958	All 2 B.C.	(Rochester) to bowl-w/7012702 and 7012703 carb.	1	7015106
1958	All 4 B.C.	(Rochester) to bowl	1	7013580
1959	All 2 B.C.-3/2 B.C. exc. T420E	(Rochester) to bowl Front and rear	2	7015106
1959	All 2 B.C.-T420E	(Rochester)	1	7015148
1960	All S.T.-2 B.C.	(Rochester)	1	7015148
1960	All H.T.-2 B.C. exc. T425E	(Rochester)	1	7015106
1960	All H.T.-2 B.C. T425E	(Rochester)	1	7015148
1960	All 3/2 B.C.	(Rochester) to bowl Front and rear	2	7015106
1960	All 3/2 B.C.	(Rochester) exc. 7015076 carb. Center	1	7015148
1960	All H.T.-3/2 B.C.	(Rochester) w/7015076 carb. Center	1	7013680

Group 3.737 COVER, CARBURETOR FLOAT BOWL

1949-54	P/8	(Carter 146-184S) w/719, 720, S & SA, 2122S carb.	1	7001869
1953-54	P/6	(Carter 146-218S)	1	7005879
1957	All F.I.	COVER, fuel meter	1	7014816
1958	All F.I.	fuel meter	1	7017070

1958	All F.I.	SCREEN, fuel meter external vent	1	7017041
1957-58	All F.I.	SCREW, fuel meter cover (No. 10-32x3/8")	3	7014270
1957-58	All F.I. (3.308)	fuel meter cover (No. 10-32x5/8")	2	7014280
1957	All F.I. (3.786)	fuel meter cover and mtg. bracket (No. 8-32x1")	4	7010421
1958	All F.I.	fuel meter mounting	6	7014863

Group 3.738 GASKET, CARB. BOWL COVER TO FLOAT BOWL

1947-54	P/8	(Carter 121-81)	1	7000690
1951-52	P/6	(Rochester)	1	7003191
1953-54	P/6	(Carter 121-233)	1	7005876
1955-56	All 2 B.C.	(Rochester)	1	7008600
1955	All H.T.-4 B.C.	(Rochester)	1	7006061
1955-56	All 4 B.C. (3.731)	(Carter 121-265)	1	3721037
1955	All	(Carter 121-155) w/2207S and 2182SB carb.	1	560933
1956-58	All 4 B.C.	(Rochester)	1	7006061
1957-59	All 2 B.C.	(Rochester)	1	7015128
1957-60	All 4 B.C.	(Carter 121-292)	1	1179331
1957-58	All 3/2 B.C.	(Rochester)	3	7008600
1959	All 2 B.C.-T420E	(Rochester)	1	7008600
1959-60	All 3/2 B.C.	(Rochester) Front and rear	2	7015128
1959	All 3/2 B.C.	(Rochester) Center	1	7008600
1960	All S.T.-2 B.C.	(Rochester)	1	7017405
1960	All H.T.-2 B.C. exc. T425E	(Rochester)	1	7015128
1960	All H.T.-2 B.C. T425E	(Rochester)	1	7017405
1960	All 3/2 B.C.	(Rochester) Center	1	7017405
1957-58	All F.I.	GASKET, fuel meter cover	1	7014909

Group 3.740 STRAINER PARTS, CARBURETOR BOWL COVER

1957	All F.I.	CUP, fuel meter fuel inlet	1	7014128
1939-50	All	GASKET, strainer nut (Carter 20-35)	1	1875030
1951-55	P/8	(Carter 20-35)	AR	1875030
1953-54	P/6	(Carter 20-35)	1	1875030
1951-52	P/6	(Rochester)	1	7001597
1955	All H.T.-2 B.C.-4 B.C.	(Rochester)	1	7001597
1955-56	All 4 B.C. (3.858)	fuel valve (Rochester)	2	7001613
1956-58	All 2 B.C.-4 B.C.	(Rochester) strainer nut	1	7001597
1956	All 4 B.C.	(Carter 20-127)	2	7010634
1959	All 2 B.C. exc. T420E	strainer nut (Rochester)	1	7001597
1957-60	All 4 B.C.	fuel inlet fitting (Carter 20-127)	1	7010634
1960	All H.T.-2 B.C. exc. T425E	strainer nut (Rochester)	1	7001597
1957-58	All F.I.	FITTING, air meter idle signal vacuum	1	7006854
1951-52	P/6	NUT, strainer	1	7002862
1955	All H.T.-2 B.C.-4 B.C.	(Rochester)	1	7002862
1956-58	All 2 B.C.-4 B.C.	(Rochester)	1	7002862
1957-58	All 4 B.C.	carb. fuel inlet (Carter 15-52S)	1	7011146
1959	All 2 B.C.	strainer (Rochester)	1	7013314
1959-60	All 4 B.C.	carb. fuel inlet (Carter 15-68S)	1	7013755
1960	All H.T.-2 B.C. exc. T425E	strainer (Rochester)	1	7013314
1939-50	All	NUT AND GASKET (Carter 15-35S)	1	1875025
1951-55	P/8	(Carter 15-35S)	AR	1875025
1953-54	P/6	(Carter 15-35S)	1	1875025
1956	All 4 B.C.	(Carter 15-63S)	2	7010635
1939-54	All	STRAINER, fuel inlet (Carter 30-14)	1	342139
1955-56	All	(Carter 30-75)	1	566009
1955-59	All 2 B.C.	(Rochester)	1	7000261
1955	All H.T.-4 B.C.	(Rochester)	1	7003083
1956-58	All 4 B.C.	(Rochester)	1	7003083

1957-60	All 4 B.C.	(Carter 30-78)	1	7011151
1955-56	All 4 B.C.	needle and seat fuel-primary (Carter 30-73)	1	565213
1955-56	All 4 B.C.	needle and seat fuel-secondary (Carter 30-74)	1	565214
1955	All H.T.-4 B.C.	fuel valve (Rochester)	2	7006079
1956	All 4 B.C.	fuel valve (Rochester)	1	7006079
1957-58	All 2 B.C.-4 B.C.	fuel valve (Rochester)	1	7006079
1959-60	All 3/2 B.C.	needle and seat fuel (Rochester)	2	7013249
1959-60	All 2 B.C.-3/2 B.C.	fuel valve (Rochester)	1	7006079
1960	All H.T.-2 B.C. exc. T425E	fuel inlet (Rochester)	1	7000261
1957	All F.I.	SCREW, fuel meter inlet		
		cup (Truss Hd. No. 6-32x5/16")	1	7010434

Group 3.741 SCREW AND WASHER, CARB. THROTTLE BODY

1947-54	P/8	to float bowl (Carter 101-149S)	4	7000650
1951-52	P/6	to float bowl (5/16"-24x1-1/8")	1	7002877
1953-54	P/6	to float bowl (Carter 101-149S)	4	7000650
1955	All	to float bowl (Carter 101-353S) w/2207S and 2182SB carb.	2	566013
1955-60	All 2 B.C.-3/2 B.C.	(Rochester) to float bowl (No. 12-28x13/16")	AR	7015105
1955	All H.T.-4 B.C.	(Rochester) (3/8"-24x1-1/8")	1	7004324
1955-56	All 4 B.C.	(Carter 101-149S) (No. 12-28x3/4")	1	7000650
1955-56	All 4 B.C.	(Carter 101-382S) (No. 12-28x1")	3	3721034
1956-58	All 4 B.C.	(Rochester) (3/8"-24x1-1/8")	1	7004324
1955-56	All 4 B.C.	(Carter 101-298S) (No. 10-32x1-1/16")	2	3721033
1955-60	All (8.931)	WASHER, throttle body screw (No. 12)	3	121744
		SCREW (see Group 3.730 for use)		7000745

Group 3.745 FLOAT, CARBURETOR

1946-50	P/6	(Carter 21-86S)	1	7000393
1947-54	P/8	(Carter 21-80S)	1	7000676
1951-52	P/6	(Rochester)	1	7002672
1955	All	(Carter 21-113S) w/2207S and 2182SB carb.	1	7002445
1955	All 4 B.C.	(Carter 21-146S)	2	563884
1955-58	All 2 B.C.	(Rochester)	1	7000273
1955-56	All 4 B.C.	(Rochester)	2	7000199
1956	All 4 B.C.	primary (Carter 21-146S)	1	563884
1956	All 4 B.C.	secondary (Carter 21-168S)	1	7009566
1957	All 4 B.C.	(Rochester)	1	7010064
1957-60	All 4 B.C.	(Carter 21-179S)	2	7011148
1958-60	All 2 B.C.	(Rochester)	1	7012028
1958	All 4 B.C.	primary (Rochester)	1	7011945
1958	All 4 B.C.	secondary (Rochester)	1	7012148
1958-60	All 3/2 B.C.	(Rochester)	1	7012028
1958-60	All 3/2 B.C.	(Rochester)	1	7000273
1957	All F.I.	FLOAT, fuel meter	1	7014180
1958	All F.I.		1	7014914
1953-54	P/6	FLOAT AND LEVER PKG. (Carter 21-150U)	1	7005861
1953-54	P/6	LEVER, auxiliary float (Carter 22-67)	1	7005862
1957-58	All 4 B.C.	SPRING AND CLIP ASSY., carb. float balance-secondary (Rochester)	1	7001850

Group 3.747 PIN, CARBURETOR FLOAT LEVER

1940-54	P/8 exc. 1940 28	(Carter 24-24)	1	1875363
1951-52	P/6	(Rochester)	1	7002081

1953-54	P/6	(Carter 24-29)	1	7005863
1955	All	(Carter 24-24) w/2207S and 2182SB carb.	1	1875363
1955-56	All 4 B.C.	(Carter 24-24)	2	1875363
1955-56	All 2 B.C.	(Rochester)	1	7002081
1955	All H.T.-4 B.C.	(Rochester)	2	7001595
1956-58	All 4 B.C.	(Rochester)	2	7001595
1957-58	All 2 B.C.	(Rochester)	1	7010037
1957-60	All 4 B.C.	(Carter 24-29)	2	7005863
1957-58	All 3/2 B.C.	(Rochester)	3	7002081
1959	All 2 B.C. exc. T420E	(Rochester)	1	7010037
1959	All 2 B.C.-T420E	(Rochester)	1	7002081
1959-60	All 3/2 B.C.	(Rochester) Front and rear	2	7010037
1959-60	All 3/2 B.C.	(Rochester) Center	1	7002081
1960	All S.T.-2 B.C.	(Rochester)	1	7002081
1960	All H.T.-2 B.C. exc. T425E	(Rochester)	1	7010037
1960	All H.T.-2 B.C.-T425E	(Rochester)	1	7002081
1957	All F.I.	PIN, fuel meter float hinge	1	7014124
1958	All F.I.		1	7014920

Group 3.750 HOUSING AND COIL ASSY., CARB. THERMOSTATIC

1940-50	P/6	(Carter 170F-64S)	1	1875425
1947-54	P/8	(Carter 170N-77S)	1	7000611
1953-54	P/6	(Carter 170N-77S)	1	7000611
1955	All	(Carter 170AM-347S) w/2207S and 2182SB carb.	1	7007289
1955-56	All 4 B.C.	(Carter 170AM-374S)	1	7008362
1957-58	All H.T.-4 B.C.	(Carter 170X-478S)	1	7011587
1958	All S.T.-4 B.C.	(Carter 170N-478S) w/2751S and 2768S carb.	1	7012785
1959	All 4 B.C.	(Carter 170X-478S)	1	7011587
1960	All 4 B.C.	(Carter 170AD-478S)	1	1188587
1951-52	P/6	COVER AND COIL ASSY., carb. thermostatic w/gasket	1	7003453
1955	All 2 B.C.	(Rochester) w/gasket	1	7007118
1955	All 4 B.C.	(Rochester) w/gasket	1	7008492
1956	All 2 B.C.	(Rochester) w/gasket	1	7003071
1956	All 4 B.C.	(Rochester) w/gasket	1	7009457
1956	All 2/4 B.C.	(Rochester) w/gasket	2	7009872
1957	All 2 B.C.	(Rochester) w/gasket	1	7010803
1957	All S.T.-4 B.C.	(Rochester) w/gasket	1	7010806
1957	All H.T.-4 B.C.	(Rochester) w/gasket	1	7011063
1957-60	All S.T.-3/2 B.C.	(Rochester) w/gasket Center	1	7011636
1957-60	All H.T.-3/2 B.C.	(Rochester) w/gasket Center	1	7011635
1958	All H.T.-2 B.C.	(Rochester) w/gasket	1	7012837
1958	All S.T.-2 B.C.	(Rochester) w/gasket-w/7011703 carb.	1	7012477
1958	All S.T.-2 B.C.	(Rochester) w/gasket-w/7012703 carb.	1	7010803
1958	All 4 B.C.	(Rochester) w/gasket	1	7013790
1959	All S.T.-2 B.C. exc. T420E	(Rochester) w/gasket	1	7010803
1959-60	All H.T.-2 B.C. exc. T420E-T425E	(Rochester) w/gasket	1	7012837
1959	All S.T.-2 B.C.-T420E	(Rochester) w/gasket	1	7011636
1959-60	All H.T.-2 B.C.-T420E-T425E	(Rochester) w/gasket	1	7011635
1960	All S.T.-2 B.C.	carb. thermostatic (Rochester)-w/gasket	1	7011636
1957	All F.I.	COVER AND THERMOSTAT PKG., air meter cold enrichment	1	7014884
1958	All F.I.		1	7014989
1937-47	All	GASKET, coil housing (Carter 121-74) with single carb.	1	1875423
1947-56	P/8	(Carter 121-78)	1	7000610
1953-54	P/6	(Carter 121-78)	1	7000610
1957-58	All 4 B.C.	(Carter 121-78)	1	7000610
1959-60	All 4 B.C.	(Carter 121-78)	1	7000610
1951-52	P/6	GASKET, choke cover	1	7002760

1955	P/8 H.T.-2 B.C.-4 B.C.	(Rochester)	1	7002760
1956-60	All	(Rochester)	1	7002760
1951-52	P/6	GASKET, choke housing to air horn	1	7002841
1955	All	(Carter 20-43) w/2207S and 2182SB carb.	1	1423131
1955-56	All	(Carter 121-243) w/2268S, 2283S and 2364S carb.	1	565215
1955-58	All 2 B.C.-4 B.C.	(Rochester)	1	7007502
1956	All	(Carter 121-283) w/2364SA carb.	1	1175241
1957-58	All	(Carter 20-43)	1	1423131
1959-60	All 4 B.C.	(Carter 20-43)	1	1423131
1959-60	All	(Rochester)	1	7007502
1957	All F.I.	GASKET, air meter cold enrichment housing	1	7014589
1958	All F.I.	air meter cold enrichment housing	1	7017005
1951-52	P/6	HOUSING ASSY., carb. choke	1	7002836
1955	All	(Carter 170-351S) w/2207S and 2182SB carb.	1	7007288
1955	All 4 B.C.	(Carter 170-370S)	1	7008361
1955	All 2 B.C.	(Rochester)	1	7006841
1955	All 4 B.C.	(Rochester)	1	7007894
1956	All 2 B.C.	(Rochester)	1	7009789
1956	All 4 B.C.	(Rochester)	1	7013101
1956	All	(Carter 170-416S) w/2364S carb.	1	7009579
1956	All	(Carter 170-452S) w/2364SA carb.	1	7010462
1956	All 2/4 B.C.	(Rochester)	2	7009288
1957-58	All 2 B.C.	(Rochester)	1	7010047
1957	All 4 B.C.	(Rochester)	1	7010218
1957-58	All 4 B.C.	(Carter 170-494S) (Casting 170-491) w/2506S, 2740S, 2751S and 2767S carb.	1	7011200
1957	All 3/2 B.C.	(Rochester)	Center	1 7011483
1958	All 3/2 B.C.	(Rochester)	Center	1 7012183
1958	All H.T.-4 B.C.	(Carter 170-555S) (Casting 170-553) w/2767S, SA and 2768S carb.	1	7013362
1958	All 4 B.C.	(Rochester)	1	7013305
1959	All 2 B.C. exc. T420E	(Rochester)	1	7010047
1959	All 2 B.C.-T420E	(Rochester)	1	7013675
1959-60	All 4 B.C.	(Carter 170-555S) (Casting 170-553)	1	7013362
1959	All 3/2 B.C.	(Rochester)	Center	1 7013675
1960	All H.T.-2 B.C. exc. T425E	(Rochester)	1	7016161
1960	All S.T.-2 B.C. & T425E	(Rochester)	1	7016386
1960	All 3/2 B.C.	(Rochester)	Center	1 7016082
1957	All F.I.	HOUSING ASSY., air meter cold enrichment	1	7014627
1958	All F.I.		1	7017007
1951-52	P/6	PACKING, carb. choke suction tube	1	7002883
1947-54	P/8	PLATE, coil housing baffle (Carter 186-15)	1	7000609
1953-54	P/6	(Carter 186-15)	1	7000609
1955	All	(Carter 186-48S) w/2207S and 2182SB carb.	1	7007291
1955-56	All 4 B.C.	(Carter 186-51S)	1	7008363
1955	All H.T.-2 B.C.-4 B.C.	(Rochester)	1	7006643
1956	All	(Rochester)	1	7006643
1957-58	All 2 B.C.	(Rochester)	1	7010598
1957-58	All 4 B.C.	(Rochester)	1	7006643
1957-59	All 4 B.C.	(Carter 186-67S)	1	7011203
1959-60	All 2 B.C.-3/2 B.C.	(Rochester)	1	7010598
1960	All 4 B.C.	(Carter 186-90S)	1	7016863
1955-60	All	PLUG, choke housing expansion		
		(Rochester) (5/8" dia.)	1	7003135
1940	28 All	RETAINER, housing (Carter 63-48)	2	1875400
1940-50	P/6	(Carter 63-48)	3	1875400
1947-54	P/8	(Carter 63-58)	3	7000614
1951-54	P/6	(Carter 63-58)	3	7000614
1955-56	All	(Carter 63-58)	3	7000614
1955	All H.T.-2 B.C.-4 B.C.	(Rochester)	1	7006846
1955-58	All 2 B.C.-4 B.C.	(Rochester)	AR	7000614
1956	All	(Rochester)	1	7006846
1957-58	All 4 B.C.	(Rochester)	1	7006846

1957-58	All 4 B.C.	(Carter 63-58)	3	7000614
1959-60	All 4 B.C.	(Carter 63-58)	3	7000614
1959-60	All 2 B.C.-3/2 B.C.-T420E-T425E	(Rochester)	3	7000614
1957-58	All F.I.	RETAINER, air meter cold enrichment cover	3	7014544
1955	All	SCREW, retainer (Carter 101-274) w/2207S and 2182SB carb.	3	7002480
1955-60	All 4 B.C. (8.907)	(Carter 101-136) (No. 8-32x1/4")	3	131954
1955-60	All (8.907)	(Rochester) (No. 8-32x5/16")	3	131958
1957	All F.I. (8.907)	SCREW, air meter cold enrichment cover (No. 8-32x5/16")	3	131958
1958	All F.I. (8.907)	air meter cold enrichment cover (No. 8-32x1/4")	3	131954
1951-52	P/8	SCREW, choke housing attachment (No. 8-32x9/16")	2	7005654
1955	All	(Carter 101-284) w/2182SB and 2207S carb.	3	560926
1955-58	All	(Rochester) (No. 8-32x13/16")	2	7019516
1956	All 4 B.C.	(Carter 101-363)	2	1165640
1956	All 4 B.C.	(Carter 101-275)	1	7002481
1957-58	All 2 B.C.	(Rochester)	1	7019776
1957-60	All 4 B.C.	(Carter 101-436)	3	1179316
1959	All 2 B.C. exc. T420E	choke housing (Rochester) (No. 8-32x1-1/16")	2	7019776
1959-60	All H.T.-2 B.C.-T420E-T425E	choke housing (Rochester) (No. 8-32x13/16")	2	7019516
1959-60	All 3/2 B.C.	choke housing (Rochester)-Center (No. 8-32x13/16")	2	7019516
1960	23, 25, 26 All S.T.-2 B.C.	(Rochester) (No. 8-32x13/16")	2	7019516
1960	All H.T.-2 B.C. exc. T425E	choke housing (Rochester)	1	7019776
1957-58	All F.I.	SCREW, air meter cold enrichment housing (No. 8-32x3/8")	2	7011270
1955-56	All 4 B.C.	STAND PIPE, carb. float bowl (Carter 145-142)	1	3732788
1951-52	P/6	TUBE AND SEAL ASSY., carb. choke suction	1	7002881

Group 3.751 VALVE, CARBURETOR CHOKE

1946-50	P/6	(Carter 7-144)	1	7000424
1947-48	P/8	(Carter 7-145) w/630S, SA, SB and 653S carb.	1	7000608
1949-50	P/8	(Carter 7-145) w/719S carb.	1	7000608
1949-50	P/8	(Carter 7-156) w/720S carb.	1	7001863
1950-53	P/8	(Carter 7-166) w/719SA carb.	1	7002746
1950-54	P/8	(Carter 7-167) w/719SA, 720SA and 2122S carb.	1	7005916
1951-52	P/6	(Rochester)	1	7002086
1953-54	P/6	(Carter 7-187) w/2010S carb.	1	7005916
1955	All	(Carter 7-185) w/2207S and 2182SB carb.	1	566004
1955-56	All 4 B.C.	(Carter 7-173)	1	1346547
1955-56	All 2 B.C.	(Rochester)	1	7007151
1955	All H.T.-4 B.C.	(Rochester)	1	7000191
1956-58	All 4 B.C.	(Rochester)	1	7000191
1957-58	All 2 B.C.	(Rochester)	1	7010035
1957-58	All 4 B.C.	(Carter 7-218)	1	7011137
1957-60	All 3/2 B.C.	(Rochester) Center	1	7007151
1959	All 2 B.C. exc. T420E	(Rochester)	1	7010035
1959	All 2 B.C.-T420E	(Rochester)	1	7007151
1959-60	All 4 B.C.	(Carter 7-235)	1	7013752
1960	All H.T.-2 B.C. exc. T425E	(Rochester)	1	7010035
1960	All S.T.-2 B.C. & T425E	(Rochester)	1	7007151
1939-50	All	SCREW, choke valve (Carter 39-10) (No. 3-48x3/16")	2	838959
1951-54	P/8	(Carter 39-10) (No. 3-48x3/16")	2	838959
1951-52	P/6	(Rochester) (No. 6-32x9/32")	2	7007627
1953-54	P/6	(Carter 39-10) (No. 3-48x3/16")	2	838959
1955	All	(Carter 39-10) w/2207S and 2182SB carb. (No. 3-48x3/16")	2	838959
1955-60	All 4 B.C. (3.761)	(Carter 39-11) (No. 3-48x7/32")	2	342146
1955-60	All 2 B.C.-4 B.C.	(Rochester) (No. 6-32x9/32")	2	7007627

Group 3.752 SHAFT, LEVER AND LINK ASSY., CARBURETOR CHOKE

1939-50	P/6	(Carter 14-222S) w/494S carb. on 1942	1	1875238
1947-50	P/8	(Carter 14-344S) w/630S, SA, SB, 653S, 719S and 720S carb.	1	7000604
1950-54	P/8	(Carter 14-401S) w/719-720, SA carb.	1	7002749
1951-52	P/6	(Rochester)	1	7002850
1953-54	P/6	(Carter 14-401S)	1	7002749
1955	All	(Carter 14-470S) w/2207S and 2182SB carb.	1	566007
1955-56	All 4 B.C.	(Carter 14-439S)	1	1346550
1955-56	All 2 B.C.	(Rochester)	1	7000253
1955	All 4 B.C.	(Rochester)	1	7007891
1956	All 4 B.C.	(Rochester)	1	7008185
1957-60	All 3/2 B.C.	(Rochester) Center	1	7011511
1959	All 2 B.C.-T420E	(Rochester)	1	7011511
1957-59	All 2 B.C.	SHAFT AND LEVER, carb. choke (Rochester)	1	7010032
1957-58	All 4 B.C.	(Rochester)	1	7007143
1957	All 4 B.C.	(Carter 14-582S)	1	7011540
1958	All 4 B.C.	(Carter 14-568S) w/2740S, 2751S and 2767S carb.	1	1470446
1959-60	All 4 B.C.	(Carter 14-605S)	1	1182810
1960	All H.T.-2 B.C. exc. T425E	(Rochester)	1	7010032
1957-59	All 2 B.C.	SHAFT AND LEVER, intermediate choke		
		(Rochester)	1	7010048
1957-58	All 4 B.C.	(Rochester)	1	7007503
1957	All 4 B.C.	(Carter 113-42S)	1	7011186
1958	All 4 B.C.	(Carter 113-48S) w/2740S, 2751S and 2767S carb. (▲)	1	1182813
1958-60	All 4 B.C.	(Carter 14-612S) w/2767S, SA, 2768S, 2820S, 2975S and 2976S carb. (▲▲)	1	1472185
1960	All H.T.-2 B.C. exc. T425E	(Rochester)	1	7010048
1937-40,				
1947-50	All exc. 1940 29	PISTON (Carter 160-35)	1	1875075
1941-46	P/6	(Carter 160-35)	1	1875075
1951-54	P/8	(Carter 160-35)	1	1875075
1951-52	P/6		1	7002853
1953-54	P/6	(Carter 160-35)	1	1875075
1955	All	(Carter 160-35) w/2207S and 2182SB carb.	1	1875075
1955-56	All	(Carter 160-138) w/2268S, 2364S and 2364SA carb.	1	7008360
1955	All	(Carter 160-91) w/2283S carb.	1	1457554
1955	All 2 B.C.	(Rochester)	1	7009032
1955	All 4 B.C.	(Rochester)	1	7009062
1956	All 2 B.C.	(Rochester)	1	7009092
1956	All 4 B.C.	(Rochester)	1	7009710
1957-58	All 2 B.C.	(Rochester)	1	7010522
1957	All 4 B.C.	(Rochester)	1	7008186
1957-58	All 4 B.C.	(Carter 160-168)	1	7011621
1957-58	All 3/2 B.C.	(Rochester) Center	1	7011799
1958	All 4 B.C.	(Rochester)	1	7012048
1959	All 2 B.C. exc. T420E	(Rochester)	1	7010522
1959	All 2 B.C.-T420E	(Rochester)	1	7013888
1959	All 4 B.C.	(Carter 160-199)	1	7013765
1959-60	All 3/2 B.C.	(Rochester) Center	1	7013888
1960	All H.T.-2 B.C. exc. T425E	(Rochester)	1	7010522
1960	All S.T.-2 B.C.	(Rochester)	1	7013888
1960	All S.T.-4 B.C.	(Carter 160-199)	1	7013765
1960	All H.T.-4 B.C.	(Carter 160-214)	1	7017538
1960	All 3/2 B.C.	(Rochester) Center	1	7013888
1946-50	All	PIN, choke piston (Carter 150-62)	1	1875069
1951-56	P/8	(Carter 150-62)	1	1875069
1951-52	P/6	(Rochester)	1	7002854
1953-54	P/6	(Carter 150-62)	1	1875069
1955-56	All 2 B.C.-4 B.C.	(Rochester)	1	7004748
1957	All 2 B.C.-4 B.C.	(Rochester)	1	7002854

1957-60	All 4 B.C.	(Carter 150-190)	1	1172252
1958	All 2 B.C.	(Rochester)	1	7002854
1958	All 4 B.C.	(Rochester)	1	7010746
1959-60	All 2 B.C.-3/2 B.C.	(Rochester)	1	7010746
1951-54	All	CLIP, choke rod end	1	7003137
1957-58	All (3.762)	(Rochester)-intermediate choke rod	1	7005109
1959	All 2 B.C. (3.762)	(Rochester)	1	7005109
1960	All H.T.-2 B.C. exc. T425E (3.762)	(Rochester)	1	7005109
1960	All S.T.-2 B.C. & T425E	KIT, carb. choke link (Rochester)	1	7019563
1960	All H.T.-2 B.C. exc. T425E	(Rochester)	1	7019562
1960	All 3/2 B.C.	(Rochester) Center	1	7019564
1951-52	P/6	LEVER AND COLLAR ASSY., carb. choke	1	7002860
1955	All 2 B.C.	(Rochester)	1	7006616
1955	All 4 B.C.	(Rochester)	1	7006837
1956-60	All 2 B.C.	(Rochester)	1	7009248
1956-58	All 4 B.C.	(Rochester)	1	7008547
1959-60	All 3/2 B.C.	(Rochester) Center	1	7009248
1957	All F.I.	LEVER AND COLLAR ASSY., air meter cold enrichment	1	7014021
1958	All F.I.	air meter cold enrichment	1	7017021
1957-58	All 2 B.C.-4 B.C.	LEVER AND LINK ASSY., carb. choke piston	1	7009852
1957-58	All 4 B.C.	(Rochester)	1	7009852
1959-60	All 4 B.C.	(Carter 14-581S) w/2506S, 2740S, 2751S and 2767S carb. (▲)	1	1180734
1959	All 2 B.C.-4 B.C. exc. T420E	(Carter 14-609S) w/2767S, SA, 2768S, 2819S, 2820S, 2975S and 2976S carb. (▲▲)	1	1472184
1960	All H.T.-2 B.C. exc. T425E	(Rochester)	1	7012748
1960	All S.T.-2 B.C. & T425E	(Rochester)	1	7012748
1947-54	P/8	LEVER, carb. choke (Carter 14-296S) with screw	1	7000641
1953-54	P/6	(Carter 14-454S)	1	7005860
1955-56	All 4 B.C.	(Carter 14-383S)	1	7002443
1957-58	All 4 B.C.	(Carter 14-512) Outside	1	1173247
1957-58	All 4 B.C.	(Carter 14-550) Inside	1	7011142
1959-60	All 4 B.C.	choke shaft (Carter 14-619)	1	7013753
1951-52	P/6	LEVER, carb. choke trip	1	7002863
1955-58	All 2 B.C.	(Rochester)	1	7006596
1956-58	All 4 B.C.	(Rochester)	1	7000196
1957-58	All 3/2 B.C.	(Rochester) Center	1	7011014
1959-60	All 2 B.C.-3/2 B.C.	(Rochester)	1	7006596
1959-60	All 4 B.C.	(Carter 14-620)	1	7013754
1957-58	All F.I.	LEVER, air meter cold enrichment trip	1	7000196
1951-52	P/6	ROD, carb. choke	1	7002880
1955	All	(Carter 115-229) w/2207S and 2182SB carb.	1	7007286
1955-56	All 4 B.C.	(Carter 115-215)	1	566249
1955-56	All 2 B.C.	(Rochester)	1	7005817
1955-56	All 4 B.C.	(Rochester)	1	7006835
1957-58	All 2 B.C.	(Rochester)	1	7010055
1957-58	All 4 B.C.	(Rochester)	1	7010222
1957-59	All 3/2 B.C.	(Rochester) Center	1	7005817
1957-59	All 2 B.C.	(Rochester) intermediate	1	7010056
1957-58	All 4 B.C.	(Rochester) intermediate	1	7010357
1957	All 4 B.C.	(Carter 115-277)	1	7011191
1958-60	All 4 B.C.	(Carter 115-285)	1	1182811
1959	All 2 B.C. exc. T420E	(Rochester)	1	7010055
1959	All 2 B.C.-T420E	(Rochester)	1	7005817
1960	All H.T.-2 B.C. exc. T425E	intermediate choke (Rochester)	1	7010056
1955	All (3.762)	RETAINER, choke conn. rod (Carter 172-22) w/2207S, SB, 2182S, SA and SB carb.	1	7002140
1955-56	All 2 B.C.-4 B.C. (3.841)	(Rochester)	2	836159
1956-60	All 4 B.C. (3.841)	(Carter 150A-10)	1	836159
1951-52	P/6	SCREW, carb. choke trip lever (No. 6-32x5/16")	1	1875051
1955	All H.T.-2 B.C.-4 B.C.	(Rochester) (No. 6-32x5/16")	1	1875051

1956-58	All	(Rochester)	(No. 6-32x5/16")	1	1875051
1957-58	All 4 B.C.	(Carter 101-65)	(No. 6-32x5/16")	1	1875051
1959-60	All	choke trip lever (Carter 101-65)	(No. 6-32x5/16")	1	1875051
1959-60	All 4 B.C.	choke shaft lever attaching	(No. 6-32x5/16")	1	1875051
1959-60	All 2 B.C.	choke piston lever attaching	(No. 6-32x5/16")	1	1875051
1957-58	All F.I.	SCREW, air meter cold enrichment trip lever	(No. 6-32x5/16")	1	7010434
1951-52	P/6	WASHER, trip lever spacing		1	1875354
1957-60	All 4 B.C.	choke piston ret. (Carter 136-34)		2	1875354
1960	All 4 B.C.	choke shaft (Carter 136-219)		1	7016862
		RETAINER (see Group 3.762 for use)			1346650

▲NOTE: Use with 7011200 Housing (Casting 170-491).

▲▲NOTE: For 1958 2767S-SA use with 7013362 Housing (Casting 170-553)

Group 3.758 VALVE, CARBURETOR THROTTLE

1940	28 All	(Carter 2-99)		1	1875230
1940-52	P/8 exc. 1940 28	(Carter 2-92)		2	1875428
1941-50	P/6	(Carter 2-99) w/494S on 1942		1	1875230
1953-54	P/6	(Carter 2-92)		2	1875428
1953-54	P/8	(Carter 2-2) w/719SA and 720SA carb.		2	1875428
1954	P/8	(Carter 2-101) w/2122S carb.		2	839034
1955	All	(Carter 2-101) w/2207S and 2182SB carb.		2	839034
1955	All 4 B.C.	primary (Carter 2-92)		2	1875428
1955	All 4 B.C.	secondary (Carter 2-161)		2	566234
1956	All 4 B.C.	primary (Carter 2-101)		2	839034
1956	All 4 B.C.	secondary (Carter 2-170)		2	1168639
1956	All 4 B.C.	auxiliary (Rochester)		1	7009685
1956	All 4 B.C.	auxiliary (Carter 2-179)		2	7009559
1956	All 2/4 B.C.	auxiliary (Rochester)		2	7009585
1957	All 4 B.C.	auxiliary (Rochester)		1	7010892
1957-58	All 4 B.C.	primary (Carter 2-185) w/2506S, 2740S and 2751S carb.		2	7011097
1957-60	All 4 B.C.	secondary (Carter 2-196)		2	7011098
1957	All 4 B.C.	auxiliary (Carter 2-198)		2	7011099
1958	All 4 B.C.	primary (Carter 2-223) w/2767S and 2758S carb.		2	7012737
1958	All 4 B.C.	auxiliary (Rochester)		1	7012578
1959-60	All S.T.-4 B.C.	primary (Carter 2-195)		2	1470441
1959	All H.T.-4 B.C.	primary (Carter 2-224) w/2819S carb.		2	7013748
1960	All H.T.-4 B.C.	primary (Carter 2-224)		2	7017534

Group 3.759 SHAFT AND LEVER, CARBURETOR THROTTLE

1940	28 All	(Carter 3-370S)		1	1875440
1941-50	P/6	(Carter 3-370S) w/494S carb. on 1942		1	1875440
1947-54	P/8	(Carter 3-598S) w/630S, 630SA, 630SB and 719S carb.		1	7001458
1948-50	P/6 H.T.	(Carter 3-546S) w/652S or 718S carb.		1	7001463
1948-54	P/8 H.T.	(Carter 3-605S) w/653S or 720S & SA carb.		1	7001470
1953-54	P/6	(Carter 3-842S)		1	7005856
1954	P/8	(Carter 3-902S) w/2122S carb.		1	7006349
1955	All	(Carter 3-921S) w/2207S and 2182SB carb.		1	7007279
1955	All 4 B.C.	primary (Carter 3-987S)		1	7008343
1955	All 4 B.C.	secondary (Carter 3-851S)		1	566236
1956	All 4 B.C.	primary (Carter 3-1029S)		1	7009560
1956	All 4 B.C.	secondary (Carter 3-1031S)		1	7009561
1956	All 4 B.C.	auxiliary (Carter 3-1035S)		1	7009562
1957	All 4 B.C.	primary (Carter 3-1076S)		1	7011130
1957-60	All 4 B.C.	secondary (Carter 3-1074S)		1	7011100
1957	All 4 B.C.	auxiliary (Carter 3-1101S)		1	7011133

1958	All 4 B.C.	primary (Carter 3-1200S) w/2740S and 2751S carb.	1	7012398
1958	All 4 B.C.	primary (Carter 3-1215S) w/2767S and 2768S carb.	1	7012738
1958	All 4 B.C.	auxiliary (Carter 3-1213S)	1	7012399
1959-60	All 4 B.C.	primary (Carter 3-1220S)	1	7013749
1959-60	All 4 B.C.	auxiliary (Carter 3-1226S)	1	7013750
1956	All 4 B.C.	SHAFT PKG., secondary throttle (Rochester)	1	7009960
1947-54	P/8	RING, carb. throttle shaft ret. (Carter 63-118) w/630SA, SB, 653S, 719, 720, S and SA carb.	1	7001461
1955-56	All 4 B.C.	WASHER, throttle shaft-spring (Carter 136-84)	1	563132

Group 3.761 SCREW, CARBURETOR THROTTLE VALVE AND LEVER

1937-50	All	SCREW, valve attaching-single carb.		
		(Carter 39-11) (No. 3-48x7/32")	2	342146
1940-54	P/8 exc. 1940 28	(Carter 101-73) (No. 3-48x1/4")	4	7000645
1953-54	P/6	(Carter 101-73) (No. 3-48x1/4")	4	7000645
1954	P/8	(Carter 101-126) w/2122S carb.	4	1438309
1955	All	(Carter 101-126) w/2207S and 2182SB carb.	4	1438309
1955-56	All 4 B.C.	primary (Carter 101-348)	4	563892
1955-56	All 4 B.C.	SCREW, secondary (Carter 101-337)	4	563127
1956	All 4 B.C.	auxiliary (Carter 101-414)	4	7009572
1957-60	All 4 B.C.	primary (Carter 101-420)	4	7011175
1957-60	All 4 B.C.	secondary (Carter 101-419)	4	7011174
1957	All 4 B.C. (3.751)	auxiliary (Carter 39-10)	4	838959
1947-54	P/8	SCREW, lever adjusting		
		(Carter 101-121) (No. 10-26x13/16")	1	839062
1953-54	P/6	(Carter 101-376) (No. 10-26x13/16")	1	839062
1955-56	All 4 B.C.	(Rochester) (No. 10-32x3/4")	1	566247
1955	All H.T.-4 B.C.	(Carter 101-452)	1	7001619
1957-58	All 4 B.C.	SPRING, lever adj. screw (Carter 61-291)	1	7012657
1955-58	All 4 B.C.	WASHER, lever adj. screw (Carter 136-174)	1	1451460
1955-58	All 4 B.C.		1	566255

Group 3.762 ARM-ROD-SPRING, CARBURETOR THROTTLE

1939-40	All exc. 1940 29	ARM, throttle shaft (Carter 114-42S)	1	1875222
1941-42	P/6	(Carter 114-42S) w/496S carb. on 1942	1	1875222
1946-50	P/6	(Carter 114-42S) w/537S or 717S carb.	1	1875222
1947-48	P/8	(Carter 114-45) w/630S carb.	1	7000687
1949-54	P/8	(Carter 114-45) w/719S and 719SA carb.	1	7000687
1953-54	P/6	(Carter 114-45)	1	7000687
1955	All	(Carter 114-132) w/2207S and 2182SB carb.	1	7007861
1955	All 4 B.C.	outer (Carter 114-127)	1	7008356
1955	All 4 B.C.	inner (Carter 114-128)	1	7008357
1955	All 4 B.C.	secondary lock out (Carter 53A-338)	1	563111
1956-58	All 4 B.C.	inner (Carter 114-139)	1	7009573
1956	All 4 B.C.	outer (Carter 114-143)	1	7009643
1956	All 4 B.C.	secondary lock out (Carter 53A-397)	1	7009567
1957-58	All 4 B.C.	outer (Carter 114-144) w/2506S, 2740S and 2751S carb.	1	7011187
1958-60	All 4 B.C.	outer (Carter 114-146) w/2767S, 2768S, 2819S and 2820S carb.	1	1470468
1959-60	All 4 B.C.	inner (Carter 114-147)	1	1470469
1955	All 4 B.C.	DOG, throttle shaft (Carter 4A-158)	1	7008344
1956	All 4 B.C.	(Carter 4A-164)	1	7009563
1957-60	All 4 B.C.	primary throttle shaft (Carter 4A-175)	1	7011134
1957-60	All 4 B.C.	secondary throttle shaft lockout (Carter 53A-412)	1	7011158
1955	All 4 B.C.	LEVER, secondary shaft operating (Carter 53A-365)	1	566243
1956	All 4 B.C.	(Carter 53A-398)	1	7009568
1957-58	All 4 B.C.	(Carter 53A-414)	1	7011160

1957	All 3/2 B.C.	(Rochester)-rear carb. lock out	1	7010993
1958	All 3/2 B.C.	(Rochester)-front carb. lock out	1	7011878
1958-60	All 3/2 B.C.	(Rochester)-front carb. actuating	1	7011894
1958-60	All 3/2 B.C.	(Rochester)-rear carb. actuating	1	7011897
1959-60	All 4 B.C.	secondary shaft operating (Carter 53A-430)	1	1182487
1957	All 3/2 B.C.	LEVER AND PIN ASSY., front carb. actuating	1	7011369
1957	All 3/2 B.C.	(Rochester)-rear carb. actuating	1	7011370
1955-56	All 4 B.C.	LINK, throttle lever secondary	1	7000241
1957-58	All 4 B.C.	(Rochester)	1	7010352
1957	All 3/2 B.C.	lock out lever	1	7011429
1957-58	All 3/2 B.C.	front to rear carb.	1	7011009
1958	All 3/2 B.C.	lock out lever	1	7012088
1958	All 3/2 B.C.	(Rochester)-front carb. vacuum actuating	1	7012720
1959-60	All 3/2 B.C.	front carb. to rear carb.	1	7015362
1947-54	P/8	ROD, connector (Carter 115-130) w/719, 720S and SA, 2122S carb.	1	7002125
1949-50	P/6	(Carter 115-122) w/717S and 718S carb.	1	7001855
1955	All	(Carter 115-212) w/2207S and 2182SB carb.	1	566015
1955-56	All 4 B.C.	(Carter 115-216)	1	566250
1955-56	All 4 B.C.	primary to secondary levers (Carter 115-208)	1	563893
1957	All 4 B.C.	throttle connector (Carter 115-276)	1	7011190
1957-58	All 4 B.C.	throttle operating (Carter 115-292) w/2506S, 2740S and 2751S carb.	1	7011543
1958-60	All 4 B.C.	throttle operating (Carter 115-309) w/2767S, 2768S, 2819S and 2820S carb.	1	1185170
1958-60	All 4 B.C.	throttle connector (Carter 115-323) use w/7002140 retainer	1	7013763
1947-48	P/8	RETAINER, throttle rod anti-rattle spring		
1948	P/6	(Carter 63-93) w/630S or 653S carb.	1	7000760
1949-54	All	(Carter 63-93) w/652S carb.	1	7000760
1955-58	All 4 B.C.	(Carter 63-93) w/179, 720S and SA carb.	1	7000760
1949-50,		(Carter 63-35)	1	1875046
1953-54	P/6	throttle connector rod (Carter 172-22)	1	7002140
1949-54	P/8	throttle connector rod (Carter 172-22) w/719, 720S and SA, 2122S carb.	1	7002140
1955	All	throttle connector rod (Carter 172-24) w/2207S and 2182SB carb.	2	1346650
1959-60	All 4 B.C.	throttle connector rod (Carter 172-22)	1	7002140
1939-58	All	RETAINER SPRING, throttle connector rod (Carter 150A-10)	AR	836159
1959-60	All 4 B.C.	(Carter 150A-10)	AR	836159
1947-54	P/8	SCREW, shaft arm (Carter 101-74) w/630S, 719S or 719SA carb.	1	1875292
1953-54	P/6	(Carter 101-74)	1	1875292
1955	All	(Carter 101-74) w/2207S and 2182SB carb.	1	1875292
1955-60	All 4 B.C.	(Carter 101-74)	2	1875292
1957-60	All 3/2 B.C.	carb. actuating lever		
1937-48	All	retainer Front and rear (No. 8-32x5/16")	1	7010435
1949-50	P/8	SPRING, throttle connector rod anti-rattle (Carter 61-128)	1	839539
1955-56	All 4 B.C.	(Carter 61-128)	1	839539
1947-54	All	(Carter 61-128)	1	839539
1953-54	P/6	WASHER, throttle shaft arm (Carter 136-38) used with 630S, 719S or 719SA carb.	1	7000754
1955	All	(Carter 136-38)	1	7000754
1955-60	All 4 B.C.	(Carter 136-38)	1	7000754
1955-56	All 4 B.C.	primary (Carter 136-159)	1	1459371
1957-60	All 4 B.C.	secondary (Carter 136-172)	1	563896
1958-60	All 3/2 B.C.	secondary (Carter 136-160)	1	7011198
		front carb. vacuum actuating link (Rochester)	1	7005993
		CLIP (see Group 3.752 for use)		7005109

Group 3.763 SPRING-PIN, CARBURETOR THROTTLE

1955-60	All 4 B.C.	SPRING, secondary return (Carter 61-483)	1	563888
1955	All 4 B.C.	throttle flex (Carter 61-548)	1	7008801
1955-56	All 4 B.C.	secondary lock out arm (Carter 61-535)	1	7008353
1956	All 4 B.C.	throttle flex (Carter 61-574)	1	7009642
1957-59	All 4 B.C.	throttle flex (Carter 61-592)	1	7011171
1957	All 3/2 B.C.	throttle return (Rochester) Front and rear	1	7011003
1958	All 3/2 B.C.	throttle return (Rochester) Front and rear	2	7011895
1959-60	All 3/2 B.C.	throttle return (Rochester) Front and rear	2	7013783
1960	All 4 B.C.	throttle flex (Carter 61-623)	1	1190130
1958	All 4 B.C.	SPRING KIT, secondary lockout (Rochester)	1	7012445
1957	All 3/2 B.C.	PIN, throttle return spring Front and rear	1	7010971

Group 3.764 CONTROL UNIT-SWITCH-VALVE, CARBURETOR VACUUM CONTROL

1957	All 3/2 B.C.	CONTROL ASSY., rear carb. vacuum	1	1998829
1958	All 3/2 B.C.	front carb. vacuum	1	1998827
1959-60	All 3/2 B.C.	carb. throttle thermostatic vacuum	1	7013310
1957-58	All 3/2 B.C.	SWITCH, carb. vacuum control Center	1	7011310
1959-60	All 3/2 B.C.	carb. vacuum control Center	1	7013670
1957	All S.T.-3/2 B.C. . . . (4.955)	VALVE ASSY., carb. vacuum control	1	5454944
1959-60	All 3/2 B.C. (4.955)	carb. vacuum check	1	5455973

Group 3.765 CONTROL-BRACKET-LINK-TANK, CARBURETOR VACUUM CONTROL

1959-60	All 3/2 B.C.	CONTROL, front carb. vacuum	1	1998857
1957	All 3/2 B.C.	BRACKET, rear carb. vacuum control	1	7011427
1958	All 3/2 B.C.	front carb. vacuum unit	1	7011280
1959-60	All 3/2 B.C.	front carb. vacuum control	1	7013284
1959-60	All 3/2 B.C.	vacuum check valve support	1	533680
1959-60	All 3/2 B.C.	vacuum check valve hose pipe to front carb. hose . .	1	533748
1959	All 3/2 B.C.	vacuum pipe to timing chain cover	1	533945
1960	All 3/2 B.C.	vacuum pipe to vacuum diaphragm	1	536585
1960	All	CLAMP, vac. hose and check valve to		
		bracket (3/4" dia.)	1	535158
1960	All 3/2 B.C.	vac. hose and pipe to bracket (3/4" dia.)	1	535158
1959-60	All 3/2 B.C.	GASKET, vacuum control to intake manifold	1	533130
1959-60	All 3/2 B.C. (4.931)	HOSE, vacuum check valve pipe to front carb.		
		(cut to length) (3/8" I.D. x 28")	AR	530783
1959-60	All 3/2 B.C. (10.153)	vacuum check valve reducer to reserve tank		
		(cut to length) (7/32" I.D. x 73")	AR	530802
1959-60	All 3/2 B.C. (10.153)	thermostatic vacuum control pipe to reserve tank		
		(cut to length) (7/32" I.D. x 73")	AR	530802
1957	All 3/2 B.C.	LINK, rear carb. vacuum control	1	7011428
1959-60	All 3/2 B.C.	front carb. vacuum control actuating	1	7013285
1959-60	All 3/2 B.C.	REDUCER, check valve hose	1	533750
1959-60	All 3/2 B.C.	SPACER, front carb. vacuum control bracket	1	7013275
1959-60	All 3/2 B.C.	TANK, vacuum reserve	1	533681
1959-60	All 3/2 B.C.	TEE, carb. vacuum hoses to vacuum reserve tank . . .	1	4568633

Group 3.766 CAM-LEVER, CARBURETOR FAST IDLE

1947-54	P/8	CAM (Carter 181-134S)	1	7000664
1949-50	P/6	(Carter 181-155S) w/717S or 718S carb.	1	7001859
1951-52	P/6	(Rochester)	1	7002876

1953-54	P/6	(Carter 181-134S)	1	7000664
1955	All	(Carter 181-214S) w/2207S and 2182SB carb.	1	7007290
1955-57	All 2 B.C.	(Rochester)	1	7006021
1955	All 4 B.C.	(Rochester)	1	7004395
1955-56	All 4 B.C.	(Carter 181-192S)	1	1459376
1956-57	All 4 B.C.	(Rochester)	1	7009149
1956	All 2/4 B.C.	(Rochester)	2	7010028
1957	All 4 B.C.	(Carter 181-241)	1	7011202
1958	All 2 B.C.	(Rochester) w/7011702 and 7011703 carb.	1	7006021
1958	All 2 B.C.	(Rochester) w/7012702 and 7012703 carb.	1	7012564
1958	All 4 B.C.	(Carter 181-257S)	1	7012408
1958	All 4 B.C.	(Rochester)	1	7012589
1959	All 2 B.C. exc. T420E	(Rochester)	1	7013801
1959	All 2 B.C.-T420E	(Rochester)	1	7016086
1959-60	All 3/2 B.C.	(Rochester) Center	1	7016086
1959-60	All 4 B.C.	(Carter 181-267S)	1	7013766
1960	All H.T.-2 B.C. exc. T425E	(Rochester)	1	7013801
1960	All S.T.-2 B.C. & T425E	(Rochester)	1	7016086
1957	All F.I.	CAM, air meter fast idle	1	7014668
1958	All F.I.	air meter fast idle	1	7014838
1954	All A.C.	DIAPHRAGM AND SOLENOID ASSY., carb. fast idle		
		(Carter 202-56S)	1	518745
1947-54	P/8	LEVER, cam trip (Carter 14-355)	1	7000692
1953-54	P/6	(Carter 14-355)	1	7000692
1955-56	All 4 B.C.	(Carter 14-440)	1	1459332
1958	All H.T. exc. F.I.	throttle control overtravel	1	529775
1954	P/8 A.C.	PIPE, fast idle diaphragm to manifold	1	518748
1940-54	P/8 exc. 1940 28	SCREW, adjusting (Carter 101-84) (No. 8-32x3/4")	1	7000646
1953-54	P/6	(Carter 101-84) (No. 8-32x3/4")	1	7000646
1955-60	All 2 B.C.-4 B.C.	(Rochester) (No. 10-32x1")	1	7006213
1957-59	All 4 B.C.	(Carter 101-429)	1	7011179
1957-60	All 3/2 B.C.	(Rochester) Center (No. 10-32x1")	1	7006213
1957	All 4 B.C.	SPACER, fast idle cam (Carter 108-64)	1	7011184
1955	All H.T.-4 B.C.	SPRING, idle adjusting screw (Rochester)	1	7001690
1956-58	All 4 B.C.	(Rochester)	1	7001690
1955	All 4 B.C.	idle stop screw (Rochester)	1	7003176
1958	All F.I.	TUBE ASSY., air meter cranking valve	1	7017030
1958	All F.I.	VALVE ASSY., air meter cranking signal	1	7014954

Group 3.767 ARM-SPRING-SCREW, CARBURETOR FAST IDLE

1948-54	P/8 H.T.	ARM AND SCREW ASSY., (Carter 53A-287S) w/653S, 720S and SA carb.	1	7001471
1937-50	All	SCREW, cam attaching (Carter 101-81) single carb.	1	1875053
1940-47	All	(Carter 101-70)	1	7003561
1947-54	P/8	(Carter 101-140)	1	7000748
1951-52	P/6	(Rochester)	1	7003561
1953-54	P/6	(Carter 101-140)	1	7000748
1955-60	All 2 B.C.-4 B.C.	(Rochester)	1	7003561
1955-56	All 4 B.C.	(Carter 101-324)	1	1459352
1957-59	All 4 B.C.	(Carter 101-323)	1	7011620
1957-58	All F.I.	SCREW, air meter cam attaching	1	7003561
1947-54	P/8	SPRING, fast idle arm (Carter 61-266)	1	7000668
1953-54	P/6	(Carter 61-266)	1	7000668
1955	All	(Carter 61-391) w/2207S and 2182SB carb.	1	560921
1955-56	All 4 B.C.	(Carter 61-454)	1	1459342
1959-60	All 4 B.C.	(Carter 61-624)	1	7013761

Group 3.768 LINK-ROD-SPRING, CARBURETOR FAST IDLE CONNECTOR

1955	All	LINK, connector (Carter 117-161) w/2207S and 2182SB carb.	1	566017
------	-----	---	---	--------

1957	All F.I.	LINK, air meter fast idle cam	1	7014033
1958	All F.I.	air meter fast idle cam	1	7014933
1947-54	P/8	ROD, connector (Carter 115-70)	1	7000741
1953-54	P/6	(Carter 115-205)	1	7005873
1957-58	All 4 B.C.	(Carter 115-275)	1	7011189
1959-60	All 4 B.C.	(Carter 115-314)	1	7013762
1939-60	All 4 B.C. (3.841)	RETAINER SPRING, fast idle connector rod (Carter 150A-10)	AR	836159
1957-58	All F.I. (3.762)	CLIP, air meter fast idle link	2	7005109

Group 3.774 NOZZLE, CARBURETOR

1946-50	P/6	(Carter 12-286)	1	7000397
---------	-----	-----------------	---	---------

Group 3.775 PLUG, CARBURETOR IDLE PORT AND PASSAGE

1947-50	All	idle port-rivet (Carter 11B-108)	2	1875015
1951-54	P/8	idle port-rivet (Carter 11B-108)	2	1875015
1953-54	P/6	idle port-rivet (Carter 11B-108)	2	1875015
1955	All	idle port-rivet (Carter 11B-108) w/2207S and 2182SB carb.	2	1875015
1957-60	All 4 B.C.	passage-ball (Carter 103-14) (3/16")	1	7011181
1958	All 4 B.C.	passage-ball (Carter 103-15) w/2767S carb. (1/4")	1	7011182

Group 3.786 VENTURI ASSEMBLY, CARBURETOR

1955	All H.T.-2 B.C.	(Rochester)	1	7009233
1955	All H.T.-4 B.C.	primary (Rochester)	1	7007855
1955	All H.T.-4 B.C.	secondary (Rochester)	1	7007868
1956	All S.T.-2 B.C.	(Rochester)	1	7009096
1956	All H.T.-2 B.C.	(Rochester)	1	7009239
1956	All S.T.-4 B.C.	primary (Rochester)	1	7009247
1956	All H.T.-4 B.C.	primary (Rochester)	1	7008548
1956	All 4 B.C.	secondary (Rochester)	1	7009112
1956	All 2/4 B.C.	primary (Rochester)	2	7010825
1957	All S.T.-2 B.C.	(Rochester)	1	7011561
1957	All H.T.-2 B.C.	(Rochester)	1	7010575
1957	All S.T.-4 B.C.	primary (Rochester)	1	7010216
1957	All H.T.-4 B.C.	primary (Rochester)	1	7010225
1957	All 4 B.C.	secondary (Rochester)	1	7010217
1957	All 4 B.C.	primary-choke side (Carter 58-177S)	1	7011584
1957	All 4 B.C.	primary-pump side (Carter 58-178S)	1	7011585
1957	All 4 B.C.	secondary-choke side (Carter 58-164S)	1	7011167
1957	All 4 B.C.	secondary-pump side (Carter 58-165S)	1	7011168
1957-58	All 3/2 B.C.	(Rochester) Front and rear	2	7010972
1957	All S.T.-3/2 B.C.	(Rochester) Center	1	7011513
1957	All H.T.-3/2 B.C.	(Rochester) Center	1	7011434
1958	All S.T.-2 B.C.	(Rochester)-w/7011703 carb.	1	7012349
1958	All H.T.-2 B.C.	(Rochester)-w/7011702 carb.	1	7012647
1958	All S.T.-2 B.C.	(Rochester)-w/7012703 carb.	1	7012552
1958	All 4 B.C.	primary (Rochester)	1	7012323
1958	All 4 B.C.	secondary (Rochester)	1	7011943
1958	All H.T.-2 B.C.	(Rochester)-w/7012702 carb.	1	7012995
1958	All S.T.-4 B.C.	primary-choke side (Carter 58-274S) w/2751S carb.	1	7012783
1958	All S.T.-4 B.C.	primary-choke side (Carter 58-309S) w/2768S carb.	1	7013359
1958	All H.T.-4 B.C.	primary-choke side (Carter 58-260S) w/2740S carb.	1	7012404
1958	All H.T.-4 B.C.	primary-choke side (Carter 58-296S) w/2767S carb.	1	7012743

1958	All S.T.-4 B.C.	primary-pump side (Carter 58-275S) w/2751S carb. .	1	7012784
1958	All S.T.-4 B.C.	primary-pump side (Carter 58-311S) w/2768S carb. .	1	7013360
1958	All H.T.-4 B.C.	primary-pump side (Carter 58-261S) w/2740S carb. .	1	7012405
1958	All H.T.-4 B.C.	primary-pump side (Carter 58-297S) w/2767S carb. .	1	7012744
1958	All 4 B.C.	secondary-choke side (Carter 58-196S)	1	1470456
1958	All 4 B.C.	secondary-pump side (Carter 58-197S)	1	1470457
1958-59	All S.T.-3/2 B.C.	(Rochester) Center	1	7012365
1958	All H.T.-3/2 B.C.	(Rochester) Center	1	7012347
1959	All S.T.-2 B.C. exc. T420E .	(Rochester)	1	7013610
1959	All H.T.-2 B.C. exc. T420E .	(Rochester)	1	7013768
1959	All S.T.-2 B.C.-T420E . . .	(Rochester)	1	7015551
1959	All H.T.-2 B.C.-T420E . . .	(Rochester)	1	7013922
1959	All S.T.-4 B.C.	primary-choke side (Carter 58-387S)	1	7015200
1959	All S.T.-4 B.C.	primary-pump side (Carter 58-388S)	1	7015201
1959-60	All H.T.-4 B.C.	primary-choke side (Carter 58-316) w/2819S carb. .	1	7013757
1959-60	All H.T.-4 B.C.	primary-pump side Carter 58-317S w/2819S carb. .	1	7013758
1959	All 4 B.C.	secondary-choke side (Carter 58-347S)	1	7013759
1959	All 4 B.C.	secondary-pump side (Carter 58-348S)	1	7013760
1959-60	All 3/2 B.C.	(Rochester) Front and rear	2	7013381
1959	All 3/2 B.C.	(Rochester) Center	1	7013815
1960	All S.T.-2 B.C. exc. T425E .	(Rochester)	1	7016190
1960	All H.T.-2 B.C.	(Rochester) w/7015072 carb.	1	7017953
1960	All H.T.-2 B.C. exc. T425E .	(Rochester)	1	7016375
1960	All H.T.-2 B.C. T425E . . .	(Rochester)	1	7016189
1960	All S.T.-4 B.C.	primary-choke side (Carter 58-477S)	1	7017536
1960	All S.T.-4 B.C.	primary-pump side (Carter 58-478S)	1	7017537
1960	All S.T.-3/2 B.C.	(Rochester) Center	1	7016261
1960	All 4 B.C.	secondary-choke side (Carter 58-475S)	1	7016798
1960	All 4 B.C.	secondary-pump side (Carter 58-476S)	1	7016799
1960	All H.T.-3/2 B.C.	(Rochester) Center	1	7016263
1955-56	All 2 B.C.	GASKET, venturi cluster to pump discharge screw . .	1	7000295
1957-58	All 3/2 B.C.	(Rochester)	3	7000295
1957-59	All 2 B.C. exc. T420E . . .	venturi cluster center screw	1	7008892
1959	All 2 B.C.-T420E	venturi cluster to pump discharge screw (Rochester) .	1	7000295
1959-60	All 3/2 B.C.	venturi cluster to pump discharge screw (Rochester) Center	1	7000295
1959-60	All 3/2 B.C.	venturi cluster center screw (Rochester) Front and rear	2	7008892
1960	All H.T.-2 B.C. exc. T425E .	venturi cluster center screw	1	7008892
1960	All S.T.-2 B.C. & T425E . . .	venturi cluster to pump discharge screw (Rochester)	1	7000295
1955-56	All 2 B.C.	SCREW, venturi cluster (Rochester) (No. 8-32x1-3/16")	2	7000293
1955-56	All 2 B.C.	(Rochester) (No. 8-32x15/16")	1	7000294
1955-56	All 4 B.C. (3.730)	(Rochester) (No. 8-32x1")	6	451910
1957-59	All 2 B.C.	(Rochester) Center (No. 10-32x15/16")	1	7009077
1957-58	All 4 B.C.	(Rochester) (No. 8-32x1")	1	7010421
1957-58	All 3/2 B.C.	(Rochester) (No. 8-32x15/16")	3	7000294
1957-58	All 3/2 B.C.	(Rochester) (No. 8-32x1-3/16")	6	7000293
1957-58	All 4 B.C.	primary (Carter 101-442S)	4	7011542
1957-60	All 4 B.C.	secondary (Carter 101-379) (No. 10-32 x 1")	4	7006414
1959	All 2 B.C.-T420E	(Rochester) (Spec. No. 8-32x15/16")	1	7000294
1959	All 2 B.C.-T420E	(Rochester) (Spec. No. 8-32x1-3/16")	2	7000293
1959-60	All 3/2 B.C.	(Rochester) . Front and rear (Spec. No. 10-32x15/16")	2	7009077
1959-60	All 3/2 B.C.	(Rochester) Center (Spec. No. 8-32x15/16")	1	7000294
1959-60	All 3/2 B.C.	(Rochester) Center (Spec. No. 8-32x1-3/16")	2	7000293
1960	All H.T.-2 B.C. exc. T425E .	(Rochester) Center (Spec. No. 10-32x15/16")	1	7009077
1960	All S.T.-2 B.C. & T425E . . .	(Rochester) (Spec. No. 8-32 x 15/16")	1	7000294
1960	All S.T.-2 B.C. & T425E . . .	(Rochester) (Spec. No. 8-32x1-3/16")	2	7000293

Group 3.790 GASKET, VENTURI CLUSTER

1955-56	All 2 B.C.	(Rochester)	1	7000292
---------	--------------------	-----------------------	---	---------

1955	All H.T.-4 B.C.	(Rochester)	2	7007803
1956-58	All 4 B.C.	(Rochester)	2	7007803
1957-59	All 2 B.C. exc. T420E	(Rochester)	1	7008893
1957-58	All 3/2 B.C.	(Rochester)	3	7000292
1957-60	All 4 B.C.	primary (Carter 121-302)	2	7011544
1957-60	All 4 B.C.	secondary (Carter 121-293)	2	7011197
1959	All 2 B.C.-T420E	(Rochester)	1	7000292
1959-60	All 3/2 B.C.	(Rochester) Front and rear	2	7008893
1959-60	All 3/2 B.C.	(Rochester) Center	1	7000292
1960	All H.T.-2 B.C. exc. T425E . . .	(Rochester)	1	7008893
1960	All S.T.-2 B.C. & T425E	(Rochester)	1	7000292

Group 3.792 JET AND GASKET, CARBURETOR METERING ROD

1940	28 All	(Carter 120-133S)	1	1875422
1940-50	P/6	(Carter 120-133S) w/494S carb. on 1942	1	1875422
1947-54	P/8	(Carter 120-65S) w/630S carb.	2	1875369
1953-54	P/6	(Carter 120-158)	2	1338015
1955	All	(Carter 120-165) w/2507S and 2182SB carb.	2	1346577
1955	All 4 B.C.	primary (Carter 120-166)	2	1459366
1955	All	secondary (Carter 120-181) w/2268S carb.	2	7008359
1955	All	secondary (Carter 120-187) w/2283S carb.	2	563894
1956	All 4 B.C.	primary (Carter 120-224)	2	7009575
1956	All 4 B.C.	secondary (Carter 120-222)	2	1465397
1957-58	All 4 B.C.	primary (Carter 120-163)	2	7012085
1957	All 4 B.C.	secondary (Carter 120-175)	2	1459367
1958	All 4 B.C.	secondary (Carter 120-229) w/2740S, 2751S and 2767S carb.	2	1179328
1958-60	All 4 B.C.	secondary (Carter 120-194) w/2768S carb.	2	7011193
1951-52	P/6	JET, carb. main metering-standard	1	7002958
1951-52	P/6	(Rochester) 2 step lean	1	7002956
1955	All H.T.-2 B.C.	(Rochester) standard	2	7002655
1955	All H.T.-2 B.C.	(Rochester) lean	2	7002654
1955	All H.T.-4 B.C.	primary (Rochester) standard	2	7002652
1955	All H.T.-4 B.C.	secondary (Rochester) standard	2	7002653
1955	All H.T.-4 B.C.	primary (Rochester) lean	2	7002651
1956	All 2 B.C.	(Rochester) standard	2	7002658
1956	All 4 B.C.	primary (Rochester) standard	2	7002656
1956	All 4 B.C.	secondary (Rochester) standard	2	7008667
1956	All S.T.-2/4 B.C.	primary (Rochester) lean	4	7002654
1956	All H.T.-2/4 B.C.	primary (Rochester) standard	4	7002650
1956	All S.T.-2/4 B.C.	secondary (Rochester)	4	7008673
1956	All H.T.-2/4 B.C.	secondary (Rochester)	4	7008669
1957	All H.T.-2 B.C.	(Rochester) standard	1	7008664
1957	All S.T.-2 B.C.	(Rochester) standard	2	7008665
1957	All 4 B.C.	secondary (Rochester) standard	2	7008682
1957	All 4 B.C.	primary (Rochester) lean	2	7002657
1957-58	All 3/2 B.C.	primary (Rochester) standard Front and rear	4	7002656
1957	All 3/2 B.C.	(Rochester) Center	2	7002662
1958	All S.T.-3/2 B.C.	(Rochester) Center	2	7002660
1958	All H.T.-3/2 B.C.	(Rochester) Center	2	7002661
1958-60	All 4 B.C.	primary (Carter 120-160)	2	7002494
1958	All S.T.-2 B.C.	(Rochester) standard-w/7011703 carb.	2	7008665
1958	All S.T.-2 B.C.	(Rochester) standard-w/7012703 carb.	2	7008664
1958	All H.T.-2 B.C.	(Rochester) standard-w/7011702 carb.	2	7008669
1958	All H.T.-2 B.C.	(Rochester) standard-w/7012702 carb.	2	7008668
1958	All 4 B.C.	(Rochester) standard	2	7002655
1958	All 4 B.C.	secondary (Rochester)	2	7008684
1959-60	All S.T.-2 B.C. exc. T420E . . .	(Rochester) standard	2	7008665
1959	All H.T.-2 B.C. exc. T420E . . .	(Rochester) standard	2	7008669
1959	All S.T.-2 B.C.-T420E	(Rochester) standard	2	7008666

1959-60	All H.T.-2 B.C.-T420E-T425E	(Rochester) standard	2	7008663
1959	All S.T.-2 B.C.-T420E	(Rochester) standard-1 step lean	2	7008664
1959	All S.T.-2 B.C.-T420E	(Rochester) 2 step lean	2	7008662
1959	All H.T.-2 B.C.-T420E	(Rochester) 1 step lean	2	7008661
1959-60	All H.T.-2 B.C.-T420E-T425E	(Rochester) 2 step lean	2	7002659
1959	All S.T.-3/2 B.C.	(Rochester) standard	2	7008662
1959	All H.T.-3/2 B.C.	(Rochester) standard	2	7008665
1959-60	All 3/2 B.C.	(Rochester) standard	4	7008666
1960	All S.T.-2 B.C.	(Rochester) standard-1 step lean	2	7008662
1960	All S.T.-2 B.C.	(Rochester) 2 step lean	2	7008660
1960	All H.T.-2 B.C. exc. T425E	(Rochester) standard	2	7008664
1960	All H.T.-2 B.C.	(Rochester) standard	2	7008663
1960	All H.T.-2 B.C. exc. T425E	(Rochester) 1 step lean	2	7008660
1960	All H.T.-2 B.C.-T425E	(Rochester) 1 step lean	2	7002660
1960	All H.T.-2 B.C.-T425E	(Rochester) 2 step lean	2	7002658
1960	All S.T.-3/2 B.C.	(Rochester) 1 step lean	2	7008660
1960	All S.T.-3/2 B.C.	(Rochester) 1 step lean	2	7002659
1960	All H.T.-3/2 B.C.	(Rochester) 1 step lean	2	7008660
1960	All H.T.-3/2 B.C.	(Rochester) 2 step lean	2	7002659
1960	All 3/2 B.C.	(Rochester) standard	2	7008663
1960	All 3/2 B.C.	(Rochester) 1 step lean	4	7008663
1960	All 3/2 B.C.	(Rochester) 2 step lean	4	7008661
1960	All 3/2 B.C.	(Rochester) 2 step lean	2	7002656

Group 3.798 JET, CARBURETOR LOW SPEED

1946-50	P/6	(Carter 11-168S)	1	7000389
1947-54	P/8	(Carter 11-183S)	2	7001433
1953-54	P/6	(Carter 11-191S)	1	7005858
1954	P/8	(Carter 11-261S) w/2122S carb.	2	7006388
1955	All S.T.	(Carter 11-198S) w/2207S carb.	2	7007998
1955	All	(Carter 11-274S) w/2268S carb.	2	7008346
1955	All	(Carter 11-276S) w/2283S carb.	2	7009046
1956	All	(Carter 11-291S) w/2364S and 2364SA carb.	2	7009565

Group 3.806 ROD, CARBURETOR METERING

1946-50	P/6	std. (Carter 75-528)	1	7000398
1949-54	P/8	std. (Carter 75-664) w/719, 720S and SA carb.	2	7001867
1954	P/8	std. (Carter 75-986) w/2122S carb.	2	7006392
1953-54	P/6	std. (Carter 75-910)	2	7005914
1955	All H.T.	std. (Carter 75-1136) w/2182SB carb.	2	7007284
1955	All S.T.	std. (Carter 75-1135) w/2207S carb.	2	7007283
1955	All	std. (Carter 75-1171) w/2268S carb.	2	7008355
1955	All	std. (Carter 75-1183) w/2283S carb.	2	7009047
1956	All	std. (Carter 75-1240) w/2364S and 2364SA carb.	2	7009571
1946-50	P/6	1 step lean (Carter 75-582)	1	7001413
1949-54	P/8	1 step lean (Carter 75-683) w/719, 720S and SA carb.	2	7002574
1953-54	P/6	1 step lean (Carter 75-945)	2	7006205
1954	P/8	1 step lean (Carter 75-1109) w/2122S carb.	2	7006551
1955	All	1 step lean (Carter 75-1172) w/2207S and SB carb.	2	7008287
1955	All	1 step lean (Carter 75-1174) w/2182S, SA and SB carb.	2	7008289
1955	All H.T.	1 step lean (Carter 75-1203) w/2268S carb.	2	7009222
1955	All S.T.	1 step lean (Carter 75-1219) w/2283S carb.	2	7009223
1946-50	P/6	2 steps lean (Carter 75-583)	1	7001414
1947-48	P/8	2 steps lean (Carter 75-605) w/630S carb.	2	7001437
1949-54	P/8	2 steps lean (Carter 75-684) w/719S, 720S and 720SA carb.	2	7002575
1953-54	P/6	2 steps lean (Carter 75-946)	2	7006206

1954	P/8	2 steps lean (Carter 75-1110) w/2122S carb.	2	7006552
1955	All	2 steps lean (Carter 75-1173) w/2207S and SB carb.	2	7008288
1955	All	2 steps lean (Carter 75-1175) w/2182S, SA and SB carb.	2	7008290
1960	All S.T.-4 B.C.	standard (Carter 16-134)	2	7017535
1960	All H.T.-4 B.C.	standard (Carter 16-126)	2	7016797
1957	All 4 B.C.	ROD, carb. step up (Carter 16-30)	2	7011582
1958	All 4 B.C.	(Carter 16-54) w/2740S and 2751S carb.	2	7012403
1958	All 4 B.C.	(Carter 16-56) w/2751S carb.	2	7012782
1958	All 4 B.C.	(Carter 16-72) w/2767S carb.	2	7013366
1958	All 4 B.C.	(Carter 16-71) w/2768S carb.	2	7013357
1959	All S.T.-4 B.C.	(Carter 16-101)	2	7015356
1959	All H.T.-4 B.C.	standard (Carter 16-80) w/2819S carb.	2	7013756
1959	All H.T.-4 B.C.	1 step lean (Carter 16-103)	2	7016271
1955	All H.T.	ROD AND JET PKG., 2 steps lean (Carter 75-1205U)		
		w/2268S carb.	1	7009224
1955	All S.T.	2 steps lean (Carter 75-1221U) w/2283S carb.	1	7009225
1959	All H.T.-4 B.C.	carb. step up-2 steps lean (Carter 16-105U)	1	7016272
1960	All S.T.	carb. step up-1 step lean (Carter 16-144U)	1	7017741
1960	All H.T.	carb. step up-1 step lean (Carter 16-148U)	1	7017743
1960	All S.T.	carb. step up-2 step lean (Carter 16-146U)	1	7017742
1960	All H.T.	carb. step up-2 step lean (Carter 16-150U)	1	7017744

Group 3.807 ARM, CARBURETOR METERING ROD

1955	All	(Carter 111-53S) w/2207S and 2182SB carb.	1	7002486
1955-56	All 4 B.C.	(Carter 111-60S)	1	1346570

Group 3.810 SPRING, CARBURETOR METERING ROD

1938	All	(Carter 61-75)	1	837149
1942-50	P/6	(Carter 61-75) w/521S or 545S carb. on 1942	1	837149
1947-54	P/8	(Carter 61-234)	1	7000663
1953-54	P/6	(Carter 61-234)	1	7000663
1955-56	All	(Carter 60-382)	1	7002455
1957-60	All 4 B.C.	step up rod ret. (Carter 61-585)	2	7011170
1939-54	P/6	(3.841) RETAINER SPRING, metering rod pin	AR	836159

Group 3.811 DISC, CARBURETOR METERING ROD

1947-53	P/8	(Carter 129-22)	2	7000686
1956	All 4 B.C.	(Carter 129-19)	2	7009578

Group 3.814 NEEDLE AND SEAT, CARBURETOR INTAKE

1940-47	P/8 exc. 1940 28	(Carter 25-74S) w/548S carb. on 1947	1	7000787
1942-50	P/6	(Carter 25-83S) w/521S or 545S carb. on 1942	1	7000788
1947-54	P/8	(Carter 25-105S)	1	7001473
1951-52	P/6	(Rochester) w/gasket	1	7002885
1953-54	P/6	(Carter 25-236S)	1	7006043
1954	P/8	(Carter 25-260S) w/2122S carb.	1	7006416
1955	All	(Carter 25-243S) w/2207S and 2182SB carb.	1	566008
1955-56	All 4 B.C.	primary (Carter 25-280S)	1	7008347
1955-56	All 4 B.C.	secondary (Carter 25-289S)	1	7008348
1955-56	All 2 B.C.	(Rochester)	1	7006998
1955-58	All 4 B.C.	(Rochester)	2	7012144

1957	All 2 B.C.	(Rochester)	1	7012602
1957-60	All 4 B.C.	(Carter 25-362S)	2	7013699
1957-60	All 3/2 B.C.	(Rochester) Center	1	7012602
1957-58	All 3/2 B.C.	(Rochester) Front and rear	2	7012603
1958-60	All 2 B.C.	(Rochester)	1	7012253
1958	All 4 B.C.	primary (Rochester)	1	7012207
1959-60	All 3/2 B.C.	(Rochester) Front and rear	2	7013787
1957	All F.I.	NEEDLE AND SEAT, fuel meter	1	7014817
1958	All F.I.		1	7014691
1957	All 4 B.C.	NEEDLE, SEAT AND GASKET PKG., (Rochester)	1	7012295
1947-54	P/8	CLIP, needle pull (Carter 61-257)	1	7000624
1951-52	P/6	carb. float valve pull	1	7002849
1957-58	All F.I. (3.858)	GASKET, fuel meter needle seat	1	7001613

Group 3.820 COVER-GASKET-KIT-SCREW, CARBURETOR IDLE COMPENSATOR

1960	All H.T.-3/2 B.C.	COVER ASSY, idle compensator- w/7015076 carb. Center	1	7013937
1958	All 4 B.C.	GASKET (Rochester)	1	7013341
1960	All H.T.-3/2 B.C.	w/7015076 carb. Center	1	7013341
1960	All H.T.-3/2 B.C.	idle compensator cover to bowl- w/7015076 carb. Center	1	7013736
1958	All 4 B.C.	KIT (Rochester)	1	7013527
1960	All H.T.-3/2 B.C.	idle compensator-w/7015076 carb. Center	1	7013527
1958	All 4 B.C.	SCREW (Rochester)	2	7015127
1960	All H.T.-3/2 B.C.	idle compensator-w/7015076 carb. Center	1	7015127

Group 3.820 VALVE-GASKET-SCREW, CARBURETOR THERMOSTATIC

1959	All H.T.-4 B.C.	VALVE, carb. thermostatic (Carter 169-43S)	1	7016495
1960	All 4 B.C.	carb. thermostatic	1	7016495
1959	All H.T.-4 B.C.	GASKET, carb. thermostatic valve (Carter 121-314) w/2819S carb.	1	1186601
1960	All 4 B.C.	carb. thermostatic valve (Carter 121-314)	1	1186601
1959	All H.T.-4 B.C.	RESTRICTION, carb. thermostatic valve passage (Carter 11B-387)	1	7015355
1959	All H.T.-4 B.C.	SCREW AND WASHER, carb. thermostatic valve attaching (Carter 101-453S) w/2819S carb.	1	1186600
1960	All 4 B.C.	carb. thermostatic valve attaching (Carter 101-453S)	1	1186600

Group 3.822 SCREW, CARBURETOR IDLE AIR ADJUSTING

1937-50	P/6	(Carter 30A-39)	1	1875035
1937-40	P/8 exc. 1940 29	(Carter 30A-39)	1	1875035
1940-54	P/8	(Carter 30A-41) w/dual carb.	1	1875368
1951-52	P/6	(Rochester)	1	7002875
1953-54	P/6	(Carter 30A-41)	2	1875368
1955-56	All	(Carter 30A-58)	2	1163770
1955-58	All 2 B.C.	(Rochester)	2	7007008
1955-57	All 4 B.C.	(Rochester)	2	7004402
1957-60	All 4 B.C.	(Carter 30A-80)	2	7011583
1958	All 2 B.C.	(Rochester)-w/7012702 and 7012703 carb. (7/16"-20x1-11/16")	1	7012545
1958-60	All 4 B.C.	(Carter 30A-78) Center	1	1470450
1958	All 4 B.C.	(Rochester)	1	7012704
1959	All 2 B.C.	(Rochester)	1	7012545
1957-58	All F.I.	SCREW, air meter idle air adjusting	1	7014005

1960	All H.T.-2 B.C. exc. T425E	(Rochester)	1	7012545
1957-58	All F.I.	NEEDLE, air meter idle adjusting	1	7001669
1958	All 4 B.C.	carb. idle (Rochester)	2	7013116
1959-60	All 2 B.C.-3/2 B.C.	(Rochester) Center	2	7013116
1957-58	All F.I. (10,587)	PLUG, air meter air adjusting screw access hole	1	4668116

Group 3.823 SPRING, CARBURETOR IDLE AIR ADJUSTING SCREW

1937-50	All	(Carter 61-57)	AR	1875042
1951-54	P/8	(Carter 61-57)	AR	1875042
1951-52	P/6	(Rochester)	1	7003190
1953-54	P/6	(Carter 61-57)	2	1875042
1955-60	All	(Carter 61-84)	2	563887
1955-58	All 2 B.C.-4 B.C.	(Rochester)	2	7003190
1958	All 2 B.C.	(Rochester)-w/7012702 and 7012703 carb. (5/8" O.D.x7/8")	1	7012622
1958-60	All 4 B.C.	(Carter 61-599) Center	1	1470460
1958	All 4 B.C.	(Rochester)	1	7012557
1958	All 4 B.C.	carb. idle needle (Rochester)	2	7011479
1959-60	All 2 B.C.-3/2 B.C.	(Rochester) Center	2	7011479
1959	All 2 B.C.	idle air adjusting screw (Rochester)	1	7012622
1960	All H.T.-2 B.C. exc. T425E	idle air adjusting screw (Rochester)	1	7012622
1957-58	All F.I.	SPRING, air meter idle air screw	1	7014006
1957-58	All F.I.	air meter idle needle	1	7003190

Group 3.825 BALL-GUIDE-SPRING, CARB. PUMP DISCHARGE

1951-52	P/6	BALL	1	7002117
1955	All H.T.-2 B.C.-4 B.C.	(Rochester)	1	7002117
1956-60	All	(Rochester)	AR	7002117
1951-52	P/6	GUIDE, spring	1	7002119
1955-60	All 2 B.C.-3/2 B.C.	(Rochester)	AR	7000286
1955	All H.T.-4 B.C.	(Rochester)	1	7003838
1956-58	All 4 B.C.	(Rochester)	1	7003838
1951-52	P/6	SPRING, check valve	1	7002118
1955-60	All 2 B.C.-3/2 B.C.	(Rochester)	AR	7002118
1955	All H.T.-4 B.C.	(Rochester)	1	7006059
1956-58	All 4 B.C.	(Rochester)	1	7006059

Group 3.826 BALL, CARB. PUMP CHECK

1939-48	All	steel (Carter 116-13)	2	1875237
1949-50	P/6	steel (Carter 116-13)	2	1875237
1951-52	P/6	(Rochester)	1	7002120
1955	All H.T.-2 B.C.-4 B.C.	(Rochester)	1	7002120
1955-60	All 4 B.C. (3,862)	(Carter 116-13)	1	1875237
1956-60	All	(Rochester)	1	7002120
1959-60	All 4 B.C.	CHECK ASSY., carb. pump intake ball (Carter 122-108S)	1	7013735
1955-56	All 4 B.C.	RETAINER, check ball (Carter 63-57)	1	1447265
1957-58	All 4 B.C.	SEAT, carb. pump intake check ball (Carter 38A-107) w/2506S, 2740S and 2751S carb.	1	7011154
1958	All 4 B.C.	(Carter 38A-116) w/2767S and 2768S carb.	1	7012741

Group 3.832 NEEDLE-PLUG-GASKET, CARBURETOR PUMP DISCHARGE CHECK

1947-54	P/8	NEEDLE (Carter 17-66)	1	7000700
1955	All	(Carter 17-70) w/2207S and 2182SB carb.	1	7002444
1955-56	All 4 B.C.	(Carter 17-50)	1	1438299

1957-59	All	(Carter 17-51)	1	7000711
1960	All 4 B.C.	(Carter 17-51)	1	7000711
1947-48	P/8	PLUG (Carter 122-81) w/630S carb.	1	7001474
1948	P/8 H.T.	(Carter 122-81) w/653S carb.	1	7001474
1949-54	P/8	(Carter 122-91) w/719, 720S & SA, 2122S carb.	1	7001868
1955	All 4 B.C.	(Carter 11B-129S)	1	7000616
1957-60	All	GASKET, needle seat (Rochester)	AR	7001613

Group 3.838 PLUNGER AND ROD, CARBURETOR PUMP

1939	All	(Carter 64-58S)	1	7000428
1946-50	P/6	(Carter 64-58S)	1	7000428
1947-48	P/8	(Carter 64-113S) w/630S, SA and SB carb.	1	7000769
1949-54	P/8	(Carter 64-124S) w/719, 720S and SA carb.	1	7001865
1951-52	P/6	w/spring	1	7002867
1953-54	P/6	(Carter 64-185S)	1	7008831
1955	All	(Carter 64-185S) w/2207S and 2182SB carb.	1	7008831
1955-56	All 4 B.C.	(Carter 64-165S)	1	566245
1955	All 2 B.C.	(Rochester)	1	7000278
1955	All 4 B.C.	(Rochester)	1	7000208
1956	All 2 B.C.	(Rochester)	1	7009485
1956	All 4 B.C.	(Rochester)	1	7009279
1957-59	All 2 B.C. exc. T420E	(Rochester)	1	7010039
1957-58	All 3/2 B.C.	(Rochester) Center	1	7009485
1957-58	All 3/2 B.C.	(Rochester) Front and rear	2	7011533
1957-58	All 4 B.C.	(Rochester)	1	7010211
1957-58	All 4 B.C.	(Carter 64-204S) w/2506S, 2740S and 2751S carb.	1	7011172
1958-60	All 4 B.C.	(Carter 64-217S) w/2767S, 2819S and 2820S carb.	1	7012745
1958	All 4 B.C.	(Carter 64-218S) w/2768S carb.	1	7013361
1959	All 2 B.C.-T420E	(Rochester)	1	7019518
1959-60	All 3/2 B.C.	(Rochester) Front and rear	2	7019519
1959	All 3/2 B.C.	(Rochester) Center	1	7015177
1960	All H.T.-425E	(Rochester)	1	7019518
1960	All 3/2 B.C.	(Rochester) Center	1	7019518
1960	All H.T.-2 B.C. exc. T425E	(Rochester)	1	7019517
1960	All S.T.-2 B.C.	(Rochester)	1	7019518
1955	All H.T.-4 B.C.	BOOT, pump rod (Rochester)	1	7006372
1956-58	All 4 B.C.	(Rochester)	1	7006372
1955	All H.T.-4 B.C.	CLIP, pump lever rod	1	7003137
1956-58	All	(Rochester)	1	7003137
1957-58	All 3/2 B.C.	pump lever actuating rod Front and rear	2	7003242
1959-60	All 3/2 B.C.	pump rod Front and rear	2	7010773
1959-60	All 2 B.C.	pump lever actuating rod	1	7003242
1947-54	P/8	GUIDE, plunger (Carter 196-15)	1	7000691
1953-54	P/6	(Carter 196-18)	1	7005880
1955-57	All 2 B.C.-4 B.C.	RETAINER, pump rod (Rochester)	AR	836159
1947-54	P/8	SCREW, pump retainer (Carter 101-67)	1	7000749
1953-54	P/6	(Carter 101-67)	1	7000749

Group 3.841 PLUG-RETAINER-SPRING-STRAINER, CARBURETOR PUMP

1947-54	P/8	PLUG, pump discharge check (Carter 122-85S)	1	7000767
1953-54	P/6	pump passage (Carter 11B-279S)	1	7005859
1947-54	P/8	RETAINER, pump spring (Carter 63-92)	1	7000640
1955	All H.T.-4 B.C.	pump inlet screen (Rochester)	1	7001605
1956-58	All 4 B.C.	(Rochester)	1	7001605
1940-47	P/8 exc. 1940 28	SPRING (Carter 61-17) w/548S carb. on 1947	1	1875351
1941-50	P/6	(Carter 61-245) w/494S carb. on 1942	1	1875482

1947-54	P/8	(Carter 61-365)	Lower	1	7000768
1947-54	P/8	(Carter 61-329)	Upper	1	7001434
1953-54	P/6	(Carter 61-389)		1	7005868
1955	All	(Carter 61-389) w/2207S and 2182SB carb.		1	7005868
1955-60	All 4 B.C.	(Carter 61-171)		1	1875351
1951-52	P/6	pump return		1	7005954
1947-50	P/8	pump plunger (61-338)		1	7000638
1955	All 2 B.C.-4 B.C.	pump return (Rochester)		1	7004597
1956	All 2 B.C.	pump return (Rochester)		1	7008694
1956	All 4 B.C.	pump return (Rochester)		1	7004597
1957-58	All 2 B.C.-4 B.C.	pump return (Rochester)		1	7005954
1957-58	All 3/2 B.C.	pump return (Rochester)	Front and rear	2	7004597
1957-58	All 3/2 B.C.	pump return (Rochester)	Center	1	7008694
1959-60	All 2 B.C.-3/2 B.C.	pump return (Rochester)		AR	7004597
1939	All	STRAINER, pump (Carter 30-35)		1	1875253
1946-50	P/6	(Carter 30-35)		1	1875253
1947-54	P/8	(Carter 30-42)		1	7000752
1951-52	P/6	SCREEN, pump inlet		1	7002866
1955-58	All 2 B.C.	(Rochester)		1	7004557
1955	All H.T.-4 B.C.	(Rochester)		1	7001604
1956-58	All 4 B.C.	(Rochester)		1	7001604
1959-60	All 2 B.C.-3/2 B.C.	(Rochester)		AR	7004557
		SPRING (see Group 3.762 for use)			839539
		RETAINER (See Group 3.752-3.762-3.768-3.810-3.843 for use)			836159
		RETAINER (See Group 3.852 for use)			560923

Group 3.842 LEVER AND COUNTERSHAFT, CARBURETOR PUMP OPERATING

1946-50	P/6	(Carter 53A-166S)		1	1875190
1947-54	P/8	(Carter 53A-284S)		1	7000652
1953-54	P/6	(Carter 53A-363S)		1	7005865
1955	All	(Carter 53A-366S) w/2207S and 2182SB carb.		1	566011
1955	All 4 B.C.	(Carter 53A-389S)		1	7008352
1955-57	All 2 B.C.	(Rochester)		1	7000263
1955	All 4 B.C.	(Rochester)		1	7007625
1956-57	All 4 B.C.	(Rochester)		1	7007617
1956	All 4 B.C.	(Carter 53A-333S)		1	1346557
1956	All 2/4 B.C.	(Rochester)		2	7009519
1957-58	All 3/2 B.C.	(Rochester)	Center	1	7011415
1958-60	All 2 B.C.	(Rochester)		1	7006975
1958	All 3/2 B.C.	(Rochester)	Front and rear	2	7000263
1958	All 4 B.C.	(Rochester)		1	7011789
1959-60	All 3/2 B.C.	(Rochester)	Front and rear	2	7013250
1959	All 3/2 B.C.	(Rochester)	Center	1	7015108
1960	All 3/2 B.C.	(Rochester)	Center	1	7017442
1955	All 4 B.C.	BUSHING, pump countershaft (Carter 38A-83)		1	1163051
1955	All H.T.-4 B.C.	CLIP, pump shaft (Rochester)		1	7007616
1956-58	All 4 B.C.	(Rochester)		1	7007616
1955-58	All	LEVER, pump inside		1	7000266
1959-60	All 2 B.C.			1	7000266
1959-60	All 3/2 B.C.		Front and rear	2	7013253
1959-60	All 3/2 B.C.		Center	1	7000266
1955-56	All 4 B.C.	SPRING, pump countershaft (Carter 61-516)		1	566244
1959-60	All 3/2 B.C.	RETAINER, pump lever-spring type	Front and rear (3/16")	2	149505

Group 3.843 LINK, CARBURETOR PUMP CONNECTOR

1939	All	(Carter 117-58)		1	1875224
1940	All exc. 29	(Carter 117-58)		1	1875224

1941-50	P/6	(Carter 117-58) w/494S carb. on 1942	1	1875224
1953-54	P/6	(Carter 117-159)	1	7005875
1955	All	(Carter 117-159) w/2207S and 2182SB carb.	1	7005875
1955-56	All 4 B.C.	(Carter 117-165)	1	1166219
1957-60	All 4 B.C.	(Carter 117-182)	1	7019692
1959	All 2 B.C.-T420E (8,938)	PIN, pump rod (3/64"x5/16")	1	225845
1959-60	All 3/2 B.C. (8,938)	pump rod Center (3/64"x5/16")	1	225845
1955-56	All 2 B.C.	ROD, pump lever actuating (Rochester)	1	7005816
1955-56	All 4 B.C.	(Rochester)	1	7000246
1957	All 4 B.C.	(Rochester)	1	7010221
1957	All 3/2 B.C.	(Rochester) Front and rear	2	7005816
1957	All 3/2 B.C.	(Rochester) Rear	1	7011005
1958	All 3/2 B.C.	(Rochester) Front	1	7011005
1958	All 3/2 B.C.	(Rochester) Center	1	7012555
1958	All 3/2 B.C.	(Rochester) Rear	1	7005816
1958	All 4 B.C.	(Rochester)	1	7011856
1959	All 2 B.C.-T420E	(Rochester)	1	7013998
1959-60	All 3/2 B.C.	(Rochester) Front and rear	2	7013276
1959-60	All 3/2 B.C.	(Rochester) Center	1	7013998
1960	All S.T.-2 B.C. & T425E	(Rochester)	1	7016092
1957-59	All 2 B.C.	ROD KIT, pump lever actuating (Rochester)	1	7013192
1960	All H.T.-2 B.C. exc. T425E	(Rochester)	1	7013192
1939-56	All (3,841)	RETAINER SPRING, pump connector link (Carter 150A-10)	AR	836159
1957-59	All 4 B.C.	(Carter 150A-21)	1	1180909
1953-54	P/6	WASHER, pump connector link (Carter 136-173)	2	7005878
1955	All	(Carter 136-173) w/2207S and 2182SB carb.	1	7005878

Group 3.844 JET, CARBURETOR PUMP

1942-50	P/6	(Carter 48-72) w/521S or 545S carb. on 1942	1	1875243
1947-54	P/8	(Carter 48-143S)	1	7000647
1955	All	(Carter 48-169S) w/2207S and 2182SB carb.	1	7007282
1955-56	All 4 B.C.	(Carter 48-235S)	1	7008349
1957-58	All 4 B.C.	(Carter 48-255S) w/2506S, 2740S and 2751S carb.	1	7011157
1958	All 4 B.C.	(Carter 48-270S) w/2767S carb.	1	7012742
1958	All 4 B.C.	(Carter 48-258S) w/2758S carb.	1	7013358
1959	All 4 B.C.	(Carter 48-270S)	1	7012742
1960	All S.T.-4 B.C.	(Carter 48-258S)	1	7013358
1960	All H.T.-4 B.C.	(Carter 48-270S)	1	7012742
1955-56	All	GASKET, pump jet (Carter 121-241)	1	1163772
1957-60	All 4 B.C.	(Carter 121-303)	1	7011545
1947-54	P/8	PLUG ASSY., pump relief valve (Carter 122-75S)	1	7000658
1956	All 4 B.C.	(Carter 122-98S)	1	7009577
1957-58	All 4 B.C. (3,775)	pump intake screw (Carter 11B-363)	1	7011138
1947-54	P/8	SCREW AND WASHER, pump jet housing (Carter 101-155S)	2	7000747
1953-54	P/6	(Carter 101-155S)	2	7000747
1955-56	All 4 B.C.	(Carter 101-278)	1	7002482

Group 3.845 ARM AND COLLAR, CARBURETOR PUMP

1947-54	P/8	(Carter 111-45S)	1	7000655
1953-54	P/6	(Carter 111-62S)	1	7005872
1955	All	(Carter 111-62S) w/2207S and 2182SB carb.	1	7005872
1955-56	All 4 B.C.	(Carter 111-47S)	1	1338013
1957-58	All 4 B.C.	(Carter 111-75) w/2506S, 2740S and 2751S carb.	1	7011185

1958-60	All 4 B.C.	(Carter 111-84) w/2767S, 2758S, 2819S and 2820S carb.	1	7012746
1953-54	P/6	SPRING, pump operating lever (Carter 61-494)	1	7005869
1955	All	(Carter 61-494) w/2207S and 2182SB carb.	1	7005869
1955-56	All 4 B.C. (8.907)	SCREW, pump arm clamp		
		(Carter 101-6) (Fill. Hd. No. 8-32x5/16")	1	131958
1957-60	All 4 B.C.	(Carter 101-421)	1	7011176
1957-60	All (8.907)	(Rochester) pump lever . . (Fill. Hd. No. 8-32x5/16")	1	131958

Group 3.852 CARBURETOR ANTI-PERCOLATOR VALVE PARTS

1956	All 4 B.C.	ARM, carb. vent (Carter 53A-344)	1	1459754
1939	All	CAP AND ROCKER ARM (Carter 184-18S)	1	1875234
1940	All exc. 29	(Carter 184-18S)	1	1875234
1942-50	P/6	(Carter 184-18S) w/494S carb. on 1942	1	1875234
1956	All 4 B.C.	PIN AND VALVE CAP ASSY., vent (Carter 150-186S)	1	563548
1956-57	All 4 B.C.	GUIDE, idle vent valve (Rochester)	1	7004528
1956	All 4 B.C. (3.841)	RETAINER, vent spring (Carter 63-149)	1	560923
1958	All 4 B.C.	SHIELD, idle vent (Rochester)	1	7012520
1956	All 4 B.C.	SPRING, rocker arm (Carter 61-474)	1	563531
1956-57	All 4 B.C.	idle vent valve (Rochester)	1	7004529
1956-57	All 4 B.C.	VALVE, idle vent (Rochester)	1	7004527
1958	All 2 B.C.-4 B.C.	(Rochester)	1	7007129
1959-60	All 2 B.C.-3/2 B.C.	(Rochester)	1	7007129
1958	All 2 B.C.	VALVE KIT, idle vent (Rochester)	1	7012252
1958	All 4 B.C.	idle vent (Rochester)	1	7012188
1959-60	All 2 B.C.-3/2 B.C.	idle vent (Rochester)	1	7012252
1956	All 4 B.C.	SCREW AND WASHER, vent arm (Carter 101-277S)	1	1346567
1958	All 2 B.C.-4 B.C.	SCREW, idle vent (Rochester) w/7011701-7012702 & 7012703 carb.	1	7012548
1959	All S.T.-2 B.C. exc. T425E	(Rochester)	1	7012548
1960	All 2 B.C.	(Rochester) w/7015062-72 & 73 carb.	1	7012548

Group 3.858 PISTON ASSEMBLY, CARBURETOR VACUUM

1946	P/6	PISTON AND PIN (Carter 160-67S)	1	1875448
1947-50	All		1	1875448
1947-50	All	(Carter 160-67S)	1	1875448
1951-54	P/8	(Carter 160-67S)	1	1875448
1955	All	(Carter 160-131S) w/2207S and 2182SB carb.	1	7007287
1955-56	All 4 B.C.	(Carter 160-110S)	1	1346583
1951-52	P/6	PISTON, carb. power valve actuating-w/rod	1	7002068
1955-57	All 2 B.C.	(Rochester)	1	7006323
1955-56	All 4 B.C.	(Rochester)	1	7000204
1957	All 4 B.C.	(Rochester)	1	7010332
1957-60	All S.T.-3/2 B.C.	(Rochester) Center	1	7011478
1957-60	All H.T.-3/2 B.C.	(Rochester) Center	1	7008069
1958-59	All 2 B.C. exc. T420E	(Rochester)	1	7012266
1958	All 4 B.C.	(Rochester)	1	7011947
1959	All 2 B.C.-T420E	(Rochester)	1	7008069
1960	All S.T.-2 B.C. & T425E	(Rochester)	1	7008069
1960	All H.T.-2 B.C. exc. T425E	(Rochester)	1	7012266
1957-60	All 4 B.C.	PISTON, carb. step up (Carter 160-153)	2	1195596
1955-57	All 2 B.C.	VALVE, carb. power (Rochester)	1	7006331
1955	All H.T.-4 B.C.	(Rochester)	1	7001608
1956	All 4 B.C.	(Rochester)	1	7009349
1957	All 4 B.C.	(Rochester)	1	7010918
1957-60	All S.T.-3/2 B.C.	(Rochester) Center	1	7009349
1957-60	All H.T.-3/2 B.C.	(Rochester) Center	1	7006331
1958	All 2 B.C.-4 B.C.	(Rochester)	1	7011989
1959	All 2 B.C. exc. T420E	(Rochester)	1	7011989
1959	All H.T.-2 B.C.-T420E	(Rochester)	1	7006331
1960	All H.T.-2 B.C. exc. T425E	(Rochester)	1	7011989
1960	All S.T.-2 B.C. & T425E	(Rochester)	1	7006331

1955-57	All 2 B.C.-4 B.C.	GASKET, power valve (Rochester)	1	7001613
1958	All 2 B.C.	(Rochester)-w/7011702 and 7011703 carb.	1	7012488
1958	All 2 B.C.	(Rochester)-w/7012702 and 7012703 carb.	1	7011990
1958	All 4 B.C.	(Rochester)	1	7012488
1959	All 2 B.C. exc. T420E	(Rochester)	1	7011990
1959	All 2 B.C.-T420E	(Rochester)	1	7001613
1959-60	All 3/2 B.C.	(Rochester)	1	7001613
1960	All H.T.-2 B.C. exc. T425E	(Rochester)	1	7011990
1960	All H.T.-2 B.C.-T425E	(Rochester)	1	7001613
1960	All S.T.-2 B.C.	(Rochester)	1	7001613
1947-54	P/8	LINK, piston (Carter 117-83)	1	7000660
1953-54	P/6	(Carter 117-83)	1	7000660
1955-56	All 4 B.C.	(Carter 117-162)	1	566251
1957-60	All 4 B.C.	PLATE, step up piston cover (Carter 65-43)	2	7011173
1955-60	All 4 B.C.	SCREW AND WASHER, carb. dust cover (Carter 101-184S)	2	1346566
1957-60	All 4 B.C.	step-up piston plate (Carter 101-435S)	2	1179315

Group 3.859 SPRING, CARBURETOR VACUUM PISTON

1942-50	P/6	(Carter 61-178) w/521S carb. on 1942	1	1875556
1947-54	P/8	(Carter 61-259)	1	7000751
1953-54	P/6	(Carter 61-377)	1	7005866
1955	All	(Carter 61-135)	1	7002454
1956	All	(Carter 61-478)	1	7009746
1957-58	All 4 B.C.	(Carter 61-246)	2	1332553
1958	All 4 B.C.	(Rochester)	1	7011957
1959-60	All 4 B.C.	(Carter 61-246)	2	1332553
1951-52	P/6	SPRING, carb. power valve actuating piston	1	7002896

Group 3.890 FILTER ASSY., FUEL

1955-57	All exc. F.I.	(A.C. GF-48) with 5/16" fuel line	1	854444
1957	All exc. F.I.	(A.C. GF-48P)-with 3/8" fuel line	1	854469
1957-58	All exc. F.I.	(A.C. GF-61P) use w/531850 Adapter Pkg.	1	854619
1957-58	All F.I.	(A.C. GF-43)	1	854385
1958	All exc. A.C. & F.I.	(A.C. GF-48P)	1	854469
1958	All A.C. exc. F.I.	(A.C. GF-53)	1	854494
1959	All 2 B.C. exc. A.C.	(A.C. GF-48P)	1	854469
1959	All 2 B.C.-A.C.	(A.C. GF-53)	1	854494
1959	All exc. 2 B.C.-A.C.	(A.C. GF-61P) use with 531850	1	854619
1960	All	(A.C. GF-61P) use with 531850	1	854619
1957-59	All exc. F.I.	ADAPTER PKG., fuel filter-with 3/8" fuel line	1	531850
1956-57	All A.C.	BAIL, NUT & SEAT PKG., fuel filter (A.C. CF-19)	1	854215
1956-57	All A.C.	BOWL PKG., fuel filter (A.C. CF-20)	1	854237
1957	All F.I.	BRACKET, fuel filter mounting	1	524903
1958	All F.I.		1	530829
1959-60	All 3/2 B.C. (8.963)	CONNECTOR, fuel filter to fuel line tee . . (3/8" I.D.)	1	442330
1959	All A.C. (8.963)	ELBOW, fuel filter to fuel tank vapor return pipe (1/4" x 90°)	1	137421
1959-60	All Circulaire A.C. . . (3.201)	vapor return pipe hose (3/16" x 90°)	1	573646
1956-59	All A.C.	ELEMENT PKG., fuel filter (A.C. GF-124K)	1	854467
1957	All F.I.	(A.C. GF-130)	1	854386
1956-57	All A.C.	GASKET, fuel filter bowl (A.C. CF-131)	1	854389
1957	All F.I.	fuel filter "O" ring (A.C. CF-136)	1	854442
1959-60	All Circulaire A.C.	HOSE, vapor return pipe connector	2	533652

1955	All 2 B.C.	NIPPLE, filter to carburetor (1/8")	1	443976
1955	All 4 B.C.	(Rochester) (1/8")	1	521615
1959	All 2 B.C. exc. A.C. . . (8.963)	filter to pump (1/4" x 1")	1	192051
1958-59	All A.C. exc. F.I.	UNION, fuel filter to fuel tank vapor return . . (1/4")	1	137413
1959	All 4 B.C.-3/2 B.C.-A.C.	VAPOR SEPARATOR PKG., fuel (A.C. GF-63)	1	854622
1959	All 3/2 B.C.	(Rochester) Center	1	7013998
1960	All A.C.	(A.C. GF-63)	1	854622

Group 3.900 FUEL PUMP PACKAGE

1939-48	All P/6 and 1939-40 28	(A.C. 496)	1	1523496
1956-57	All exc. F.I.	(type 4328) w/electric w/s wiper	1	5593941
1957	All exc. F.I.	(type 4418) w/electric w/s wiper (3/8" fuel line) . .	1	5593982
1958	All	(type 4488)	1	5621641
1959-60	All	(type 4512)	1	5621733
1939-48	All P/6 and 1939-40 28	PUMP ASSY., PKG., fuel and vacuum (A.C. 515)	1	1523515
1941-51	P/8	(type 539)	1	1523539
1949-51	P/6	(type 539)	1	1523539
1951-54	All exc. A.C.	(type 9630)	1	5592657
1954	P/8 A.C.	(type 539)	1	1523539
1955-57	All exc. F.I.	(type 4123) exc. electric w/s wiper (5/16" fuel line) .	1	5593227
1957	All exc. F.I.	(type 4417) exc. electric w/s wiper (3/8" fuel line) . .	1	5593981
1957	All F.I.	(type 4410) exc. electric w/s wiper	1	5593983

Group 3.901 CONNECTIONS, FUEL PUMP LINE

1939-50	All	ELBOW, pump inlet to hose (45°) (5/16")	1	502733
1946-54	All (8.963)	pump to manifold (90°) (1/4")	1	169983
1955-57	All (8.963)	pump to carb. (90°) (1/4")	1	169983
1957-58	All	fuel filter to carb. (35°) (1/4" to 1/8")	1	528399
1957-58	All	fuel pump to filter pipe (90°) (3/8")	AR	528504
1958	All F.I.	fuel pump filter pipe to filter (45°) (1/8")	1	531598
1959-60	All 3/2 B.C.	carburetor fuel inlet Front and rear	1	533212
1935-57	All (8.963)	NUT, pump outlet (5/16")	1	114964
1935-50	All (8.963)	pump inlet (5/16")	AR	114964
1957	All	CONNECTOR (3/8" to 1/4")	AR	528503
1957	All H.T. exc. F.I.-3/2 B.C.	filter pipe to carb. (3/8" to 1/8")	AR	528326
1957	All F.I.	fuel pump to filter pipe (3/8" to 1/8")	1	528326
1958	All 4 B.C.	filter pipe to carb. (5/8" to 1/8")	1	530635
1959	All T420E exc. A.C.	filter pipe to carb. (5/8" to 1/8")	1	530635
1960	All S.T.-2 B.C.-T425E exc. A.C.	filter pipe to carb. (5/8" to 1/8")	1	530635
1958-60	All (8.963)	fuel filter and vapor separator	AR	442323
1937-58	All (8.900)	BOLT, fuel pump mounting . . . (Hex. 3/8"-16x1-1/2")	2	454906
1959-60	All (8.900)	 (Hex. 3/8"-16 x 1")	2	180122
1937-58	All (8.964)	TUBING, pump to manifold (1/4"x25' coil)	AR	364934

Group 3.903 BOWL, FUEL PUMP

1941-52	All	w/type 9640 pump	1	5590159
1953-54	All	w/type 9640 pump	1	5590159

Group 3.904 GASKET, FUEL PUMP BOWL

1937-51	All	w/type 539 pump	1	5590040
1941-52	All	w/type 9640 pump	1	5590039
1953-54	All	w/type 9640 pump	1	5590039
1937-54	All	to block	1	412270
1955-60	All	to timing chain cover	1	412270
1955-57	All	SEAL, oil (w/A.C. D-156 diaphragm kit)	1	5592331
1955-57	All	RETAINER, oil seal (w/A.C. D-156 diaphragm kit) . . .	1	5620995

Group 3.906 BALL ASSY., FUEL PUMP BOWL

1941-52	All	w/type 9640 pump	1	5590153
1953-54	All	w/type 9640 pump	1	5590153

Group 3.910 DIAPHRAGM, FUEL PUMP PULSATOR

1957	All	(A.C. F.G.-22) w/type 4410 and 4417 pump	1	5593898
------	-----	--	---	---------

Group 3.925 KIT-DIAPHRAGM UNIT, FUEL AND VACUUM REPAIR

KIT				
1939-51	All	w/type 539 pump	1	1539000
1941-52	All	w/type 9640 pump	1	5592725
1953-54	All	w/type 9640 pump	1	5592725
1954	P/8 A.C.	w/type 539 pump	1	1539000
1955-57	All	w/type 4123 pump	1	5593528
1957	All	w/type 4417 pump-w/3/8" lines	1	5620966
1957	All	w/type 4418 pump-w/3/8" lines	1	5620967
1957	All F.I.	w/type 4410 pump	1	5620968
1958	All	w/type R415	1	5621201
1959-60	All	w/type R-422	1	5621314
DIAPHRAGM UNIT				
1937-51	All	(A.C. D-18) Fuel side	1	1538510
1937-51	All	(A.C. D-28) Vacuum side	1	1538637
1941-52	All	(A.C. D-120) w/type 9640 pump Fuel side	1	5592780
1941-52	All	(A.C. D-154) w/type 9640 pump Vacuum side	1	5593410
1953-54	All	(A.C. D-120) w/type 9640 pump Fuel side	1	5592780
1953-54	All	(A.C. D-154) Vacuum side	1	5593410
1955-57	All	(A.C. D-156) Fuel side	1	5593529
1955-57	All	(A.C. D-126) Vacuum side	1	5592863
1957	All	(A.C. D-140) w/type 4414 pump Fuel side	1	5593093
1957	All	(A.C. D-257) w/type 4417 and 4418 pump Fuel side	1	5620964
1957	All	(A.C. D-258) w/type 4410, 4414 and 4417 pump-w/3/8" lines Vacuum side	1	5620965
1957	All F.I.	(A.C. D-217) Fuel side	1	5620560
1958	All	(A.C. D-253) Vacuum side	1	5620959
1958-60	All	(A.C. D-217) Fuel side	1	5620560
1937-51,				
1954	All	OIL SEAL & GASKET PKG., fuel pump w/type 539 pump	1	5591805
		ECCENTRIC AND BUSHING PKG., (see Group 0.737 for use)		523024