

YEAR	MODEL	PART NAME	PART NO.	PER CAR	PART NO.
Group 11.005 SASH CHANNEL, REAR QUARTER WINDOW UPPER					
1949-52	2537-67 All			2	4170830
1953-54	2537, 2837 All	Upper and rear		2	4151694
1953-54	2567, 2867			2	4151675
1955-57	25/2737, 2837 All			2	4156611
1955-57	2867 All			2	4156751
1958	2547SD			2	4238137
1958	2567 All			2	4238139
1958	2731, 2831 All			2	4237124
1959-60	2137, 2337, 2837		4301766 RH		4301767 LH
1959-60	2167, 2867			2	4301702

Group 11.007 SASH CHANNEL, REAR QUARTER WINDOW LOWER					
1949-52	2507-11 All		4561166 RH		4561167 LH
1949-52	2537-67 All	Front and lower	4177727 RH		4177728 LH
1953-54	2537, 2837 All	Front and lower			4150643 LH
1953-54	2567, 2867	Front and lower	4150856 RH		4150857 LH
1955-57	25/2711 All	w/manual reg.	4673301 RH		4673302 LH
1955-56	25/2711 All	w/electric regulator	4673303 RH		4673304 LH
1955-57	25/2737, 2837 All	Front and lower	4156612 RH		4156613 LH
1955-57	25/2763 F All		4650568 RH		
1955-57	2867 All	Front and lower	4156754 RH		4156755 LH
1958	2547SD	Front and lower	4238132 RH		4238133 LH
1958	2567 All	Front and lower	4238140 RH		4238141 LH
1958	2731, 2831 All	Front and lower	4237128 RH		4237129 LH
1958	2741		4720234 RH		4720235 LH
1959-60	2111, 2411		4780679 RH		4780680 LH
1959-60	2137, 2337, 2837	Front and lower	4301770 RH		4301771 LH
1959-60	2167, 2867	Front and lower	4301704 RH		4301705 LH
1958	2741	CLIP, rear qtr. window reg. cam		2	4722456
All	All (10.696)	FILLER, lower sash channel (.032" thick)		AR	603954
All	All (10.696)		(.047" thick)	AR	603955
1958	2547 SD	ROLLER, qtr. window lower sash channel		4	4626457
1942-48	2567	SCREW, front to upper sash channel		4	4135226
1956-57	2737, 2837-67 All (8.908)	rear qtr. window upper sash channel	Front (No. 8-32x1/4")	4	456288
1958	2547-67, 2731, 2831 All (8.908)	rear qtr. window upper sash channel	Front (No. 8-32x1/4")	4	456288

Group 11.008 CHANNEL, REAR QUARTER WINDOW					
1949-50	2561-62 All	(A)	3808250 RH		3808249 LH
1949-54	2561-62 All (12.180)	stationary glass		2	4162630
1951-52	2562 All	stationary window		2	4598511
1951-52	2562 All	sliding window	4598547 RH		4598548 LH
1953-54	2562	sliding window	4598547 RH		4598548 LH
1953-54	2562	stationary window		2	4598511
1953-54	2562 F-62 DF	stationary window		2	4603465
1955-57	25/2719, 2819 All	stationary vent	4646946 RH		4646947 LH
1955-57	25/2763 F			2	4643201
1955-57	25/2764 DF	stationary window	Outer 4658490 RH		4658491 LH

1955-57	25/2762-62 FC	vent. glass	4156948 RH	4156949 LH
1955-57	25/2762-62 FC-63 F	stationary window	2	4653560
1955-57	25/2762 DF-62 SDF	stationary window	2	4653558
1955-57	25/2764 DF	stationary window	4662969 RH	4662970 LH
1955-57	25/2764 DF	sliding window	Lower 4664209 RH	4664210 LH
1955-57	25/2764 DF	sliding window	Inner 4658492 RH	4658493 LH
1958	2794	sliding window	Outer	2 4726455
1958	2794	stationary window	Inner	2 4726168
1958	2794	stationary window	2	4727962
1958	2793 All	stationary window	2	4727968
1959-60	2119, 2419	stationary	4758237 RH	4758238 LH
1959-60	2135-45, 2735	stationary	4760528 RH	4760529 LH
1959-60	2135-45, 2735	stationary vent	4760438 RH	4760439 LH
1960	2111, 2411 (10.716)		2	4782199
1955-57	25/2763 F	MOLDING, rear qtr. wind. div.	Outer	2 4656557
1955-57	25/2763 F		Inner	2 4678247
1955-57	25/2763 F	RETAINER, rear qtr. wind. div. mldg.	Outer	2 4653385
1955-57	25/2763 F		Inner	2 4653386
1956-57	2763 F	GROMMET, rear qtr. wind. div. mldg.	Outer	4 4650840
1956-57	2763 F		Inner	4 4683814

▲NOTE: Cut to size and form, using old part as template.

Group 11.010 LATCH, REAR QUARTER SLIDING GLASS

1955-58	25/2764 DF-94		4663731 RH	4663732 LH
1949-51	2561-62 All (10.559)	KNOB, sliding window locking rod	2	4661023
1952	2562 All (10.559)	sliding window (coral)	2	4735934
1958	2794	PLATE, qtr. sliding wind. front glass run finish	2	4746122
1955-57	25/2764 DF	STRIKER, sliding window latch	2	4663807
1958	2794		2	4726739

Group 11.011 GLASS, REAR QUARTER WINDOW (SAFETY)

1949-52	2562 All	stationary half	2	4562269
1949-52	2562 All	sliding half	2	4562268
1953-54	2511 All		2	4599419
1953-54	2537, 2837 All		2	4600839
1953-54	2562	sliding half	2	4603276
1953-54	2562 F-62 DF	stationary	2	4602745
1953-54	2511 All	e-ze-eye	2	4612515
1953-54	2537, 2837 All	e-ze-eye	2	4612517
1955-57	25/2711 All		2	4649356
1955-57	25/2711 All	e-ze-eye	2	4649357
1955-57	25/2719, 2819 All		2	4646108
1955-57	25/2719, 2819 All	e-ze-eye	2	4646109
1955-57	25/2737, 2837 All		2	4647515
1955-57	25/2737, 2837 All	e-ze-eye	2	4647516
1955-57	25/2762 DF-62 SDF	stationary	4647555 RH	4647556 LH
1955-57	25/2762 DF-62 SDF	stationary e-ze-eye	4647557 RH	4647558 LH
1955-57	25/2762-62 FC-63 F	stationary	4647559 RH	4647560 LH
1955-57	25/2762-62 FC-63 F	stationary e-ze-eye	4647561 RH	4647562 LH
1955-57	25/2763 F		2	4652010
1955-57	25/2763 F	e-ze-eye	2	4652011
1955-57	25/2764 DF	stationary	4660809 RH	4660810 LH
1955-57	25/2764 DF	stationary e-ze-eye	4660811 RH	4660812 LH
1955-57	25/2764 DF	sliding	2	4662708
1955-57	25/2764 DF	sliding e-ze-eye	2	4662709
1955-57	2867 All		2	4646346
1955-57	2867 All	e-ze-eye	2	4646347

1958	2547 SD			2	4721750
1958	2547 SD	e-ze-eye		2	4721751
1958	2567 All			2	4714178
1958	2567 All	e-ze-eye		2	4714179
1958	2731, 2831 All			2	4715649
1958	2731, 2831 All	e-ze-eye		2	4715650
1958	2741			2	4718829
1958	2741	e-ze-eye		2	4718830
1958	2793 All	stationary		2	4725282
1958	2793 All	stationary e-ze-eye		2	4725283
1958	2794	sliding		2	4725276
1958	2794	sliding e-ze-eye		2	4725277
1958	2794	stationary		2	4725284
1958	2794	stationary e-ze-eye		2	4725285
1959	2111, 2411			2	4758558
1959	2111, 2411	e-ze-eye		2	4758559
1959-60	2119, 2419	stationary		2	4758068
1959-60	2119, 2419	stationary e-ze-eye		2	4758069
1959-60	2135-45, 2735	stationary	4748941 RH		4748942 LH
1959-60	2135-45, 2735	stationary e-ze-eye	4748943 RH		4748944 LH
1959-60	2135-45, 2735	stationary vent		2	4760451
1959-60	2135-45, 2735	stationary vent e-ze-eye		2	4760452
1959-60	2137, 2337, 2837			2	4811998
1959-60	2137, 2337, 2837	e-z-eye		2	4811999
1959-60	2167, 2867			2	4812789
1959-60	2167, 2867	e-ze-eye		2	4812790
1960	2111, 2411			2	4801687
1960	2111, 2411	e-ze-eye		2	4801688

Group 11.012 STOP, REAR QUARTER WINDOW GLASS

1953-54	2537, 2837 All	(10.715)		2	4614039
1955-57	25/2711-37, 2837 All		Lower	2	4626151
1955-57	25/2737, 2837 All		Upper	2	4692356
1956-57	2711		w/electric regulator	Lower	2 4678376
1958	2547, 2731, 2831 All		Upper	2	4692356
1958	2547, 2731, 2831 All		Lower	2	4626151
1958	2567 All		Upper	4602176 RH	4602177 LH
1959-60	2137, 2337, 2837		Upper	2	4753877
1959-60	2137, 2337, 2837		Lower	2	4626151
1956-57	2737, 2837	(10.715)	SCREW, qtr. wind. stop bumper adj.	2	4087403
1955	2511 All		WASHER, rear qtr. wind. stop-w/electric reg.	AR	4663454

Group 11.013 BUMPER, REAR QUARTER WINDOW STOP

1956-57	2763 F	(10.716)	Front	2	4782199
1953-54	2511 All	(10.716)		2	4131052
1953-54	2562			2	4603823
1955-57	25/2711 All	(10.726)	anti rattle	2	4091152
1955-57	25/2764 DF			2	4663538
1955-60	2167, 2567, 2867 All			2	4665181
1959	2111, 2411	(10.716)		2	4782199
1958	2739-41, 2839 All		Lower	2	4114117
1958	2794		sliding window stop	2	4758400
1941-52	All exc. 2567	(10.716)		AR	4782199
1960	2167, 2867		CLIP, rear qtr. wdw. stop bumper retainer	2	4805767
1953-54	2537, 2837 All	(10.716)	CUSHION, qtr. wind. stop adj. plate	4	4099476
1958	2741		SUPPORT, lower bumper	2	4733826

Group 11.015 WEATHERSTRIP, REAR QUARTER WINDOW

1940	2511, 2619, 2927 . . . (10.710)	stainless bead	2	4102157
1941-48	2511, 2607 (10.710)	stainless bead. Lower	2	4102157
1941-48	2519-69 All	stainless bead		4114873 LH
1949-54	2507-11-37-67, 2837 All (10.710)	stainless bead	2	4102157
1949-52	2537-67 All	at frame Front	4562592 RH	4562593 LH
1951-54	2562 All	sliding or stationary window (13-5/8" long)	4627098 RH	4627099 LH
1952	2537-67	on lock pillar Lower Front	2	4615019
1953-54	2537, 2837 All	at frame (13-3/8" long)	4602583 RH	4602584 LH
1953-54	2537, 2837 All	(6-13/16" long) Inner Upper	4604327 RH	4604328 LH
1953-54	2537-67, 2837-67 All	on lock pillar Lower front	2	4607180
1953-54	2567, 2867	at frame (13-3/16" long)	4602953 RH	4602954 LH
1955-57	25/2711 All	 Inner	4648041 RH	4648042 LH
1955-57	25/2711 All	 Outer	4647470 RH	4647471 LH
1955-57	25/2737, 2837 All	 Inner	4649733 RH	4649334 LH
1955-57	25/2737, 2837 All	 Outer	4157020 RH	4157021 LH
1955-57	25/2737, 2837 All	on lock pillar Upper corner	4649432 RH	4649433 LH
1955-57	25/2737, 2837 All	at frame	4648220 RH	4648221 LH
1955-57	2867 All	at frame	4646917 RH	4646918 LH
1955-57	2867 All	 Inner	4648166 RH	4648167 LH
1955-57	2867 All	 Outer	4157138 RH	4157139 LH
1955-57	2867 All	on lock pillar Upper corner	2	4648555
1955-57	25/2762-62 FC	rear qtr. vent	4156946 RH	4156947 LH
1955-57	25/2764 DF	sliding wind. div. channel	4663415 RH	4663416 LH
1956-57	2737	rear qtr. window Outer	4678321 RH	4678322 LH
1956-57	2763 F (10.710)	stainless bead	2	4102157
1958	2547 SD	 Front	4717787 RH	4717788 LH
1958	2547 SD	 Outer	4237978 RH	4237979 LH
1958	2547 SD	 Upper	4717624 RH	4717625 LH
1958	2547 SD	at frame	4720281 RH	4720282 LH
1958	2547 SD	on lock pillar Upper corner	4720684 RH	4720685 LH
1958	2547 SD	sealing	4722420 RH	4722421 LH
1958	2567 SD	 Inner	4715867 RH	4715868 LH
1958	2567 All	 Outer	4237758 RH	4237759 LH
1958	2567 All	at frame	4721009 RH	4721010 LH
1958	2567 All	on lock pillar Upper corner	4721748 RH	4721749 LH
1958	2731, 2831 All	 Inner front	4716996 RH	4716997 LH
1958	2731, 2831 All	 Outer front	4750320 RH	
1958	2731, 2831 All	 Outer		4750321 LH
1958	2731, 2831 All	 Outer rear	4750320 RH	
1958	2731, 2831 All	 Upper	4717622 RH	4717623 LH
1958	2731, 2831 All	at frame	4720283 RH	4720284 LH
1958	2731, 2831 All	on lock pillar Upper corner	4720892 RH	4720893 LH
1958	2731, 2831 All	sealing	4722220 RH	4722221 LH
1958	2741	 Inner front	4722476 RH	4722477 LH
1958	2741	 Inner rear	4724604 RH	4724605 LH
1958	2741	 Outer	4722665 RH	4722666 LH
1959-60	2111, 2411	 Inner	2	4761904
1959-60	2111, 2411	 Outer	4761631 RH	4761632 LH
1959-60	2137, 2337, 2837	 Inner	4780368 RH	4780369 LH
1959-60	2137, 2337, 2837	 Outer	4758351 RH	4758352 LH
1959-60	2137, 2337, 2837	sealing	4756904 RH	4756905 LH
1959-60	2137, 2337, 2837	at frame	4757052 RH	4757053 LH
1959-60	2137, 2337, 2837	on lock pillar Upper corner	4757953 RH	4757954 LH
1959-60	2167, 2867	 Inner	4780374 RH	4780375 LH
1959-60	2167, 2867	 Upper	4302202 RH	4302203 LH
1959-60	2167, 2867	on lock pillar Upper corner	4721898 RH	4721899 LH
1959-60	2167, 2867	at frame	4762954 RH	4762955 LH
1942-48	All (10.712)	CLIP, rear quarter window weatherstrip	AR	4113415
1949-56	25/2761-62-63-64 All (10.696)	FILLER, div. channel	AR	603954

Group 11.021 CHANNEL, REAR QUARTER WINDOW GLASS RUN

1939-40	2511, 2611 (10.701)	Lower	2	609528
1939-54	All exc. 2537-67, 2837-67 (10.759)	(▲) (82" long)	AR	4209769
1939-54	All exc. 2537-67 . . (10.701)	(▲) (38-1/4" long)	AR	4074354
1939-54	All exc. 2537-67 . . (10.701)	(▲) (55" long)	AR	4209768
1950-52	2537 All	2nd type on 1950-U shape with w-strip on both sides	4610957 RH	4610958 LH
1953-54	2537, 2837 All		4601620 RH	4601621 LH
1955-57	25/2711 All		4676848 RH	4676849 LH
1955-57	25/2737, 2837 All		4649928 RH	4649929 LH
1955-57	25/2711 All		4676848 RH	4676849 LH
1955-57	25/2763 F-64 DF . . (10.701)	(▲) (55" long)	AR	4209768
1955-57	2563 F	Rear	2	4652484
1956-57	2711 All (10.759)	(▲) (82" long)	AR	4209769
1958	2741	Upper front	4722742 RH	4722743 LH
1958	2741	Lower front	4722719 RH	4722720 LH
1958	2741	Rear	2	4722584
1959-60	2111, 2411		4760427 RH	4760428 LH
1958	2794	CHANNEL, rear qtr. sliding window glass includes weatherstrip Front	4727142 RH	4727143 LH
1955-57	25/2737, 2837 All	EXTENSION, rear qtr. wind. sealing strip Inner	4650066 RH	4650067 LH

▲NOTE: Cut to required length, using old part as a template. Also see note Group 10.701.

Group 11.024 RETAINER-SUPPORT, REAR QUARTER WINDOW GLASS CHANNEL

1955-57	25/2762-62 FC-63F	RETAINER, glass channel At belt	4651489 RH	4651490 LH
1955-57	25/2762 DF-62 SDF	At belt	4651491 RH	4651492 LH
1955-57	25/2762-63-64 All	Upper	AR	4663852
1958	2793 All	stationary window Upper	6	4650633
1958	2794	stationary window Upper	4	4726167
1959	2119, 2419	stationary Front	2	4759326
1959	2119, 2419	stationary Lower	2	4758837
1959-60	2135-45, 2735	stationary Upper	4	4759241
1959	2135-45, 2735	stationary vent	6	4759241
1959-60	2135-45, 2735	stationary vent Upper	2	4759207
1959	2135-45, 2735	stationary vent Lower	2	4758837
1960	2119, 2419	stationary Upper	4	4728124
1960	2119, 2419	stationary Lower	2	4808336
1960	2135-45, 2735	stationary Upper	6	4814792
1960	2135-45, 2735	stationary vent Lower	2	4808336
1955-57	25/2764 DF	SUPPORT, glass run channel Lower	2	4691891
1958	2794	SUPPORT, stationary window	2	4716427

Group 11.027 WEATHERSTRIP, REAR QUARTER WINDOW LOWER SASH CHANNEL

1950-54	All exc. 2537-67 . . . (10.696)	(36" long)	AR	4099014
1955-57	25/2711-63 F All		2	4211196
1958	2741		1	4273579

Group 11.031 MOLDING, REAR QUARTER WINDOW REVEAL

1953-54	2537 D	attached to roof panel (6-9/16" long)	Upper	4611963 RH	4611964 LH
---------	------------------	--	-------	------------	------------

1953-54	2537 D	(7-1/2" long) rear	4611959 RH	4611960 LH
1953-54	2537 SD, 2837 SD	side outer panel-ribbed	Upper 4618507 RH	4618508 LH
1953-54	2537, 2837 All	Lower 4611961 RH	4611962 LH	
1953-54	2567, 2867	(32-1/8" long) lower	4612685 RH	4612686 LH
1954	2869 SD	side outer panel - ribbed	Upper 4631319 RH	4631320 LH
1955	2511 All	Lower 4654245 RH	4654246 LH	
1955-56	25/2719, 2819 All D	4654247 RH	4654248 LH	
1955-57	25/2737, 2837 All	Front 4649366 RH	4649367 LH	
1955-57	25/2737 D, 2837 SD	Rear 4650064 RH	4650065 LH	
1955-57	25/2762 DF-62 SDF	Lower 4649661 RH	4649662 LH	
1955-57	25/2764 DF	Upper front 4663157 RH	4663158 LH	
1955-57	25/2764 DF	Upper rear 4663331 RH	4663332 LH	
1955-57	25/2764 DF	Lower front 4663159 RH	4663160 LH	
1955-57	25/2764 DF	Lower rear 4663333 RH	4663334 LH	
1955-57	25/2764 DF	Vertical 4682461 RH	4682462 LH	
1955	2819 SD	4648556 RH	4648557 LH	
1955-57	2867 All	4649064 RH	4649065 LH	
1955-57	2737	Rear 4678200 RH	4678201 LH	
1957	2762 SDF	Upper 4649657 RH	4649658 LH	
1958	2547 SD	4719927 RH	4719928 LH	
1958	2567 All	4716923 RH	4716924 LH	
1958	2741	painted Front 4726053 RH	4726054 LH	
1958	2741	chrome Front 4724083 RH	4724084 LH	
1958	2741	painted Upper 4726067 RH	4726068 LH	
1958	2741	chrome Upper 4724085 RH	4724086 LH	
1958	2793 SD	Lower 4727979 RH	4727980 LH	
1959-60	2111	Front 4757969 RH	4757970 LH	
1959-60	2111	Upper 4753586 RH	4753587 LH	
1959	2111	w/side wind. frame scalp mldg.	Front 4755546 RH	4755547 LH
1959-60	2111	w/side wind. frame scalp mldg.	Upper 4753425 RH	4753426 LH
1959-60	2119	Front 4752015 RH	4752016 LH	
1959-60	2119	Upper 4752004 RH	4752005 LH	
1959-60	2119	w/side wind. frame scalp mldg.	Upper 4752006 RH	4752007 LH
1959-60	2119	w/side wind. frame scalp mldg.	Front 4752017 RH	4752018 LH
1959-60	2135-45	rear qtr. rear window Front 4757348 RH	4757349 LH	
1959-60	2135-45	rear qtr. rear window Upper 4775810 RH	4775811 LH	
1959-60	2135-45	rear qtr. rear window Lower 4775815 RH	4775816 LH	
1959-60	2135-45	rear qtr. rear window Rear 4785187 RH	4785188 LH	
1959-60	2135-45	rear qtr. rear wind.-w/side wind. frame scalp mldg.	Front 4757350 RH	4757351 LH
1959-60	2135-45	rear qtr. rear wind.-w/side wind. frame scalp mldg.	Upper 4775812 RH	4775813 LH
1959-60	2135-45	rear qtr. rear wind.-w/side wind. frame scalp mldg.	Lower 4775817 RH	4775818 LH
1959-60	2135-45	rear qtr. rear wind.-w/side wind. frame scalp mldg.	Rear 4785189 RH	4785190 LH
1959-60	2135-45	stationary vent Front 4757007 RH	4757008 LH	
1959-60	2135-45	stationary vent Upper 4775598 RH	4775599 LH	
1959-60	2135-45	stationary vent-w/side wind. frame scalp	Front 4756334 RH	4756335 LH
1959-60	2135-45	stationary vent-w/side wind. frame scalp	Upper 4774894 RH	4774895 LH
1959	2167, 2867	rear qtr. wind. reveal bead	4754683 RH	4754684 LH
1959	2411	Front 4755546 RH	4755547 LH	
1959-60	2411	Upper 4753425 RH	4753426 LH	
1959-60	2419	Front 4752017 RH	4752018 LH	
1959-60	2419	Upper 4752006 RH	4752007 LH	
1959-60	2735	Front 4751216 RH	4751217 LH	
1959-60	2735	rear qtr. rear window Upper 4775812 RH	4775813 LH	

1959-60	2735		rear qtr. rear window		Lower	4775817 RH	4775818 LH
1959-60	2735		rear qtr. rear window		Rear	4785189 RH	4785190 LH
1959-60	2735		stationary vent		Front	4756334 RH	4756335 LH
1959-60	2735		stationary vent		Upper	4774894 RH	4774895 LH
1960	2111		w/Decor group		Front	4782770 RH	4782771 LH
1960	2167, 2867		head mldg.			4782571 RH	4782572 LH
1960	2411				Front	4782770 RH	4782771 LH
1948	2607-09 All	(12.116)	RETAINER, rear qtr. window reveal				
			mldg.		Lower	4125725 RH	4125726 LH
1941-48	25 All	(10.708)	CLIP, for oblong holes			AR	4114230
1941-48	25 All	(10.708)	for oblong holes			AR	4114230
1955	2819 SD	(10.708)	qtr. wind. reveal mldg.			AR	4644700
1955	2519-62 DF, 2819 All					AR	4640845
1956	2719D-62DF, 2819 D	(10.708)				AR	4703806
1957	2762 DF-62SDF	(10.708)				AR	4703806
1959-60	2111-19, 2411-19		rear qtr. wind. upper reveal mldg.			AR	4760118
1959-60	2135-45, 2735		rear qtr. stationary vents reveal mldg.		Upper	6	4775854
1959-60	2135-45, 2735		NUT, stationary vent., reveal upper mldg.			6	4807615
1959-60	2135-45, 2735	(10.708)	SCREW, rear qtr. stationary vent. front reveal mldg.			6	4765687
1960	2135-45, 2735		w/side wind. frame scalp mldg.			6	4825965
1960	2735		qtr. stationery vent front reveal mldg.			6	4825965

Group 11.040 GUIDE, REAR QUARTER WINDOW

1955-57	25/2711 All			Front	4648658 RH	4648659 LH
1955-57	25/2711 All			Rear	4648714 RH	4648715 LH
1955-57	25/2737, 2837 All			Front	4646426 RH	4646427 LH
1955-57	25/2737, 2837 All			Rear	4649253 RH	4649254 LH
1955-57	2867 All				4646986 RH	4646987 LH
1958	2547 SD			Front	4719314 RH	4719315 LH
1958	2547 SD			Rear	4719216 RH	4719217 LH
1958	2567 All				4717260 RH	4717261 LH
1958	2731, 2831 All			Front	4718264 RH	4718265 LH
1958	2731, 2831 All			Rear	4718744 RH	4718745 LH
1959-60	2111, 2411			Front	4774855 RH	4774856 LH
1959-60	2111, 2411			Rear	4757340 RH	4757341 LH
1959-60	2137, 2337, 2837			Front	4756088 RH	4756089 LH
1959-60	2137, 2337, 2837			Rear	4756090 RH	4756091 LH
1959-60	2167, 2867				4757823 RH	4757824 LH
1955-57	25/2711-37, 2837 All. (10.783)	BOLT, guide to inner panel	(1/4"-20x7/16")	AR		431577
1958	2731-41, 2831 All (10.783)	guide to inner panel	(1/4"-20x7/16")	AR		431577
1959-60	2167, 2867	PLUG, body lock pillar button		2		4786200
1959-60	2137, 2337, 2837	SCREW, guide to inner panel	Lower	4		4784211
1959-60	2137, 2337, 2837	SPACER, front guide-emergency use		AR		4784210
1950-52	2737 All	STUD, guide	Upper	4		4578800
1952-54	2537-67, 2837-67 All. (10.670)	guide to panel		AR		4084009
1955-57	25/2737, 2837 All	front guide	Upper	2		4638064
1955-57	25/2737, 2837 All	rear guide	Lower	2		4658800
1955-58	2567, 2867 All	guide	Upper	1		4578800
1958	2547, 2731, 2831 All	front guide	Upper	AR		4638064
1959-60	2137, 2337, 2837 (10.792)	front guide	Upper	4		4786425
1959	2139, 2439, 2833 (10.792)	rear cam	Upper	2		4786425
1959-60	2167, 2867 (10.792)	guide	Center	2		4786425

Group 11.041 REGULATOR, REAR QUARTER WINDOW (MANUAL)

1955-57	25/2711 All			4647475 RH	4647476 LH
1955-57	25/2737, 2837 All			4657650 RH	4657651 LH

1955-57	25/2763 F	4650571 RH	4650572 LH
1955-57	2867 D	4646460 RH	4646461 LH
1958	2547 SD	4715671 RH	4715672 LH
1958	2567 All	4714484 RH	4714485 LH
1958	2731, 2831 All	4715228 RH	4715229 LH
1958	2741	4719167 RH	4719168 LH
1959-60	2111, 2411	4753841 RH	4753842 LH
1959-60	2137, 2337, 2837	4752528 RH	4752529 LH
1959-60	2167, 2867	4752079 RH	4752080 LH

Group 11.041 REGULATOR, REAR QUARTER WINDOW (ELECTRIC)

1955-57	25/2711 All	less motor	4157332 RH	4157333 LH
1955-57	25/2737, 2837 All	less motor	4158334 RH	4158335 LH
1955-57	25/2763 F	less motor	4157346 RH	4157347 LH
1955-57	2867 All	less motor	4231094 RH	4231095 LH
1958	2547 SD	less motor	4237690 RH	4237691 LH
1958	2567 All	less motor	4237700 RH	4237701 LH
1958	2731, 2831 All	less motor	4237676 RH	4237677 LH
1958	2741	less motor	4238192 RH	4238193 LH
1959-60	2111, 2411	less motor	4302128 RH	4302129 LH
1959-60	2137, 2337, 2837	less motor	4301852 RH	4301853 LH
1959-60	2167, 2867	less motor	4302224 RH	4302225 LH
1955-57	25/2711-37-63, 2837-67 All (10.783)	MOTOR, rear qtr. wind. reg.	4905387 RH	4905388 LH
1958	2547-67, 2731-41, 2831 (10.783)		4905387 RH	4905388 LH
1959-60	2111-37-67, 2337, 2411, 2837-67 (10.783)		4905387 RH	4905388 LH
1955-57	25/2737, 2837 All (10.783)	ARMATURE, qtr. wind. reg.	2 5097146	
1956-57	2711-63, 2867 All (10.783)		2 5097146	
1958	2547-67, 2731-41, 2831 All (10.783)		2 5097146	
1959	2111-37-67, 2411, 2837-67 (10.783)	w/cylindrical type motor	2 4097146	
1959-60	2111-37-67, 2337, 2411, 2837-67 (10.783)	w/square type motor	2 4904220	
1959-60	2111-38-67, 2337, 2411, 2837-67 (10.150)	BRACKET, rear qtr. wind. reg. motor brush plate mtg.	2 4904212	
1959-60	2111-37-67, 2337, 2411, 2837-67 (10.783)	BRUSHHOLDER, rear qtr. wind. reg. motor- w/square type motor	2 4905337	
1955-56	25/2737, 2837 All (10.783)	CASE AND BRUSH, wind. reg. motor	2 5095329	
1956	2711-63, 2867 All (10.783)		2 5095329	
1957-59	All (10.783)		2 4902142	
1955	2537, 2837-67 (10.783)	COVER, motor pinion and gear	2 5091720	
1958-60	2111-37, 2337, 2411, 2547SD, 2731-41, 2831-37	rear qtr. switch protector	2 4728428	
1957-59	All (10.783)	FIELD, rear qtr. wind. reg. motor-w/cylindrical type motor	2 4901831	
1959-60	2111-37-67, 2337-67, 2411, 2837-67 (10.783)	FRAME AND FIELD, rear qtr. wind. reg. motor- w/square type motor	2 4906107	
1955-57	25/2711-37-63, 2837 All (10.783)	GEAR PKG., qtr. wind. reg.	2 4900085	
1955	2867		2 5097960	
1955-60	2167, 2567, 2867 All		2 5099592	
1958	2547, 2731-41, 2831 All (10.783)		2 4900085	

1959-60	2111-37, 2337, 2411, 2837 (10.783)	2	4900085
1959	2111-37-67, 2411, 2837-67 (10.783)	GROMMET, rear qtr. wind. reg. motor	2 4904207
1959-60	2111-37-67, 2337, 2411, 2837-67	rear qtr. wind. motor lead wire	2 4652537
1958	2547-67, 2731-41, 2831 All (10.777)	PIN, rear qtr. wind. switch button	2 4238389
1959-60	2111-37-67, 2411, 2837-67 All (10.777)	rear qtr. wind. switch button	2 4238389
1955-57	25/2737, 2837-67 All (10.783)	SET SCREW, rear qtr. wind. motor	2 5096732
1959	2111-37-67, 2411, 2867 (10.783)		2 5096732
1958	2547-67, 2731-41, 2831 All . .		2 5096732
1959-60	2111-37-67, 2337, 2411, 2837-67 (10.783)		2 5096732
1955-58	2567, 2867 All	PLATE AND BUSHING, qtr. wind. regulator sector . .	2 4154670
1959-60	2167, 2867		2 4232451
1960	2111, 2411 (10.517)	WASHER, rear qtr. window reg. spindle	2 4101894

Group 11.043 CAM, REAR QUARTER WINDOW REGULATOR

1953-55	2511-63 All (11.046)	CAM, rear qtr. window lower sash channel	2 4099974
1940-55	2507-11, 2607-11 All	At inner panel	2 4099974
1957	All exc. 2739, 2839		2 4099974
1958	2741	At inner panel	2 4722458
1958	2741		2 4722457
1959-60	2137, 2337, 2837	rear qtr. window lower sash channel	2 4754696

NOTE: Cut cam to required length using old part as template.

Group 11.044 HANDLE, REAR QUARTER WINDOW REGULATOR

1941	2511 (10.797)		2 4131350
1941-48	2607 (10.797)		2 4131350
1949	2567 (10.797)	black plastic knob	2 4615414
1949-52	2507-11 All (10.797)	black plastic knob	2 4615414
1950-52	2537-67 All	black plastic knob	2 4584639
1951	2507-11 All (10.797)	chrome serrated knob	2 4615413
1951	2537-67 All	chrome serrated knob	2 4592281
1953-54	2511-37-67, 2837-67 All (10.797)	chrome serrated knob	2 4615413
1955	2511-37-62-63, 2837-67 All (10.797)		2 4648809
1956	2711-37-63 F (10.797)		2 4684665
1956	2737 D, 2837-67 All (10.797)		2 4678333
1957	2711-37-63 All (10.797)		2 4694277
1957	2837-67 D All (10.797)		2 4713904
1958	All exc. D & SD (10.797)	grey	2 4735811
1958	All exc. D & SD (10.797)	green	2 4735812
1958	All exc. D & SD (10.797)	blue	2 4735813
1958	All exc. D & SD (10.797)	red	2 4735814
1958	All D & SD (10.797)		2 4719607
1959	2111-37-67 (10.797)		2 4759438
1959-60	2337, 2411, 2837-67 (10.797)		2 4753531
1960	2111-37-67 (10.797)		2 4719607
1960	2111, 2411 (10.806)	SPRING, rear qtr. wind. reg. handle-emergency use . .	2 4566746

Group 11.047 PLATE, REAR QUARTER WINDOW REGULATOR HANDLE

1949-52	All exc. 2561-62	(10.515)	inside handle bearing	AR	4565043
1949-52	All	(10.515)	trim protector-under handle-emergency use	AR	4177710
1953-60	All	(10.515)	inside handle bearing	AR	4782769
1955-57	25/2711 All	(10.806)	SPRING, escutcheon	2	4566746
1959	2111-37-67, 2411, 2837-67	(10.806)	rear qtr. wind.	4	4566746
1942-48	2607 All	(10.517)	WASHER, door lock inside handle-rubber (7/32" I.D.)	2	3686114
1949	2507-11 All	(10.517)	rubber (7/32" I.D.)	2	3686114
1949-55	2537-67, 2837-67 All	(10.517)	escutcheon-rubber (7/32" I.D.)	2	3686114
1955-57	25/2711 All	(10.517)	rear qtr. window reg.-rubber (7/32" I.D.)	2	3686114
1958	2547 SD, 2731-41, 2831 D-31 SD		rear qtr. inner panel at reg.-rubber	1	4728429
1958	2567 All		rear qtr. inner panel at reg.-rubber	2	4625899
1959-60	2167, 2867		rear qtr. inner panel at reg.-rubber	2	4625899
1959	2137, 2837		rear qtr. window reg.-rubber	2	4601979

Group 11.052 HINGE, REAR QUARTER WINDOW

1953-54	2537-67, 2837-67 All	female half	4606826 RH	4606827 LH
1955-60	2167, 2567, 2867 All	female half	4606826 RH	4606827 LH

Group 11.053 BUSHING, REAR QUARTER WINDOW HINGE PIVOT

1942-52	2537-67 All		4	4613557
---------	-----------------------	--	---	---------

Group 11.054 PLATE, REAR QUARTER WINDOW HINGE ADJUSTING

1949-54	2537-67, 2837-67 All		4562263 RH	4562264 LH
1955-60	2167, 2547, 2867 All		4562263 RH	4562264 LH

Group 11.057 BOLT-STUD, REAR QUARTER WINDOW HINGE PIVOT

1953-54	2537-67, 2837-67	BOLT, hinge pivot. (Hex. hd. 3/8"-24x1-7/8")	2	4607677
1955-60	2167, 2567, 2867 All		2	4607677
1949-54	2537-67, 2837-67 All	STUD, hinge adjusting (Hex. hd. 3/8"-24x1-7/8")	4	4557324
1955-60	2167, 2567, 2867 All		4	4557324

Group 11.060 MOLDING, FRONT DOOR VENTILATOR GARNISH

1955	2537D-64DF, 2837SD-67		4648202 RH	4648203 LH
1956-57	2737, 2837 All		4648202 RH	4648203 LH
1956-57	2739-64, 2839-67 All		4680029 RH	4680030 LH
1958	2741-49, 2849 All		4732987 RH	4732988 LH
1959	2111-19-35-45, 2411-19, 2735		4775898 RH	4775899 LH

Group 11.075 MOLDING, FRONT DOOR WINDOW GARNISH

1947-48	2567	chrome	4135035 RH	4135036 LH
1949-50	2537-67 All	1st type on		
		1950 (39" long at top of mldg.)	4570131 RH	4570132 LH
1950-51	2537-67 All	2nd type on 1950		
		Chrome (38-1/2" long at top of mldg.)	4597030 RH	4597031 LH

1951	2527-27B All		4593228 RH	
1951	2537-67 All	silver pattern transfer	4605054 RH	4605055 LH
1952	2537-67 All		4610816 RH	4610817 LH
1953	2511		4639661 RH	4639662 LH
1953	2511 D	w/bead	4621160 RH	4621161 LH
1953	2569-71		4639526 RH	4639527 LH
1953	2569 D	w/bead	4621142 RH	4621143 LH
1953-54	2537-67, 2837-67 All		4639657 RH	4639658 LH
1953	2562-62 F	paint-beige	4639681 RH	4639682 LH
1953	2562 DF	grain finish w/bead	4621506 RH	4621507 LH
1953	2562 DF	prime-less bead	4621508 RH	4621509 LH
1954	2511 All		4639661 RH	4639662 LH
1954	2562 All		4639681 RH	4639682 LH
1954	2569, 2869 All		4639526 RH	4639527 LH
1955-57	25/2711-63 All		4656678 RH	4656679 LH
1955-57	25/2719-62, 2819 All		4657382 RH	4657383 LH
1955-57	25/2737, 2837-67 D All	with w/strip retainer	4698302 RH	4698303 LH
1955-57	25/2764 DF		4705773 RH	4705774 LH
1956-57	2739, 2839 All		4675216 RH	4675217 LH
1956	2764DF	2nd type-with w/strip retainer	4698297 RH	4698298 LH
1957	2719-62 FC-62 DF, 2819 All		4657382 RH	4657383 LH
1957	2762 SDF		4718678 RH	4718679 LH
1957	2867 SD		4719220 RH	4719221 LH
1958	2547-67 All		4748291 RH	4748292 LH
1958	2731, 2831 All		4748308 RH	4748309 LH
1958	2739, 2839 All		4748354 RH	4748355 LH
1958	2741		4748328 RH	4748329 LH
1958	2749, 2849 All		4750384 RH	4750385 LH
1958	2793-94 All		4733019 RH	4733020 LH

Group 11.085 SUPPORT, FRONT DOOR GARNISH MOLDING

1958	All exc. 2793-94	Front	4750277 RH	4750278 LH
1958	2749, 2849D-49SD	Rear	4723937 RH	4723938 LH

Group 11.086 BEAD, DOOR WINDOW GARNISH MOLDING

1953	2511 D		4151824 RH	4151825 LH
1953	2569 D		4151826 RH	4151827 LH
1953	2562 DF		4621618 RH	4621619 LH

Group 11.089 MOLDING-CAP, REAR DOOR WINDOW GARNISH

1953	2569	MOLDING	4621121 RH	4621122 LH
1953	2569 D	w/bead	4621123 RH	4621124 LH
1953	2562 DF	grain finish-w/bead	4621514 RH	4721515 LH
1953	2562 DF	prime-less bead	4621516 RH	4621517 LH
1954	2569, 2869 All		4639498 RH	4639499 LH
1955-57	25/2719, 2819 All		4657370 RH	4657371 LH
1955-57	25/2762-62 FC-62 DF		4675120 RH	4675121 LH
1956	2739 All	black	4694110 RH	4694111 LH
1956	2739 All	red	4676442 RH	4676443 LH
1956	2739 All	grey	4676444 RH	4676445 LH
1956	2739 All	green	4676446 RH	4676447 LH
1956	2739 All	blue	4676448 RH	4676449 LH
1956	2839 SD	tan	4676450 RH	4676451 LH
1956	2839 SD	blue	4676452 RH	4676453 LH

1957	2739 All	grey	4697842 RH	4697843 LH
1957	2739 All	blue	4697832 RH	4697833 LH
1957	2739 All	green	4697834 RH	4697835 LH
1957	2762 SDF	chrome	4718680 RH	4718681 LH
1957	2839 SD	silver	4697836 RH	4697837 LH
1957	2839 SD	red	4697838 RH	4697839 LH
1957	2839 SD	green	4697840 RH	4697841 LH
1957	2839 SD	blue	4709675 RH	4709676 LH
1958	2739, 2839 D	green	4732345 RH	4732346 LH
1958	2739, 2839 D	blue	4732347 RH	4732348 LH
1958	2739, 2839 D	grey	4732349 RH	4732350 LH
1958	2739, 2839 D	red	4747085 RH	4747086 LH
1958	2749, 2849 All		4732489 RH	4732490 LH
1958	2793-94 All		4733074 RH	4733075 LH
1958	2839 SD	blue	4732351 RH	4732352 LH
1958	2839 SD	green	4732353 RH	4732354 LH
1958	2839 SD	copper	4732355 RH	4732356 LH
1958	2839 SD	turquoise	4732357 RH	4732358 LH
1958	2839 SD	grey	4732359 RH	4732360 LH
1956	2739 All	CAP, rear dr. wind. garnish mldg.-		
		green-plain	4231214 RH	4231215 LH
1956	2739 All	green-plain	4231214 RH	4231215 LH
1956	2739 All	blue-plain	4231216 RH	4231217 LH
1956	2739 D	red-plain	4231210 RH	4231211 LH
1956	2739 D	grey-plain	4231212 RH	4231213 LH
1956	2839 SD	tan-plain	4231218 RH	4231219 LH
1956	2839 SD	blue-plain	4231220 RH	4231221 LH
1956	2739 All	black-ribbed	4233476 RH	4233477 LH
1956	2739 All	green-ribbed	4233492 RH	4233493 LH
1956	2739 All	blue-ribbed	4233494 RH	4233495 LH
1956	2739 D	red-ribbed	4233488 RH	4233489 LH
1956	2739 D	grey-ribbed	4233490 RH	4233491 LH
1956	2839 SD	tan-ribbed	4233496 RH	4233497 LH
1956	2839 SD	blue-ribbed	4233498 RH	4233499 LH
1957	2739 All	blue	4234682 RH	4234683 LH
1957	2739 All	green	4234684 RH	4234685 LH
1957	2739 All	grey	4234692 RH	4234693 LH
1957	2839 SD	silver	4234686 RH	4234687 LH
1957	2839 SD	red	4234688 RH	4234689 LH
1957	2839 SD	green	4234690 RH	4234691 LH
1957	2839 SD	blue	4235970 RH	4235971 LH
1958	2739, 2839 D	green	4239961 RH	4239962 LH
1958	2739, 2839 D	blue	4239963 RH	4239964 LH
1958	2739, 2839 D	grey	4239965 RH	4239966 LH
1958	2739, 2839 D	red	4300988 RH	4300989 LH
1958	2839 SD	blue	4239967 RH	4239968 LH
1958	2839 SD	green	4239969 RH	4239970 LH
1958	2839 SD	copper	4239971 RH	4239972 LH
1958	2839 SD	turquoise	4239973 RH	4239974 LH
1958	2839 SD	grey	4239975 RH	4239976 LH

Group 11.089 MOLDING, REAR DOOR VENTILATOR GARNISH

1958	2749, 2849 D	4733036 RH	4733037 LH
1958	2848 SD	4733047 RH	4733048 LH

Group 11.101 BEAD, REAR DOOR WINDOW GARNISH MOLDING

1946-48	2519 All	(11.086)	4147077 RH	4147078 LH
1953	2562 DF-69 D			2 4621599

Group 11.102 WEATHERSTRIP, REAR DOOR GARNISH MOLDING

1956-57	2739, 2839 All	4670888 RH	4670889 LH
---------	----------------	------------	------------

Group 11.113 BEAD, REAR QUARTER WINDOW GARNISH MOLDING

1946-48	2507-11-19-27- 27B All	(11.086)	4147077 RH	4147078 LH
1953	2511 D		4151890 RH	4151891 LH
1953	2562 DF		4621620 RH	4621621 LH

Group 11.118 WEATHERSTRIP, REAR QUARTER WINDOW GARNISH MOLDING

1940	2511, 2927	(10.710)	w-stainless bead	Outer	2	4102157
1941-54	All exc. 2527-27B	(10.710)	w-stainless bead	Outer	2	4102157
1955	2563 F	(10.710)	w/stainless bead	Outer	2	4102157

Group 11.119 MOLDING, REAR QUARTER WINDOW GARNISH

1949-51	2567			4585950 RH	4585951 LH
1950-51	2537 All	chrome		4580132 RH	4580133 LH
1951	2537 All	silver pattern transfer		4603672 RH	4603673 LH
1952	2537 All			4610818 RH	4610819 LH
1953	2511 D	w/bead		4621150 RH	4621151 LH
1953	2562	paint-beige		4621131 RH	4621132 LH
1953	2562 F	grain finish		4621518 RH	4621519 LH
1953	2562 F	paint-beige		4621520 RH	4621521 LH
1953	2562 DF	grain finish-w/bead		4621522 RH	4621523 LH
1953	2562 DF	prime-less bead		4621524 RH	4621525 LH
1955-57	25/2711 All			4656728 RH	4656729 LH
1955-57	25/2719, 2819 All			4657416 RH	4657417 LH
1955-57	25/2737, 2837 All			4657274 RH	4657275 LH
1955-57	25/2762 All		Front	4675437 RH	4675438 LH
1955-57	25/2762-63 All		Rear	4675455 RH	4675456 LH
1955-56	25/2763F		Front	4675443 RH	4675444 LH
1955-57	25/2764 DF		Front	4662054 RH	4662055 LH
1955-57	25/2764 DF		Front	4675272 RH	4675273 LH
1955-57	25/2764 DF		Rear	4675023 RH	4675024 LH
1955-57	2867 D			4657288 RH	4657289 LH
1957	2763 F		Front	4678248 RH	4678249 LH
1957	2867 SD			4719222 RH	4719223 LH
1958	2547 SD		Front	4732600 RH	4732601 LH
1958	2547 SD		Rear	4719459 RH	4719460 LH
1958	2567 All			4735209 RH	4735210 LH
1958	2731, 2831 All	w/stainless steel side roof rail.	Rear	4731927 RH	4731928 LH
1958	2731		Rear	4731934 RH	4731935 LH
1958	2731, 2831 All		Lower	4732527 RH	4732528 LH
1958	2741		Lower	4732561 RH	4732562 LH
1958	2741		Upper front	4733091 RH	4733092 LH
1958	2741		Rear	4733108 RH	4733109 LH
1958	2793 All		Front	4733175 RH	4733176 LH
1958	2793 All		Rear	4733148 RH	4733149 LH
1958	2793-94 All	extension			2 4733224
1958	2794		Front	4733194 RH	4733195 LH

1958	2794	Rear	4733209 RH	4733210 LH
1958	2839 SD-49 SD		4732545 RH	4732546 LH
1959-60	2111-2411		4788278 RH	4788279 LH
1959	2111-19, 2419	Front	4765302 RH	4765303 LH
1959-60	2135-45, 2735	Front	4763157 RH	4763158 LH
1959-60	2135-45, 2735	Upper front	4763294 RH	4763295 LH
1959-60	2135, 2735	Lower front	4763209 RH	4763210 LH
1959-60	2135-45, 2735	Upper rear	4763317 RH	4763318 LH
1959-60	2135, 2735	Lower rear	4763260 RH	4763261 LH
1959-60	2135-45, 2735	Rear	4763340 RH	4763341 LH
1959-60	2135-45, 2735	stationary vent Front	4763123 RH	4763124 LH
1959-60	2135-45, 2735	stationary vent Rear	4763140 RH	4763141 LH
1959	2145	Lower front	4763249 RH	4763250 LH
1959	2145	Lower rear	4787963 RH	4787964 LH
1959-60	2735	stationary vent. head	Inner	2 4758822
1960	2119, 2419	Front	4788007 RH	4788008 LH
1960	2145	Lower front	4787939 RH	4787940 LH
1960	2145	Lower rear	4787963 RH	4787964 LH
1955-57	25/2762-63-64 All	SPACER, rear qtr. wind. garn. mldg.	AR	4665983
1958	2793-94 All	SUPPORT, rear qtr. wind. garnish mldg.	4	4727921

Group 11.120 MOLDING, BACK WINDOW GARNISH

1953-54	2511-69, 2869 All	4639164 RH	4639165 LH
1955	2511-19, 2819 All	Side 4676643 RH	
1955-56	25/2711-19, 2819 All	Side	4676644 LH
1955	2511-19, 2819 All	Upper	1 4676522
1955-57	25/2737 All	Side 4662973 RH	4662974 LH
1955-57	2837 All	Side 4647462 RH	4647463 LH
1955-57	25/2737, 2837 All	Upper	1 4647461
1956	2719 D, 2819 D	Upper	1 4676522
1956	2719 D, 2819 D	Side 4676643 RH	
1956-57	2739, 2839 All	Side 4670691 RH	4670692 LH
1956-57	2739, 2839 All	Upper	1 4670693
1957	2719 D, 2819 D-19 SD	Upper	1 4698018
1957	2719 D, 2819 D-19 SD	Side 4698022 RH	4698023 LH
1958	2547 SD	Upper	1 4717597
1958	2547 SD	Lower 4733318 RH	4733319 LH
1958	2547 SD	Lower corner 4719140 RH	4719141 LH
1958	27-28 All exc. 2793-94	Side 4733270 RH	4733271 LH
1958	27-28 All exc. 2793-94	Center	1 4733288
1959	2111, 2411 All	Side 4767648 RH	4767649 LH
1959	2111-19	w/back wind. upper garnish mldg.	1 4767672
1959	2119, 2419	Side 4767589 RH	4767590 LH
1959	2137	w/back wind. upper garnish mldg.	1 4763464
1959	2137	Side 4763456 RH	4763457 LH
1959	2137	w/painted side roof rail mldgs. Side 4763435 RH	4763436 LH
1959	2139, 2439	Upper 4785468 RH	4785469 LH
1959	2139, 2439	Side 4764873 RH	4764874 LH
1959-60	2411-19	Upper	1 4765276
1959-60	2837	Upper	1 4765769
1959-60	2837	Side 4783173 RH	4783174 LH
1959-60	2839	Upper 4785463 RH	4785464 LH
1959	2839	Side 4765775 RH	4765776 LH
1960	2111, 2411	Side 4788420 RH	4788421 LH
1960	2119, 2419	Side 4788431 RH	4788432 LH
1960	2137, 2337	Side 4790416 RH	4790417 LH
1960	2139, 2339, 2439	Upper 4788409 RH	4788410 LH
1960	2139, 2339, 2439	Side 4803298 RH	4803299 LH
1960	2839	Side 4803294 RH	4803295 LH

Group 11.128 SCREW, WINDOW GARNISH MOLDING (SHEET METAL)

1953-54	2511-62-69-71 All . . . (8.977)	front door window (No. 8x3/4")	4	9414754
1953-57	25/2711-19-62-71, 2819-69 (8.977)	front door window (No. 8x5/8")	AR	9415633
1953-57	25/2762-63 All (8.977)	rear qtr. window (No. 8x5/8")	AR	9415633
1953-54	2562 All (8.977)	lift gate window (No. 8x3/4")	8	9414754
1953-57	25/2737, 2837 All . . . (8.977)	back window-lower (No. 8x1-1/2")	7	145420
1955-57	25/2711 All (8.977)	rear qtr. window (No. 8x3/4")	2	9414754
1955-57	25/2719-62, 2819 All . (8.977)	rear door window (No. 8x3/4")	4	9414754
1955-57	25/2719-62-63-64, 2819 All (8.977)	rear qtr. window-rear (No. 8x1-1/2")	4	145420
1955-57	25/2719, 2819 All . . . (8.977)	rear qtr. window (No. 8x1")	AR	9414756
1955	2562-63 All (8.977)	lift gate window (No. 8x3/4")	12	186575
1955	2564 DF (8.977)	rear qtr. window upper, front and rear (No. 8x1-1/4")	6	145419
1955	2564 DF (8.977)	rear qtr. window-front (No. 8x3/4")	4	9414754
1956-57	2711-19, 2819 All . . . (8.977)	back window (No. 8x1")	AR	9414756
1956-57	2737-39, 2837-39 All . (8.977)	back window-upper and side (No. 8x1-1/4")	AR	145419
1956-57	2762-63 All (8.977)	lift gate window (No. 8-15x3/4")	7	9414754
1956-57	2762-63 All (8.977)	rear qtr. window-front and rear . . (No. 8x1-1/4")	AR	145419
1958	2749, 2849 All (10.695)	rear door vent, garnish mldg.	2	4651543
1958	2793-94 All (8.977)	front and rear door (No. 8x5/8")	AR	9415633
1959	2111-19-35-45, 2411-19, 2735	front door vent (Oval Hd. No. 8-32x7/16")	6	4776962
1959	2111-19-35-45, 2411-19, 2735 (14.651)	front door vent (Rd. Hd. No. 8-18x7/16")	2	4714792
1959-60	All (10.056)	back wind. side (Oval Hd. No. 8-18x1")	AR	4756680
1959-60	All (10.056)	rear qtr. wind. (Oval Hd. No. 8-18x1")	AR	4756680
1959-60	2135-45, 2735 (10.056)	rear qtr. wind. (Oval Hd. No. 8-18x1-3/4")	AR	4759799
1959-60	2135-45, 2735 (10.056)	tail gate wind. (Oval Hd. No. 8-18x1-3/4")	AR	4759799
1960	2135-45	front qtr. stationary vent, reveal mldg.	6	4816670
1959-60	2135-45, 2735 (8.977)	rear qtr. window (No. 8-15 x 3/4")	Rear	AR 9414754
1960	2135-45, 2735	rear qtr. stationary vent Rear (8-18 x 1-1/2")	6	4755480
1960	2137, 2337, 2837 . . . (10.056)	back window side (8-18 x 1-1/4")	AR	4760061

Group 11.133 CLIP, WINDOW GARNISH MOLDING

1940-48	All	spacing type	AR	4112927
1949-51	2507-11-27 All	spacing type	6	4112927
1952-57	25/2711 All	spacing type	6	4112927
1949-52	2507-08-11-27-69-71 All . . .	spacing type	AR	4562163
1953-57	25/2711-19-62-63-69-71, 2819-69 All	spacing type	AR	4562163
1953-57	25/2737-64-67, 2837-67 All . .	door belt-spacing type	4	4605610
1955-57	25/2719, 2819 All	rear qtr. window-spacing type	2	4649416
1955-57	25/2737, 2837-67 All	door window Front	2	4661091
1958	2739, 2839	rear door window	2	4750223
1958	2793 All	rear qtr. wind. garnish mldg. lower ret.	6	4724593
1958	2794	rear qtr. wind. garnish mldg. lower ret. . . . Front	2	4724593
1959	2794	rear qtr. wind. garnish mldg. lower ret. . . . Rear	42	4724799
1959-60	2135-45, 2735	rear qtr. wind. garnish mldg. Front	4	4759362
1959-60	2135-45, 2735	rear qtr. wind. garnish mldg. lower ret. . . . Front	6	4724593
1953-54	2511-69, 2869 (10.050)	ESCUTCHEON, back window garnish mldg.	2	4639566
1955	2562	rear qtr. window Upper 4656852 RH	1	4656853 LH
1955	2562	rear qtr. window Lower 4656857 RH	1	4656858 LH
1955-57	25/2762 DF-62 SDF	rear qtr. window Upper	2	4675177
1955-57	25/2762 DF-62 SDF	rear qtr. window Lower	2	4675184
1955-56	25/2763 F	rear qtr. window Upper	2	4675178
1955-56	25/2763 F	rear qtr. window Lower	2	4675185
1956	2762 FC	rear qtr. window Upper 4676396 RH	1	4676397 LH

1956	2762 FC	rear qtr. window	Lower	4676403 RH	1	4676404 LH
1957	2762 FC	rear qtr. window	Upper	4697772 RH	1	4697773 LH
1957	2762 FC	rear qtr. window	Lower	4697785 RH	1	4697786 LH
1959	2139, 2439	back wind. garnish mldg.	Upper		1	4764778
1959-60	2839	back wind. garnish mldg.	Upper		1	4765760
1960	2139, 2339, 2439	back wind. garnish mldg.	Upper		1	4788289

Group 11.139 BUMPER, DOOR GARNISH MOLDING

1949-57	25/2737-39-64-67, 2837-39-67 All				2	4162170
---------	----------------------------------	--	--	--	---	---------

Group 11.175 PLATE, FRONT DOOR SILL

1949-52	2507-11-27 All			4584354 RH		4584355 LH
1949-52	2537-67 All			4603327 RH		4603328 LH
1949-52	2508-61-62-69-71 All			4584357 RH		4584358 LH
1953-54	2511-37-67 All			4602021 RH		
1953-54	2511-37, 2837 All					4602022 LH
1953-54	2562-69-71 All			4602017 RH		4602018 LH
1953-54	2567, 2867					4602352 LH
1954	2869 All			4602017 RH		4602018 LH
1954	2837-67 All			4602021 RH		
1954	2837 SD					4602022 LH
1955-57	25/2711-37-63-64, 2837-67 All				2	4651283
1955-57	25/2719-62, 2819 All				2	4651279
1956-57	2739, 2839 All			4669887 RH		4669888 LH
1958	25/2731-41-47-67, 2831 All				2	4721125
1958	2739-49-93-94, 2839-49 All				2	4721126
1959-60	2111-37-67, 2337, 2411, 2837-67				2	4754349
1959-60	2119-35-39-45, 2339, 2419-39, 2735, 2839				2	4754353
1949-52	All	SUPPORT ASSY., door sill plate-front or rear (▲)		AR		4596691
1960	All exc. 2145 (8.977)	SCREW, door sill plate to rocker panel (8-15x5/8")		AR		162400

▲NOTE: Cut to required length.

Group 11.176 SUPPORT, DOOR OPENING CARPET

1955-57	25/2711-37-63-64, 2837-67 All	Front	4646154 RH		4646155 LH
1955-57	25/2719-62, 2819 All	Rear	4646078 RH		4646079 LH
1956-57	2739, 2839 All	Front	4669924 RH		4669925 LH
1956-57	2739, 2839 All	Rear	4669922 RH		4669923 LH
1958	2547 SD, 2731-41	Front	4716259 RH		4716260 LH
1958	2567 All	Front	4722968 RH		4722969 LH
1958	2739-49, 2839-49 All	Front	4715873 RH		4715874 LH
1958	2739, 2839 All	Rear	4715877 RH		4715878 LH
1958	2793-94 All	Front	4715875 RH		4715876 LH
1958	2793-94 All	Rear	4715879 RH		4715880 LH
1958	2849 All	Rear	4722964 RH		4722965 LH
1959-60	2111-37, 2337, 2411, 2837		4759462 RH		4759463 LH
1959	2119-35-45, 2419, 2735	Front	4759402 RH		4759403 LH
1959-60	2119-35-39-45, 2339, 2419-39, 2735, 2839	Rear	4742216 RH		4742217 LH

1959-60	2135-45, 2735	at fldg. 2nd seat	4797280 RH	4797281 LH
1959-60	2139, 2339, 2439, 2839	Front	4759406 RH	4759407 LH
1959-60	2167, 2867	Front	4759466 RH	4759467 LH
1960	2119-45, 2419	Front	4759402 RH	4759403 LH
1956-57	2711-63-64 All	EXTENSION, door opening carpet support	4649862 RH	4649863 LH
1958	2741		4716294 RH	4716295 LH
1959-60	2111, 2411		4753165 RH	4753166 LH
1959-60	2139, 2339, 2439, 2839	rear door opening	4752511 RH	4752512 LH

Group 11.179 PLATE, REAR DOOR SILL

1949-52	2508-61-62-69 All		4584359 RH	4584360 LH
1953-54	2562-69, 2869 All		4602019 RH	4602020 LH
1955-57	25/2719-62, 2819 All			2 4651281
1956-57	2739, 2839 All		4669889 RH	4669890 LH
1958	2739-49, 2839-49 All		4721129 RH	4721130 LH
1958	2793-94 All		4721127 RH	4721128 LH
1959-60	2119-35-39-45, 2339, 2419-39, 2735, 2839		4758991 RH	4758992 LH

Group 11.187 CHANNEL, BACK WINDOW GLASS

1949-53	2571		1	4564672
---------	------	--	---	---------

Group 11.204 GLASS, BACK WINDOW (SAFETY)

1949-51	2507-08 All		1	4559990
1949-52	2511-69 All		1	4559993
1949-51	2527-27B		1	4561843
1949-53	2571		1	4562389
1950-52	2537 All	4577106 RH		4577107 LH
1950-52	2537 All	Center	1	4577108
1951-52	2567	plastic	1	4597407
1953-54	2511-69, 2869 All		1	4616100
1953-54	2537, 2837 All		1	4618686
1953-54	2511-69, 2869 All	e-ze-eye	1	4616101
1955-57	25/2711-19, 2819 All		1	4646181
1955-57	25/2711-19, 2819 All	e-ze-eye	1	4646182
1955-57	25/2737, 2837 All		1	4647541
1955-57	25/2737, 2837 All	e-ze-eye	1	4647542
1955-57	2867 All	plastic	1	4657083
1956-57	2739, 2839 All		1	4667732
1956-57	2739, 2839 All	e-ze-eye	1	4667733
1958	2547 SD		1	4712425
1958	2547 SD	e-ze-eye	1	4712426
1958	2567 All	plastic	1	4705284
1958	27-28 All exc. 2793-94		1	4713527
1958	27-28 All exc. 2793-94	e-ze-eye	1	4713528
1959-60	2111-19, 2411-19		1	4746687
1959-60	2111-19, 2411-19	e-ze-eye	1	4746688
1959-60	2137, 2337, 2837		1	4757361
1959-60	2137, 2337, 2837	e-ze-eye	1	4759347
1959-60	2139, 2339, 2439, 2839		1	4751554
1959-60	2139, 2339, 2439, 2839	e-ze-eye	1	4751555
1959-60	2167, 2867	plastic	1	4764403

Group 11.207 CHANNEL, BACK WINDOW GLASS (RUBBER)

1949-51	2507-08 All			1	4564358
1949-52	2511-69 All			1	4564357
1949-51	2527-27B			1	4564360
1950-52	2537 All			1	4592650
1953-54	2511-69, 2869 All			1	4616107
1953-54	2537, 2837 All			1	4620102
1955	2511-19, 2819 All			1	4650475
1955-57	25/2737, 2837 All			1	4647949
1956-57	2711-19			1	4671705
1956-57	2719 D, 2819 D-19 SD			1	4650475
1956-57	2739, 2839 All			1	4670432
1958	2547 SD			1	4719114
1958	27-28 All exc. 2793-94			1	4724796
1959-60	2111-19			1	4775842
1959	2111-19	w/back wind. upper garn. mldg. (1st type)		1	4755919
1959-60	2137, 2337			1	4775841
1959	2137	w/back wind. upper garn. mldg.		1	4758078
1959-60	2139, 2339, 2439, 2839			1	4756058
1959-60	2411-19			1	4755919
1959-60	2837			1	4758078
1960	2111-19	less Decor group		1	4787595

Group 11.208 MOLDING, BACK WINDOW REVEAL

1949-52	2511-69 All	Upper	4561487 RH	4561488 LH
1950-52	2537 All	Upper	4578936 RH	4578937 LH
1950-52	2537 All	Lower front	4579092 RH	4579093 LH
1950-52	2537 All	Lower rear	4586977 RH	4586978 LH
1953-54	2511-69, 2869 All	Upper	4595990	4595990 LH
1953-54	2511-69, 2869 All	Lower	4595992 RH	4595993 LH
1953-54	2511-69, 2869 All	Upper corner	4637357 RH	4637358 LH
1953-54	2537, 2837 All	Upper	4599525	4599525 LH
1953-54	2537, 2837 All	Lower	4601533 RH	4601534 LH
1953-54	2537, 2837 All	Lower corner	4615906 RH	4615907 LH
1955-57	25/2711-19, 2819 All	Upper	4646945	4646945 LH
1955-57	25/2711-19, 2819 All	Lower	4646943 RH	4646944 LH
1955-57	25/2737, 2837 All	Upper	4648489	4648489 LH
1955-57	25/2737, 2837 All	Lower	4648254 RH	4648255 LH
1958	2547 SD	Lower	4718395 RH	4718396 LH
1958	2547 SD	Lower corner	4718624	4718624 LH
1956-57	2739, 2839 All	Upper	4671357	4671357 LH
1956-57	2739, 2839 All	Lower	4670930 RH	4670931 LH
1956-57	2739, 2839 All	Side	4671740 RH	4671741 LH
1958	2547 SD	Upper	4724815	4724815 LH
1958	2731-39-41-49, 2831-39-49 All	Upper	4716927	4716927 LH
1958	2731-39-41-49, 2831-39-49 All	Lower	4717362 RH	4717363 LH
1958	2731-39-41-49, 2831-39-49 All	Side	4717366 RH	4717367 LH
1959-60	2111-19, 2411-19	Upper	4756111	4756111 LH
1959-60	2111-19, 2411-19	Side	4758874 RH	4758875 LH
1959	2111-19, 2411-19	Lower	4756038 RH	4756039 LH
1959-60	2137, 2337, 2837	Upper	4756666	4756666 LH
1959-60	2137, 2337, 2837 All	Side	4756720 RH	4756721 LH
1959	2137, 2837	Lower	4756656 RH	4756657 LH
1959-60	2139, 2339, 2439, 2839	Upper	4756273 RH	4756274 LH
1959	2139, 2439, 2839	Side	4757495 RH	4757496 LH
1959	2139, 2439, 2839	Lower	4756646 RH	4756647 LH
1960	2111-19	Upper corner	4787600	4787600 LH
1960	2111-19	less Decor group	4787596	4787596 LH

1960	2111-19	Lower	4787597 RH	4787598 LH
1960	2111-19, 2411-19	Lower center	1 4756271	
1960	2111-19, 2411-19	Lower corner	4756691 RH	4756692 LH
1960	2137, 2337, 2837	Lower corner	4756350 RH	4756351 LH
1960	2137, 2337, 2837	Lower center	1 4756577	
1960	2139, 2339, 2439, 2839	Side	4792986 RH	4792987 LH
1960	2139, 2339, 2439, 2839	Lower	4756639 RH	4756640 LH
1960	2139, 2339, 2439, 2839	Lower center	1 4758109	

Group 11.209 ESCUTCHEON, BACK WINDOW REVEAL MOLDING

1949-51	All exc. 2561-62-67		AR	4562218
1950-52	2537 All	Lower	1	4586841
1952	2511-69-71 All		AR	4562218
1953-54	2511-37-69, 2837-69 All	Lower	1	4597174
1953	2571		2	4562218
1955-57	25/2711-19, 2819 All	Upper	2	4647354
1955-57	25/2711-19-37, 2819-37 All	Lower	1	4647160
1955-57	25/2737, 2837 All	Upper	2	4648755
1956-57	2739, 2839 All	Lower	1	4671619
1958	2731-39-41-49, 2831-39-49 All	Lower	1	4717979
1960	2111-19	lower reveal mldg.	1	4787602
1953-54	2537 All	CLIP, lower reveal mldg. to panel	4616563 RH	4616564 LH
1955-57	25/2711-19-37-39, 2819-37-39 All	upper and lower reveal mldg.	AR	4657731
1955-57	25/2711-19-37-39, 2819-37-39 All	lower reveal mldg.-emergency use	AR	4657771
1956-57	2739, 2839 All	side reveal mldg.	Upper 4687058 RH	4687059 LH
1956-57	2739, 2839 All	side reveal mldg.	Lower 4687060 RH	4687061 LH
1958	2731-39-41-49, 2831-39-49 All	side reveal mldg.	4	4718714
1958	2547, 2731-39-41-49, 2831-39-49 All	Upper and lower	18	4657731
1959	2111-19, 2411-19	lower reveal mldg.	Front	2 4759565
1959-60	2111-19, 2411-19	side reveal mldg.	Upper and center	2 4799783
1959-60	2111-19, 2411-19	side reveal mldg.	Lower	2 4799784
1959-60	2111-19-37, 2337, 2411-19, 2837	upper reveal mldg.	AR	4657731
1959-60	2111-19-37, 2411-19, 2837	lower reveal mldg.	Rear	7 4757806
1959-60	2137, 2337, 2837	side reveal mldg.	2	4758645
1959-60	2137-39, 2337, 2837	upper reveal mldg.	AR	4757890
1959-60	2139, 2339, 2439, 2839	side reveal mldg.	4	4760562
1959	2139, 2439, 2839	lower reveal mldg.	Front	2 4759399
1959-60	2139, 2339, 2439, 2839	lower reveal mldg.	Rear	9 4762456
1960	2111-19	back wind. lower corner		
	(w/back window reveal mldg.).	Rear	2	4762456
1960	2111-19, 2411-19	lower corner reveal mldg.	Front	2 4777659
1960	2111-19	w/back window reveal mldg.	Upper and center	2 4799783
1960	2111-19	w/back window reveal mldg.	Lower	2 4799784
1960	2111-19-39, 2339, 2411-19-39, 2839	lower center reveal mldg.	7	4762456
1960	2137, 2337, 2837	lower corner reveal mldg.	2	4785413
1960	2137, 2337, 2837	back window upper reveal ends-emergency use	AR	4760899
1960	2139, 2339, 2439, 2839	side reveal mldg.	Front	2 4761155
1960	2411-19	back wind. lower corner	Rear	2 4762456
1960	2137, 2337, 2837	lower center reveal mldg.	AR	4757806
1959-60	All exc. 2135-45-67, 2867	NUT, back wind. lower reveal mldg.	AR	4644959
1959-60	2111-19-37-39, 2337-39, 2411-19-39, 2837-39	back wind. lower reveal mldg.	Center and rear	AR 4629828
1960	2137-39, 2337-39, 2439, 2837-39	back wind. lwr. side & center reveal mldg.	AR	4644959
1959	2137, 2837	WASHER, back wind. lower reveal mldg.	Front	4 4759643

Group 11.216 NUT, BACK WINDOW OUTER DIVISION MOLDING

1950	2537 All	(10.052)	AR	4576656
1951-52	2537 All	(10.052)	AR	413406

Group 11.251 ARM, REAR WINDOW WIPER

1950-52	2537 All L,H,D.		1	514006
---------	-------------------------	--	---	--------

Group 11.252 BLADE, REAR WINDOW WIPER

1949-54	2507-08-11-69 All . .	(10.146)	1	3733355
---------	-----------------------	----------	---	---------

Group 11.253 KNOB-NUT, REAR WINDOW WIPER CONTROL

1949-52	All	KNOB	1	4568631
1942-52	All	NUT (1/2"-24 Hex.)	1	606318

Group 11.254 MOTOR, REAR WINDOW WIPER

1949-52	2511-69 All L,H,D.		1	4568487
1949-51	2507-08-27-27B All L,H,D.		1	606303

Group 11.358 PANEL ASSEMBLY, FRONT SEAT BACK (LESS TRIM)

1955	2511-37-63-64, 2837-67 All . .	Outer	4637359 RH	4637360 LH
1955-57	25/2711-37-62SDF-63-64, 2837-67 All	Upper	4662346 RH	4662347 LH
1955-57	25/2711-37-63-64, 2837-67 All	Inner	4634283 RH	4634284 LH
1955-56	25/2719-62, 2819 All	Outer	4621308 RH	4621309 LH
1956-57	2711-37-63-64, 2837-67 All	Outer	4682293 RH	
1956-57	2711-37-62SDF-63-64, 2837-67 All	Outer		4682294 LH
1956	2739, 2839 All	Upper	1	4663772
1956	2739, 2839 All	Outer	4682295 RH	4682296 LH
1957	2719-39-62 FC-62DF, 2819-39 All	Outer	4682295 RH	4682296 LH
1957	2719-39-62 FC-62DF, 2819-39 All	Upper	1	4699288
1957	2762 SDF	Inner	4716959 RH	
1957	2762 SDF	Outer	4718132 RH	
1958	2547 SD-67 SD	Outer	4729519 RH	4729520 LH
1958	2567, 2731-41, 2831 D	Outer side	4716970 RH	4716971 LH
1958	2547 SD-67 SD	w/bucket seats	2	4735243
1958	2739-49-93-93 D-94, 2839 D-49 D	Outer side	4716974 RH	4716975 LH
1959-60	2111-37-67, 2337, 2411, 2837-67	Upper	4741909 RH	4741910 LH
1959-60	2111-37-67, 2337, 2411	Lower corner	4751372 RH	4751373 LH
1959-60	2119-35-39-45, 2339, 2419-39, 2867	w/bucket seats	2	4754448
1959	2411-19-39	Outer side	4741759 RH	4741760 LH
1959-60	2735, 2837-39-67	Outer side	4755165 RH	4755166 LH
1959-60	2411, 2837-67	COVER, seat back outer panel	Lower inner	4757692 RH
				4757693 LH

Group 11.360 PANEL ASSEMBLY, CENTER SEAT AND FLOOR

NOTE: See group 12.975 for parts formerly listed in this group.

Group 11.362 PANEL ASSEMBLY, FRONT SEAT SIDE

1949	2508-61-62-69 All L.H.D.			4584569 LH
1953-54	2511-37-67 All			4642519 LH
1953-54	2562-69, 2869 All	side and back	4630594 RH	
1954	2537, 2837-67 All			4642519 LH
1956	2737-39		4682002 RH	4682003 LH
1958	2547 SD-67 SD		4729518 RH	
1958	2547 SD-67 SD	w/manual seat adjuster		4729517 LH
1958	2547 SD-67 SD	w/electric seat adjuster		4729516 LH
1958	2567, 2731-39-41-49-93- 93 D-94, 2831 D-39 D-49 D		4716785 RH	
1958	2567, 2731-39-41-49-93-93 D 94, 2831 D-39 D-49 D	w/manual seat adjuster		4716786 LH
1958	2567, 2731-39-41-49-93- 93 D-94, 2831 D-39 D-49 D	w/electric seat adjuster		4716787 LH
1959	2111-37-67	seat bottom rear corner trim	4751370 RH	4751371 LH
1959	2411-19-39	Side	4754864 RH	
1959	2411-19-39	w/manual seat adj.	Side	4741901 LH
1959	2411-19-39	w/electric seat adj.	Side	4750565 LH
1960	2111-37-67, 2337, 2411	seat bottom rear corner trim	4751370 RH	4751371 LH
1960	2119-35-39-45, 2339, 2419-39, 2735	seat bottom rear corner trim	4750282 RH	4750283 LH
1960	2735, 2837-39-67	w/4 way electric seat adj.	Side	4800193 LH
1959	2735, 2837-39-67	Side	4754868 RH	
1959-60	2735, 2837-39-67	w/manual seat adj.	Side	4754869 LH
1959-60	2735, 2837-39-67	w/electric seat adj.	Side	4754871 LH
1958	2547 SD-67 SD	PANEL AND FRAME ASSY., driver's seat bottom- w/bucket seats		1 4735249
1958	2547 SD-67 SD	passengers' seat bottom-w/bucket seats		1 4735248
1959-60	2867	passenger seat bottom-w/bucket seats		1 4819382
1959-60	2867	driver's seat bottom-w/bucket seats		1 4819376
1959-60	2411, 2837-67	RETAINER, front seat back outer trim	Lower 4757694 RH	4757695 LH
1955-57	All	SUPPORT, front seat side panel-w/horizontal and vertical adjuster	Center 4655588 RH	4655589 LH
1956	2739-39	w/manual seat adjuster	Front 4680675 RH	4680676 LH
1956	All	w/electric seat adjuster	Front 4678382 RH	4678383 LH
1957	All		Front 4695501 RH	4695502 LH
1958	All		Front 4716337 RH	4716338 LH
1958	All		Rear 4707242 RH	4707243 LH
1959	2135-45, 2735	seat back protector panel	Upper	4 4742349
1959-60	2135, 2145, 2735	seat back protector panel	Lower	4 4756749
1959	2411-19-39, 2735, 2837-39-67	frt. seat side panel	Front	2 4743341
1959	2411-19-39, 2735, 2837-39-67	seat back side panel-use w/4758595 retainer	Upper	2 4782653
1959-60	2411-19-39, 2735, 2837-39-67 .	seat back side panel-no retainer required	Upper 4782653 RH	4782654 LH
1959	2411-19-37-39	seat side panel	Rear 4756082 RH	4756083 LH
1959	2419-39, 2735	seat back side panel	Lower	1 4756085
1959-60	2735, 2837-39-67	seat side panel	Rear 4747748 RH	4747749 LH
1959-60	2735, 2837-39-67	seat back side panel	Lower	2 4742183
1960	2735, 2839-67	frt. seat side panel	Front	2 4743341

Group 11.370 MOLDING, REAR FLOOR FINISHING

NOTE: See group 12.976 for parts formerly listed in this group.

Group 11.370 STRIP, FLOOR BOARD SKID

NOTE: See group 12.976 for parts formerly listed in this group.

Group 11.375 SUPPORT, FRONT SEAT HINGE SIDE

1953-54	2511-37-67, 2837-67 All	4633359 RH	4633360 LH
1953	2571	passenger seat Lowerfront	2 4600558
1953	2571	driver seat Lowerfront	4600274 RH 4600275 LH
1955-57	25/2711-37-62SDF-63-64, 2837-67 All	4617491 RH	4617492 LH
1953-54	2511-37-67, 2837-67 All	front seat back hinge Center	1 4604022
1958	2547 SD-67 SD	SUPPORT, passenger seat bottom frame-w/bucket seats Inner front	1 4738162
1958	2547 SD-67 SD	w/bucket seats Outer front	1 4738160
1958	2547 SD-67 SD	w/bucket seats Inner rear	1 4738163
1958	2547 SD-67 SD	w/bucket seats Outer rear	1 4738161
1959-60	2867	passenger and driver seat bottom hinge-w/bucket seats	4 4742352
1959-60	2867	passenger seat bottom frame-w/bucket seats Inner front	1 4742330
1959-60	2867	w/bucket seats Outer front	1 4743349
1959-60	2867	w/bucket seats Inner rear	1 4742341
1957	2762 SDF	w/bucket seats Outer rear	1 4743369
1957	2762 SDF	SUPPORT ASSY., frt. seat reclining back lock bar	1 4717289
1958	2547 SD-67 SD	BAR ASSY., frt. seat reclining back locking	1 4716956
1957	2762 SDF	COVER, driver and passenger seat bottom frame-w/bucket seats Side	4738158 RH 2 4738159 LH
1953	2511-37-67 All	NUT, frt. seat reclining back pivot pin	1 4717420
1955-57	25/2711-37-63, 2837-67 All	PIN, front seat back center arm supt.	2 4627331
1958	2547-67, 2731-41-93 SD, 2831 All	PLATE, front seat hinge arm cover Outer	4668083 RH 4668084 LH
1959	2111-37-67, 2411, 2837-67	frt. seat back center arm support Center	1 4717729
1955-57	25/2711-37-63-64, 2837-67 All	reclining seat back trim protector	1 4725646
1957	2762 SDF	frt. seat reclining back locking mechanical cover	4718106 RH 4718107 LH
1958	25/2731-41-47-67, 2831 All	front seat hinge arm cover Center	1 4707185
1959-60	2111-37-67, 2337, 2411, 2837-67	frt. seat bottom frame center hinge cover	1 4742246
1957	2762 SDF	PLUG, frt. seat center hinge arm support	4722471 LH
1957	2762 SDF	ROD, frt. seat reclining back torque	1 4716772
1955-57	25/2711-37-63-64, 2837-67 All	SPRING, front seat back hinge Outer	4663077 RH
1957	2762 SDF	frt. seat reclining back assist.	1 4724397
1957	2762 SDF	frt. seat reclining back lock bar	1 4716771
1953-57	25/2711-37-62SDF-63-64, 67, 2837-67 All	STOP, front seat back frame (1-1/8" dia.) Center	2 4637788
1957	2762 SDF	STUD, front seat back lock bar to support	4716769 RH
1953-57	25/2711-37-62SDF-63-64-67, 2837-67 All	RETAINER, seat back frame qtr. hinge arm	2 4630023
1958	2547-67, 2731-41-93SD, 2831 All	RETAINER, seat ring pin	2 4714626
1959-60	2111-37-67, 2337, 2411, 2837-67	BOLT, frt. seat reclining back lock bar	2 4714626
1957	2762 SDF (10.463)		2 4689982

Group 11.376 FRONT SEAT HEAD REST PARTS

1957	2762 SDF	BOLT, head rest support	2 4718164
1957	2762 SDF	CATCH, head rest lock	1 4725916
1957	2762 SDF	ESCUTCHEON, head rest lock Inner	1 4718158
1957	2762 SDF	Outer	1 4718159
1957	2762 SDF	PLATE, head rest end finish Inner	1 4718154
1957	2762 SDF	Outer	1 4718155

1957	2762 SDF	SPACER, head rest escutcheon	Side	4718160 LH
1957	2762 SDF	SPRING, head rest lock catch	1	4718157
1957	2762 SDF	SUPPORT, head rest	Inner	1 4725915
1957	2762 SDF		Outer	1 4718153
1957	2762 SDF (14.300)	WASHER, head rest support	1	3758800

Group 11.377 FRONT SEAT BACK LOCK PARTS

BOLT (see Group 11.620 for use)	4750582
---------------------------------	---------

Group 11.380 FOLDING SEAT PARTS

NOTE: See groups 11.620, 12.975 and 12.977 for parts formerly listed in this group.

Group 11.381 BUMPER, FRONT SEAT BACK

1941-48	2607, 2927 All	side	2	4125399
1949-51	2507-11-27-27B-37-67 All	side	2	4580720
1952	2511-37-67 All	side	2	4580720
1953	2511-37-67 All	center and side	4	4637784
1954	2511-37, 2837-67 All	center-1st type	2	4637784
1954-57	25/2711-37-62SDF-63-64, 2837-67 All	center-2nd type on 1954 (1-7/8"x15/16")	4	4646163
1954	2511-37, 2837-67 All	side	2	4637784
1940-48	2507-11-27-27B, 2607-11-27-27B, 2927 All	front seat center arm adj.	AR	4105439
1949-52	2507-11-27-27B-37-67 All	front seat center arm adj.	1	4612056
1953-55	2562 F-62 DF-63 F-64 DF	fldg. seat cushion	2	4602561
1956-57	2762 FC	folding seat bottom cushion	4	4685588
1956-57	2762 DF-62 SDF-63 F-64 DF	folding seat cushion	4	4602561
1957	2762FC (12.212)	center seat side panel bar	2	4687558
1958	25/2731-41-47-67, 2831 All	front seat back	4	4717315
1958	2547SD-67SD	front seat back-w/bucket seats	4	4673566
1958	2793 All	center seat bottom frame	2	4587944
1958	2793	rear floor filler panel support	2	4721222
1958	2794	rear seat front to rear panel	4	4587944
1959-60	2111-37-67, 2337, 2411, 2837-67	frt. seat back Center and side	4	4756065
1959-60	2135-45, 2735	center seat back-on wheelhouse	1	4767527
1959-60	2135-45, 2735	center seat back-on seat	1	4767527
1959-60	2135-45, 2735	rear filler panel-on floor Center	1	4587944
1959	2135-45, 2735	rear filler panel-on floor-emergency use Center	1	4571913
1959-60	2135-45, 2735	rear filler panel-on floor Outer	2	4775833
1959	2145	fldg. third seat back-on cushion	3	4775833
1959	2145	fldg. third seat back-on floor	2	4587944
1959-60	2145	fldg. third seat bottom cushion-on floor Front	2	4767527
1959-60	2145 (12.212)	fldg. third seat bottom cushion-on floor	2	4687558
1959	2145 (12.212)	fldg. third seat back cushion-on floor	2	4687558
1959-60	2867	frt. seat back-w/bucket seats	4	4673566
1960	2145	fldg. third seat back-on cushion	3	4801149
1959	2111-37-67, 2411, 2837-67	WASHER, front seat back stop	4	4728832
1960	2111-37-67, 2337, 2411, 2837-67	front seat back stop	4	4638046

Group 11.419 UNIT, SEAT CUSHION AND BACK TIE WIRE

1949-59	All		1	3690013
---------	-----	--	---	---------

Group 11.523 SUPPORT, SEAT

1953	2571	passenger	Rear	1 4600624
------	------	-----------	------	-----------

Group 11.556 ELECTRIC SEAT ADJUSTER PARTS

NOTE: See Group 13.095 for seat adjuster relay.

1956-57	All	ACTUATOR, seat adjuster-less relay and spin nut . . .	1	5044255	
1960	All	seat adjuster-horizontal 4306909 RH		4306151	LH
1958	All	MOTOR, less relay and spin nut	1	5044309	
1959	All	seat adjuster rear vertical	1	5045163	
1959	All	seat adjuster horizontal	1	5045165	
1959	All	seat adjuster front vertical	1	4762976	
1960	All	seat adjuster rear vertical-w/6 way seat adj. (▲) . .	1	5045163	
1960	All	seat adjuster horizontal-w/6 way seat adj. (▲) . . .	1	5045165	
1960	All	seat adjuster front vertical-w/6 way seat adj. (▲) . .	1	4762976	
1960	All	seat adj. front horizontal & vertical-w/6 way seat adj. (▲▲)	1	5045227	
1960	All	horizontal & vertical power seat	1	5045177	
1959	All	MOTOR AND SUPPORT, seat adjuster front vertical . .	1	4762979	
1958	2547-67, 2731-41, 2831 All	BRACKET, seat adjuster memory double relay-w/easy entrance memory unit	1	1941830	
1956-60	All	CIRCUIT BREAKER, seat adjuster	1	4634948	
1960	All	CLUTCH AND GEAR, seat adj. trans. front vertical-(▲▲)	1	4307852	
1960	All	rear vertical-w/4 way seat adj.	1	4307858	
1960	All	rear vertical-w/6 way seat adj. (▲▲)	1	4307857	
1960	All	seat adj. trans. horizontal	1	4307852	
1960	All	DOG, seat adj. trans. clutch shaft	AR	4306370	
1960	All	GEAR, seat adj. trans. drive	1	4307284	
1958	All	GEAR BOX AND JACK SCREW, seat adj.	1	4746044	
1956-57	All	NUT ASSY., seat adjuster spinning	3	4711554	
1958	All	horizontal	1	4746045	
1958	All	vertical	1	4746046	
1960	All	PAD, seat adj. trans. support-rubber	1	5711115	
1960	All	PLUNGER, seat adj. trans. clutch shaft	AR	4306361	
1960	All	SHAFT, seat adj. trans. clutch	AR	4305871	
1960	All	SPRING, seat adj. trans. clutch shaft	AR	4305873	
1959-60	All	SUPPORT, rear vertical motor mounting	1	4304737	
1959-60	All	horizontal motor mounting	1	4303927	
1960	All	front vertical motor (▲)	1	4304802	
1960	All	seat adj. horizontal & vertical-w/6 way power seat (▲▲)	1	4305816	
1960	All	horizontal & vertical power seat	1	4305816	
1960	All	TRANSMISSION ASSY., seat adj. horizontal and vertical-w/4 way seat adj.	1	4799874	
1960	All	w/6 way seat adj. (▲▲)	1	4783126	
1956-57	All	FITTING, seat actuator end	1	4900120	
1956	All	SCREW, seat actuator end fitting	4	4901143	
1957	All		4	4901542	
1958	All	seat adj. gear box-w/washer	2	4746056	
1958	All	seat adj. spinning nut-w/washer Inner	1	4746055	
1958	All	seat adj. spinning nut-w/washer Outer	1	4746054	
1956-58	All	PIN, seat actuator roll-spring type	4	4711555	
1960	All	WASHER, seat adj. trans. clutch shaft	AR	4306371	
1960	All	seat adj. trans. drive gear	AR	4307436	
1960	All	seat adj. trans. drive gear-curved-w/4 way seat adj.	1	4307421	
1960	All	seat adj. trans. drive gear-curved-w/6 way seat adj. (▲▲)	1	4307421	

▲NOTE: 1st type-w/three motor seat adj.

▲▲NOTE: 2nd type-w/one motor seat adj.

Group 11.558 ELECTRIC SEAT ADJUSTER SWITCH PARTS

1956	All	SWITCH, front seat adjuster	1	4683840
1958	All	seat adjuster memory unit	1	1998666
1958	All exc. 2793-94	seat adjuster memory inst. panel	1	1119976
1958	All exc. 2793-94	seat back memory control-easy entrance	1	4746389
1958	25/2731-41-47-67, 2831 All	SWITCH PKG.	2	1998669
1957	All	BAR, seat adj. switch rocker	1	572628
1959	All	BAR AND HORIZONTAL BUTTON ASSY., seat adj.	1	4303435
1960	All	switch rocker-w/6 way seat adj.	1	4305679
1960	All	seat adj. switch-w/4 way seat adj.	1	4306608
1959-60	All	BASE, seat adj. switch (1st type on 1960) (▲)	1	4303431
1960	All	seat adj. switch-w/6 way seat adj. (▲▲)	1	4305742
1958	All	BEZEL, inst. panel memory seat switch	1	529105
1958	25/2731-41-47-67, 2831 All	BUMPER, memory seat back switch-easy entrance	2	4746447
1959-60	All	BUTTON, seat adj. switch-vertical	2	4303440
1959	All	seat adj. switch-horizontal	1	4303436
1960	All	seat adj. switch-w/4 way seat adj.	1	4309920
1959-60	All	CAP, seat adj. switch vert. button	2	4303439
1956	All	ESCUTCHEON, seat adjuster switch	1	4683841
1957	All exc. 2762 SDF	seat side panel switch	1	4702246
1958	All	seat side panel switch	1	4720178
1959	21 All	seat side panel switch-w/6 way seat adj.	1	4302985
1959	24-27-28 All	seat side panel switch-w/4 way seat adj.	1	4302984
1960	21-23-24 All	seat side panel switch-w/6 way seat adj.	1	4305819
1960	21-23-24 All	seat side panel switch-w/4 way seat adj.	1	4309918
1960	27-28 All	seat side panel switch-w/6 way seat adj.	1	4305820
1960	27-28 All	seat side panel switch-w/4 way seat adj.	1	4309919
1956-57	All	CONNECTOR, seat control wire harness	1	2962765
1958	All	5 wire	1	2965538
1956-57	All exc. 2762 SDF	COVER, seat adjuster switch retainer	1	4691438
1956	All exc. 2762 SDF (10.777)	CLIP, front seat side panel switch	4	4566681
1957	All exc. 2762 SDF	motor wire to relay	4	4717648
1958	All	seat adj. switch to escutcheon-6 way seat	4	4302779
1958	All	seat adj. switch wiring-w/4 way seat adj.	1	4749733
1959-60	All	seat adj. switch wiring-w/6 way seat adj.	4	4306804
1960	All	HANDLE, seat adjuster switch	1	4805670
1960	All	KNOB, seat adjuster memory switch	1	4800941
1957	All exc. 2762 SDF	NUT, front seat side panel switch and escutcheon	1	4702253
1958	All exc. 2793-94 (9.647)	PIN, seat adj. switch vert. button	1	529761
1956	All	PLATE, seat adjuster switch retainer	2	4684567
1957	All exc. 2762 SDF	seat adj. cable attaching-w/4 way seat adj.	2	4696163
1958	All	SOLENOID, seat adj. trans.-w/4 way seat adj.	2	4683738
1959-60	All	w/6 way seat adj. (▲▲)	2	4303438
1957	All exc. 2762 SDF	SPRING, seat adjuster switch anti-rattle	1	4702254
1959-60	All	STRAP, seat adj. unit harness-plastic (1st type on 1960) (▲)	2	4306674
1959	21 All	SUPPORT, seat side panel escutcheon and switch	1	4306547
1959	2411-19-39. 2735, 2837-39-67	seat side panel escutcheon and switch w/6 way power seat	1	4306495
1960	21-23-24 All	seat side panel escutcheon and switch	1	4691439
1960	21-23-24 All	seat side panel escutcheon and switch-w/4 way seat adj.	2	2328616
1960	27-28 All	seat side panel escutcheon and switch-w/4 way seat adj.	1	4757429
				4800027 LH
				4757429
				4800028 LH
				4800027 LH

▲NOTE: 1st type-w/three motor seat adj.

▲▲NOTE: 2nd type-w/one motor seat adj.

Group 11.561 ADJUSTER ASSEMBLY, FRONT SEAT

1949-51	All exc. 2571 L.H.D.	4593481 RH	
1950-51	All exc. 2571 L.H.D.	2nd type on 1950 (▲)	4593482 LH
1950-52	2571	driver's seat	1 4586308
1952	2511-37-62-67-69 All	4593481 RH	4593482 LH
1953-54	2511-62-69, 2869 All	4603100 RH	4628498 LH
1953-54	2537-67, 2837-67 All	4617779 RH	4617778 LH
1953	2571	driver's seat	1 4600790
1955	All	4674968 RH	4674969 LH
1956	All L.H.D., exc. 2737-39	4674968 RH	4674969 LH
1956	2739-39 L.H.D.	4680007 RH	4680008 LH
1957	All L.H.D.	4699663 RH	4699664 LH
1958	All	4749317 RH	4749318 LH
1958	2547SD-67SD	driver's seat-w/bucket seats	4736184 RH 4736185 LH
1959	All	4750795 RH	4750796 LH
1959-60	All	driver's seat-w/bucket seats	4754100 RH 4754101 LH
1960	All	(★)	4803432 RH 4803433 LH
1959-60	All	BAR, seat adj. lock-exc. bucket seats	4301312 RH
1949-58	All	BOLT, seat adjuster to bottom frame	AR 4561558
1949-55	All	seat adjuster to floor pan	8 4725599
1959-60	All	seat adjuster to floor pan Inner front	2 4780351
1959-60	All	seat adj. to bottom frame	4 4725599
1959	2139, 2837	seat adj. to floor pan	8 4748443
1960	All exc. 2837	seat adj. to floor pan	8 4782244
1960	2837	seat adj., to floor pan-exc. 4 & 6 way seat adj.	8 4803140
1960	2837	seat adj. to floor pan-w/4 & 6 way seat adj.	8 4782244
1953-57	All exc. 2571	RETAINER, adjuster to floor pan	4605339 RH 4605340 LH
1958	All	Front	2 4736174
1958	2793-94 All	STOP, front seat adjuster	2 4757534

▲NOTE: Used on 1950 models having seat adjuster with one-piece control linkage.

★NOTE: 2nd type w/rear end of assist spring hooking over seat bottom frame.

Group 11.561 ADJUSTER-SUPPORT-TRACK-TUBE-ROD,
HORIZONTAL AND VERTICAL SEAT ADJUSTER

1956-57	All	ADJUSTER ASSY., front seat-electric	4711802 RH 4711803 LH
1959	All	4758315 RH	4758316 LH
1960	All	frt. seat elec.-w/6 way seat adj. (▲)	4768172 RH 4768173 LH
1960	All	w/6 way seat adj. (▲▲)	4783825 RH 4783826 LH
1960	All	front seat elec.-w/4 way seat adj.	4802217 RH 4802218 LH
1959	All	ADJUSTER, seat-less jackscrew and gear nut	4302986 RH 4302987 LH
1960	All	frt. seat elec.-w/6 way seat adj. (less screw & gearnut) (▲)	4304290 RH 4324291 LH
1960	All	w/6 way seat adj. (less Jackscrew & gearnut) (▲▲)	4306260 RH 4306261 LH
1960	All	frt. seat-w/4 way seat adj. (less jackscrew and gearnut)	4306914 RH 4306915 LH
1954	All	SUPPORT, seat adjuster Top	4648457 RH 4648458 LH
1955-57	All exc. 2762 SDF, 2867 SD	Top	4710032 RH
1955	All	Top	4710033 LH
1956	All exc. 2737-39	Top	4710033 LH
1956	2737-39	Top	4722821 LH
1956-57	All exc. 2762 SDF	seat adjuster tension spring-electric Front	1 4691845
1956-57	All exc. 2762 SDF	seat adjuster tension spring-electric Rear	1 4691842
1957	All exc. 2762 SDF, 2867 SD	Top	4710033 LH
1954	All	TRACK AND BASE, seat adjuster	4648459 RH 4648460 LH
1955	All	4657957 RH	4657958 LH

1956-57	All exc. 2762 SDF, 2867 SD	4683733 RH	4683734 LH
1958	All	BASE ASSY., seat adjuster lower-electric 4746040 RH	4746041 LH
1959-60	All	BEARING, horizontal jackscrew	2 4304786
1959-60	All	horizontal jackscrew-thrust	2 4304784
1959	All	BUMPER, vertical jackscrew	4 4304554
1959-60	All	horizontal jackscrew	2 4305001
1959-60	All	CABLE ASSY., seat adj. front vertical-w/vinyl casing includes core (1st type on 1960) (▲)	4786253 RH 4786252 LH
1959-60	All	rear vertical-w/vinyl casing-includes core-w/3 motor seat adj. (1st type on 1960) (▲)	4786255 RH 4786254 LH
1960	All	horizontal-w/4 & 6 way seat adj. (▲▲)	4306816 RH 4306822 LH
1960	All	front vertical-w/4 & 6 way seat adj. (▲▲)	4306814 RH 4306820 LH
1960	All	rear vertical-w/6 way seat adj. (▲▲)	4306812 RH 4306818 LH
1960	All	seat adj. motor to trans. drive	1 4792097
1959-60	All	CASING, horizontal cable-less core (1st type on 1960) (▲)	4305183 RH 4303983 LH
1958	All	COUPLING ASSY., seat adjuster motor	1 4746049
1959-60	All	CORE, horizontal cable casing (1st type on 1960) (▲)	4303422 RH 4303424 LH
1959-60	All	CLIP, seat adj. cable (1st type on 1960) (▲)	3 4773867
1959-60	All	GEARNUT, front vertical jackscrew	2 4303411
1959-60	All	rear vertical jackscrew (1st type on 1960) (▲)	2 4303678
1960	All	front vertical jackscrew (▲▲)	2 4307546
1960	All	rear vertical jackscrew-w/6 way seat adj. (▲▲)	2 4307549
1960	All	horizontal and vertical jackscrew-w/4 way seat adj.	2 4308032
1959-60	All	JACKSCREW, horizontal	4304780 RH 4305517 LH
1959-60	All	vertical	2 4303410
1960	All	vertical-w/4 way seat adj.	2 4306584
1959-60	All	NUT, horizontal jackscrew	4304782 RH 4305649 LH
1959	All	PACKAGE, frt. seat height adjustment-exc. bucket seats	1 533965
1960	All	front seat height adj. exc. w/bucket seats	1 533965
1959-60	All	RETAINER, horizontal jackscrew nut	2 4305723
1959-60	All	RING, horizontal jackscrew retainer	2 4304296
1960	All	w/4 way seat adj.	2 4307167
1960	All	SHOE, seat adj. lower channel-w/4 way seat adj.	4 4307433
1960	All	w/6 way seat adj. (▲▲)	4 4307433
1959-60	All	SILENCER, seat adj. counterbalance spring	4 4304807
1959-60	All	SLEEVE, seat adj. horizontal jackscrew	2 4304785
1956-57	All	TUBE, seat adjuster torque-electric	1 4711550
1958	All	ROD AND LINK, seat adjuster torque-electric	1 4746050
1958	All	LINK, spinning nut to torque tube-electric	4746165 LH
1956-57	All exc. 2762 SDF	PLATE, seat adjuster tension spring front support-electric	1 4691892
1960	All	seat adj. cable attaching-w/6 way seat adj. (▲▲)	2 4306617
1960	All	PIN, seat adj. vertical jackscrew & support-w/4 way seat adj.	2 4307243
1954	All	ROD, vertical equalizing	Front 1 4648461
1954	All	vertical equalizing	Rear 1 4648462
1954	All	horizontal and vertical equalizing	1 4648463
1954	All	vertical control	Front 1 4648464
1954	All	vertical control	Rear 1 4648465
1955-57	All exc. 2762 SDF, 2867 SD	vertical equalizing	2 4657951
1955-57	All exc. 2762 SDF, 2867 SD	horizontal and vertical equalizing	1 4657954
1955-56	All	vertical control	Front 1 4657949
1955-56	All	vertical control	Rear 1 4657950
1957	All exc. 2762 SDF, 2867 SD	vertical control	Front 1 4699853
1957	All exc. 2762 SDF, 2867 SD	vertical control	Rear 1 4699854
1958	All	SLIDE, seat adj.-electric	Upper 4746042 RH 4746043 LH
1958	All	plastic-electric	4746052 RH 4746053 LH

1956-57	All	SPRING, seat adjuster assist-electric	4711549 RH	
1956-57	All exc. 2762 SDF	seat adjuster assist-electric		4688737 LH
1956-57	All	seat adjuster anti-creep-electric	1	4711556
1956-57	All exc. 2762 SDF	seat adjuster tension-electric	1	4691840
1958	All	seat adj. vertical assist-electric	1	4746051
1959-60	All	seat adj. counterbalance (1st type)	2	4305801
1959-60	All	seat adj. counterbalance-w/3 motor adj.	2	4303414
1960	All	seat adj. counterbalance-w/6 way seat adj.-(▲▲)	2	4309444
1960	All	seat adj. counterbalance-w/4 way seat adj.	2	4306585
1956-57	All	SCREW, seat adjuster torque tube link-electric	6	4711552
1956	All	seat adjuster tension spring support-electric	4	187979
1959-60	All	seat adjuster gear nut	8	4303112
1959-60	All	WASHER, horizontal jackscrew	4	4304779
1959-60	All	horizontal jackscrew	2	4303405

▲NOTE: 1st type-w/three motor seat adj.

▲▲NOTE: 2nd type-w/one motor seat adj.

Group 11.573 COVER, FRONT SEAT ADJUSTER TRACK

1958	All	electric	4735850 RH	4735851 LH
1958	All	seat adjuster mechanism		4735852 LH
1959-60	All	electric	4801185 RH	4801186 LH
1956-57	All exc. 2762 SDF	COVER, motor and regulator-electric	1	4682551
1960	All	FASTENER, seat adj. track cover stud	8	4771161
1959-60	All	SUPPORT, frt. seat adj. cover	2	4303937
1959-60	All	frt. seat adj. cover	2	4303935

Group 11.581 SPRING, SEAT ADJUSTER RETURN

1958	All		AR	4238522
1959-60	All	assist (1st type on 1960) (▲)	4304426 RH	4304866 LH
1960	All	assist (▲▲)	2	4803350
1949-57	All exc. 2571	SPRING, seat adjuster lock bar	2	4159847
1958	All		4156813 RH	4301916 LH
1959-60	All	seat adj. lock bar	2	4301314
1959-60	2867	seat adj. lock bar-w/bucket seats		4301916 LH
1959-60	All	RETAINER, frt. adj. lock bar spring	2	4301315

▲NOTE: 1st type-w/rear end of assist spring hooking over lockbar.

▲▲NOTE: 2nd type-w/rear end of assist spring hooking to seat bottom frame.

Group 11.581 SPRING-SPACER-EXTENSION-RETAINER-PIN, HORIZONTAL AND VERTICAL SEAT ADJUSTER

1954-57	All exc. 2762 SDF, 2867 SD	SPRING, seat adjuster return	1	4648467
1954	All	seat adjuster latch	1	4648468
1954	All	seat adjuster latch to latch	1	4656456
1954-57	All exc. 2762 SDF, 2867 SD	seat adjuster ratchet	4	4648469
1954-57	All exc. 2762 SDF, 2867 SD	seat adjuster counterbalance	2	4648470
1955-57	All exc. 2762 SDF, 2867 SD	seat adjuster latch	1	4657959
1955-57	All exc. 2762 SDF, 2867 SD	anti-rattle	1	4664338
1954-57	All exc. 2762 SDF, 2867 SD	SPACER, seat adjuster control rod	1	4648471
1954	All	EXTENSION, seat adj. aux. lock. rod	1	4648472
1955-57	All exc. 2762 SDF, 2867 SD		1	4657953
1954-57	All exc. 2762 SDF, 2867 SD	RETAINER, horizontal equalizing rod	2	274694
1954-57	All exc. 2762 SDF, 2867 SD	PIN, vertical equalizing rod	4	455964
1954-57	All exc. 2762 SDF, 2867 SD	NUT, seat adj. lock. ext.-spring type	2	445170

Group 11.582 CLIP, SEAT ADJUSTER ROD

1941-52	All exc. 2571	aux. locking rod center	AR	4572939
---------	---------------	-------------------------	----	---------

Group 11.588 HANDLE, FRONT SEAT ADJUSTER

1954-57	All L.H.D. exc. 2762 SDF, 2867 SD	w/horizontal and vertical adj.	2	4637839
1959-60	All	HANDLE AND LOCK BAR, seat adj.		4301307 LH
1949-52	All	KNOB, chrome	1	4591925
1953	All exc. 2571	chrome	1	4603614
1954-57	All exc. 2867 SD	chrome	1	4619984
1958	All		1	4719509
1959-60	All	chrome	1	4591925

Group 11.589 ROD, SEAT ADJ. AUXILIARY LOCKING

1949-54	All exc. 2571 L.H.D.		1	4618641
1954	All	w/horizontal and vertical adj.	1	4648466
1955-57	All exc. 2867 SD		1	4637266
1955-57	All exc. 2762 SDF, 2867 SD	w/horizontal and vertical adj.	1	4657952
1958	All		1	4757560
1959	All		1	4759698
1960	All	WIRE	1	4802099
1954	All exc. SD-L.H.D.	ESCUTCHEON, seat adj. knob-w/horizontal and vertical adj.	1	4637841
1954	2511-62-62 F-69		1	4639591
1956	2737-39 L.H.D.		1	4682264
1956	2737-39 L.H.D.	w/horizontal and vertical adj.	1	4680696
1957	All exc. 2762 SDF	w/horizontal and vertical adj.	1	4696168
1959	21 All	seat adj. knob	1	4757035
1960	21-23-24 All	seat adj. knob	1	4757035
1958	All	RETAINER, seat adj. auxiliary locking rod	1	4757561
1959	All	seat adj. auxiliary locking rod	1	4759684
1959	All	elec. seat adj. cable	1	4759684
1960	All	seat adj. auxiliary locking wire	1	4802098
1959	21 All	SUPPORT, seat adj. knob escutcheon		4757427 LH
1960	21-23-24 All	seat adj. knob escutcheon		4757427 LH

Group 11.607 FRAME ASSEMBLY, REAR SEAT

1955	2562		1	4663313
------	----------------	-----------	---	---------

Group 11.608 PLATE, SEAT ANCHOR

1949-55	2561-62 All	center and rear seat	AR	4567134
---------	-----------------------	--------------------------------	----	---------

Group 11.610 FRAME ASSEMBLY, FOLDING SEAT BOTTOM

1958	2793 All		1	4721091
1958	2794	center seat		4721089 RH
1960	2111-19-39, 2339, 2411-19-39, 2839	STOP, rear seat cushion	2	4807857

Group 11.612 RAIL, CENTER SEAT SIDE GRAB

1953-54	2562	1	4621492
1955	2562	1	4657444

Group 11.620 ATTACHING PARTS, FOLDING SEAT

1953-54	2562 F-62 DF	BOLT, folding seat bottom cushion hinge	2	4607927
1956-57	2762 DF-62 SDF-63 F-64 DF		2	4663900
1956-57	2762 DF-62 SDF-63 F-64 DF	folding seat cushion supt. to seat	2	4657487
1956-57	2762 FC	folding seat hinge pivot (Spec. 3/8"-16x1")	13	4657487
1956-57	2762 FC	folding seat hinge pivot (Spec. 3/8"-16x1-1/8")	1	4689803
1956-57	2762 FC (11.561)	center seat side outer panel to floor Rear	2	4561558 LH
1956-57	2762 FC (11.561)	folding seat side inner and outer panel to floor pan	6	4725599
1958	2793 (11.377)	folding seat link and supt. to pan and plate	8	4750582
1958	2793	folding seat link to supt. (Spec. 7/16"-20x59/64")	4	4721192
1958	2794 (11.377)	center seat link and supt. to pan and plate	8	4750582
1958	2794	center seat inner and outer link		
		to supt. (Spec. 7/16"-20x59/64")	2	4721192
1958	2794	center seat inner link		
		to supt. (Spec. 3/8"-24x1-11/16")	1	4722907
1959	2135-45, 2735	fldg. link to support	6	4757358
1959-60	2135-45, 2735	fldg. center seat link to support	6	4760650
1959	2135-45, 2735	fldg. seat link & support to plate	6	4758634
1956-57	2762 FC	BOLT AND WASHER, folding seat front support to floor pan 4131056 RH		
1956-57	2762 FC	BUMPER, folding seat back support	2	4668145
1959-60	2135-45, 2735	center seat back control link	2	4761458
1958	2794 (13.384)	BUTTON, rear seat cushion and back	11	4565454
1959-60	2135-45, 2735	BUSHING, second seat link to support	6	4761485
1959-60	2135-45, 2735	second seat back-up position 4797299 RH		
1956-57	2762 DF-62 SDF-63 F-64 DF	CLIP, folding seat cushion supt. ret.	2	4662991
1958	2793 All	folding seat anti-rattle-up position	2	4735190
1958	2793 All	folding seat anti-rattle-down position	2	4736926
1953-54	2562 F-62 DF	COVER, folding seat back retainer	2	4625082
1955-57	25/2762-63-64 All F		2	4650078
1956-57	2762 DF-62 SDF-64 DF	folding seat bottom cushion upper hinge 4667437 RH		4557438 LH
1956-57	2762 FC	center seat back hinge arm supt. 4688151 RH		4688152 LH
1958	2793 All	folding seat bottom frame protector 4746166 RH		4746167 LH
1958	2794	center seat link lock 4727494 RH		
1959-60	2135-45, 2735	fldg. center seat back catch	1	4758395
1958	2794	FASTENER, rear seat back to frame stud	5	4734848
1958	2794	rear seat cushion retainer to pan	5	4725325
1953-54	2562 F-62 DF	HINGE ASSY., folding seat cushion	2	4641609
1955	2562-63-64 All F		2	4650179
1956-57	2762 DF-62SDF-63F-64DF	fldg. seat cushion Upper 4662762 RH		
1956-57	2762 DF-62 SDF-63 F-64 DF	Lower 4662812 RH		4662813 LH
1956-57	2762 FC	center seat cushion pivot 4678153 RH		4678154 LH
1959	2145	third seat bottom cushion 4773815 RH		4773816 LH
1960	2145	third seat bottom cushion 4788768 RH		4788769 LH
1958	2793 All	LINK ASSY., folding seat 4722697 RH		4722698 LH
1958	2794	folding center seat mounting Outer 4722521 RH		4722524 LH
1958	2794	folding center seat mounting Inner 4722522 RH		4722523 LH
1959	2135-45, 2735	fldg. center seat mounting support 4766380 RH		4766381 LH
1960	2135-45, 2735	fldg. center seat mounting support 4788776 RH		4788777 LH
1960	2135	second seat back filler panel	2	4802437
1960	2145	second seat back filler panel	2	4802451
1960	2735	fldg. second seat back filler panel 4803421 RH		4803422 LH
1958	2794	NUT, center seat inner link to supt. bolt (3/8"-24)	1	4722908
1958	2793 All	folding seat link to support	4	4722812

1958	2794	center seat inner and outer link to supt.	4	4722812	
1959-60	2135-45, 2735	center seat link to support	6	4761487	
1956-57	2762 DF-62 SDF-63 F-64 DF	PLATE, folding seat back upper corner supt. bumper	2	4662900	
1956-57	2762 FC	folding seat cushion anchor		4687678	LH
1956-57	2762-63-64 All	folding seat cushion anchor-			
		on seat	4688431	RH	4688432 LH
1958	2793 All	REINFORCEMENT, folding seat link	4756086	RH	4756087 LH
1955-57	25/2762-63-64 All F	RETAINER ASSY., fldg. seat back-up position	2	4650413	
1955-57	25/2762-63-64 All F		2	4650413	
1956-57	2762 FC	rear seat back-on fldg. floor board	2	4685641	
1956-57	2762 FC	rear seat back spring to fldg. floor board	2	4680646	Upper
1958	2794	rear seat bottom cushion	1	4724706	
1958	2793-94 All	folding seat cushion	AR	4745888	
1956-57	2762 DF-62 SDF-63 F-64 DF	SCREW, folding seat cushion upper hinge	6	4644902	
1958	2793 All	folding seat link and supt. to bracket	4	4724068	
1958	2793-94 All	folding seat link and supt. to bottom	4	4565369	
1958	2794	center seat link and supt. to bracket	4	4724068	
1958	2794	SOCKET, rear seat cushion and back	11	105195	
1958	2793 All	SPRING, folding seat link torsion	4734940	RH	4734941 LH
1958	2794	center seat link lock lever	4727930	RH	
1953-54	2562 F-62 DF	STOP, on sides of seat back-up position	2	4602299	
1955	2562-63-64 All F	on side of seat back-up position	2	4650410	
1956-57	2762 F-62 SDF-63 F-64 DF	on side of seat back-up position	2	4650189	
1960	2135-45, 2735	fldg. center seat bottom cushion	2	4807857	
1959-60	2135-45, 2735	STRIKER, second seat back catch-up			
		position	4759765	RH	
1953	2562 F-62 DF	SUPPORT, folding seat back-on			
		w/house	Outer	4621481	RH 4621482 LH
1954	2562 F-62 DF	on w/house	4641597	RH	4641598 LH
1955	2562-63-64 All F		Outer	4657445	RH 4657446 LH
1956-57	2762 FC	folding floor board-up position	4685644	RH	4685645 LH
1956-57	2762 FC	center seat back hinge arm	4682247	RH	4682248 LH
1956	2762 FC	center seat bottom cushion	4689862	RH	4685494 LH
1956-57	2762 FC	center seat outer			
		side panel	Front disc	4685445	RH
1956-57	2762 FC	center seat outer side panel	Rear	4682268	RH
1956	2762 DF-63 F-64 DF	folding seat bottom cushion			1 4685251
1956-57	2762 DF-62 SDF-63 F-64 DF	folding seat back	Lower	4688439	RH 4688440 LH
1957	2762 FC	center seat cushion	4711529	RH	4711531 LH
1957	2762 DF-62 SDF-63 F-64 DF	folding seat bottom cushion			1 4711527
1958	2793 All	folding seat link mounting	4720801	RH	4720802 LH
1958	2794	folding center seat link			
		mounting	Outer	4720933	RH 4720934 LH
1958	2794	folding center seat link mounting			1 4721097
1958	2794	folding floor front panel	4717725	RH	4717726 LH
1958	2794	folding rear seat back	4755235	RH	4755236 LH
1953-55	2562-63-64 All F and DF	SUPPORT AND PIVOT	Inner	2	4602297

Group 11.629 FILLER, REAR SEAT BACK

1959-60	2137, 2337, 2837	FILLER, rear seat back to quarter panel	4758502	RH	4758503 LH
1959-60	2139, 2339, 2439, 2839		4756744	RH	4756745 LH

Group 11.630 PANEL, REAR SEAT BACK FILLER

1958	2567SD	rear seat back-w/bucket seats	1	4733876	
1958	2567SD	rear seat cushion-w/bucket seats	1	4734919	
1960	2837				Upper center 1 4740278

Group 11.649 SPRING, REAR SEAT CENTER ARM REST

1958	2547SD	coil	Inner	2	4730373
1958	2547SD	coil	Outer	2	4717904
1959-60	2837-39	SPRING AND PANEL, arm rest		1	4831675

Group 11.651 PANEL-PLATE, REAR SEAT CENTER ARM REST

1958	2547SD	PANEL		1	4714422
1958	2547SD	PLATE		1	4714419
1960	2837-39			1	4799764
1959	2837-39			1	4769964

Group 11.801 PANEL ASSY., FOOT REST

1953-54	All exc. 2571			1	4641649
---------	---------------	--	--	---	---------

Group 11.878 ESCUTCHEON, ROBE CORD

1953-54	2511-19-69, 2819-69 All		AR	4605687
1955	2519, 2819 D-19 SD		2	4605687
1956-57	2819-39 All		2	4605687
1953-55	2511-19-59, 2819-69			
	All (8.908)	SCREW, robe cord escutcheon (No. 10-32x7/8")	AR	147947
1956	2819-39 All (8.908)	(No. 10-32x7/8")	4	147947
1957	2819-39 All (8.977)	(No. 10-12x3/4")	4	168593

Group 11.898 ROBE CORD, FRONT SEAT BACK

1953	2511 D	trim 5361	2	4619174
1953-54	2569 D	trim 5360, 5450	1	4624672
1953-54	2569 D	trim 5361, 5451	1	4624671
1954	2569 D, 2869 D	trim 5460-62	1	4634413
1954	2569 D, 2869 D	trim 5461-63	1	4634414
1955	2819 D	trim 262	1	4634413
1955	2819 D	trim 263-299	1	4636510
1955	2819 D	trim 264-271	1	4655018
1955	2819 SD	trim 274-292	1	4659269
1955	2819 SD	trim 279-288-293	1	4659270
1956	2839 SD	trim 254-255	1	4674500
1956	2839 SD	trim 256-257	1	4674501
1957	2819 D	trim 215	1	4700747
1957	2819 D	trim 216	1	4700847
1957	2819 D	trim 217	1	4701779
1957	2819 SD-39 SD	trim 235-238	1	4699509
1957	2819 SD-39 SD	trim 236-239	1	4699510
1957	2819 SD-39 SD	trim 237-240	1	4699511
1957	2819 SD-39 SD	trim 247-248	1	4709469

Group 11.925 LAMP, DOME (LESS BULB)

1941-48	Exc. 2567		1	4115307
1958	2547, 2831-39 All	on side roof rail	2	4719318
1959	2439, 2837-39	on side roof rail	1	4719318
1959	2439, 2837-39	on side roof rail-w/switch		4751914 LH
1960	2111-19-35-37-39-45, 2337-39,			
	2411-19, 2735	(▲)	1	4692184
▲NOTE: 1st type use w/round type bulb.				

Group 11.927 REFLECTOR-RETAINER-SUPPORT, DOME LAMP

1959-60	2167, 2867 (11.938)	PLATE, rear bow dome lamp switch	1	4002769
1949-55	All exc. 2537-67, 2837-67 . . .	REFLECTOR AND SWITCH ASSY., dome lamp	1	4300981
1955	2537 D		1	4300981
1956-57	2711-19-37-62-63, 2819 All . . .		1	4300981
1958	2731-39-41-49-93-94, 2849 All . . .		1	4300981
1959-60	2111-19-35-37-39-45, 2337-39, 2411-19, 2735	(A)	1	4233835
1960	exc. 2167, 2867	dome and reading lamp	1	4771211
1953-54	2537, 2837 All	REFLECTOR, rear corner lamp	2	4603601
1955-57	25/2764, 2837-39 All		2	4650248
1959-60	2145	rear qtr. courtesy lamp	1	4650248
1953-57	2567, 2867 All	REFLECTOR AND RIM, rear bow lamp	1	4577220
1958-60	2167, 2567, 2867 All		1	4746615
1958	2547, 2831-39 All	REFLECTOR AND SOCKET, dome lamp	2	4238063
1959-60	2439, 2837-39	roof rail lamp 4304265 RH		
1959-60	2439, 2837-39	roof rail lamp-with switch		4786176 LH
1956-60	21/25/2867 All	SPACER, dome lamp reflector to bow	1	4644496

▲NOTE: 1st type use w/round type bulb.

Group 11.928 RIM, DOME LAMP

1941-48	All exc. 2567	less lens	1	4115921
1949-55	All exc. 2537-67, 2837-67 . . .	less lens	1	4168052
1956-57	2711-19-37-39-62-63, 2819 All . . .	less lens	1	4168052
1958	2731-39-41-49-93-94, 2849 All . . .		1	4168052
1959-60	2111-19-35-37-39, 2337-39, 2411-19, 2735 All		1	4233080
1960	All exc. 2167, 2867	dome and reading lamp-includes lens	1	4771319
1939-40	26-29 All exc. 2667	LENS, dome lamp	1	4115920
1940	2511-19		1	4115920
1940-52	2567		1	4102341
1941-48	All exc. 2567		1	4115920
1949-55	All exc. 2537-67, 2837-67 . . .		1	4168051
1950-52	2537	rear quarter corner lamp	2	4589622
1953-54	2537, 2837 All		2	4605664
1953-54	2567, 2867		1	4577221
1955-57	25/2764, 2837-39 All		2	4605664
1955-57	2867 All		1	4644417
1956-57	2711-19-37-39-62-63, 2819 All . . .		1	4168051
1958	2731-39-41-49-93-94, 2849 All . . .		1	4168051
1958	2547, 2831-39 All		2	4237709
1958	2567		1	4577221
1959-60	2111-19-35-37-39-45, 2337-39, 2411-19, 2735	dome lamp	1	5711725
1959-60	2145	rear qtr. courtesy lamp	1	4605664
1959-60	2167, 2867	rear bow dome lamp	1	4577221
1959-60	2439, 2837-39		2	4237709
1960	All exc. 2167, 2867	dome and reading lamp	1	4304351

Group 11.935 SWITCH, DOME LAMP

1942-48	All		1	4594201
1949-54	2537-67, 2837-67 All		1	4610315
1955	2867	rear bow dome lamp	1	4610315
1956-57	2764 DF	side roof rail	2	4610313
1956	2837 SD	rear qtr. corner lamp	1	4678339

1956	2837 SD	rear bow dome lamp	1	4610315
1956-57	2839 SD	rear qtr. corner lamp	1	4162151
1956	2867	rear bow dome lamp	1	4678340
1957	2837 SD	rear qtr. corner lamp	1	4711631
1957	2867 All	rear bow dome lamp	1	4711630
1958	2547, 2831-39 All SD	rear qtr. corner lamp-black	1	4162151
1958	2567	rear bow dome lamp-grey	1	4741843
1958	2567	rear bow dome lamp-green	1	4741844
1958	2567	rear bow dome lamp-blue	1	4741845
1958	2567	rear bow dome lamp-red	1	4741846
1958	2567 SD	rear bow dome lamp	1	4610313
1958	2831D-39D	rear qtr. corner lamp-grey	1	4741848
1958	2831D-39D	rear qtr. corner lamp-green	1	4741849
1958	2831D-39D	rear qtr. corner lamp-blue	1	4741850
1958	2831 D-39 D	rear qtr. corner lamp-red	1	4747072
1959-60	2145	rear qtr. courtesy lamp		4673705 LH
1959	2167	rear bow dome lamp	1	4768135
1959-60	2439, 2837-39	side roof rail lamp		4304105 LH
1959	2867	rear bow dome lamp	1	4610313
1960	2167, 2867	rear bow dome lamp	1	4610313

Group 11.938 PLATE, SIDE ROOF RAIL LAMP SWITCH

1955-57	25/2764DF		2	4002769
1959-60	2145	ESCUTCHEON, rear qtr. courtesy lamp	1	4767829

Group 11.950 SWITCH, DOME LAMP HINGE PILLAR

1941-54	All		2	4598597
1955-56	All	front door	2	1998022
1955-56	2819-30 All	rear door	2	4598597
1957-60	All	front door	2	4709879
1957-58	2793 D-93 SD, 2819-39, 49 SD			
	All	rear door	2	1998748
1959-60	2735, 2839	rear door	2	1998748

Group 11.951 GASKET, DOME LAMP DOOR HINGE PILLAR SWITCH

1941-56	All		2	4598587
1957-60	All		AR	4709880

Group 11.612 RAIL, CENTER SEAT SIDE GRAB

1953-54	2562			1	4621492
1955	2562			1	4657444

Group 11.649 SPRING, REAR SEAT CENTER ARM REST

1958	2547SD		coil	Inner	2	4730373
1958	2547SD		coil	Outer	2	4717904
1959-60	2837-39				1	4756511

Group 11.651 PANEL-PLATE, REAR SEAT CENTER ARM REST

1958	2547SD		PANEL		1	4714422
1958	2547SD		PLATE		1	4714419
1960	2837-39				1	4799764
1959	2837-39				1	4769964

Group 11.801 PANEL ASSY., FOOT REST

1953-54	All exc. 2571			1	4641649
---------	---------------	-------	-------	---	---------

Group 11.878 ESCUTCHEON, ROBE CORD

1953-54	2511-19-69, 2819-69 All			AR	4605687
1955	2519, 2819 D-19 SD			2	4605687
1956-57	2819-39 All			2	4605687
1953-55	2511-19-59, 2819-69				
	All	(8.908)	SCREW, robe cord escutcheon	(No. 10-32x7/8")	AR 147947
1956	2819-39 All	(8.908)		(No. 10-32x7/8")	4 147947
1957	2819-39 All	(8.977)		(No. 10-12x3/4")	4 168593

Group 11.898 ROBE CORD, FRONT SEAT BACK

1953	2511 D		trim 5361		2	4619174
1953-54	2569 D		trim 5360, 5450		1	4624672
1953-54	2569 D		trim 5361, 5451		1	4624671
1954	2569 D, 2869 D		trim 5460-62		1	4634413
1954	2569 D, 2869 D		trim 5461-63		1	4634414
1955	2819 D		trim 262		1	4634413
1955	2819 D		trim 263-299		1	4636510
1955	2819 D		trim 264-271		1	4655018
1955	2819 SD		trim 274-292		1	4659269
1955	2819 SD		trim 279-288-293		1	4659270
1956	2839 SD		trim 254-255		1	4674500
1956	2839 SD		trim 256-257		1	4674501
1957	2819 D		trim 215		1	4700747
1957	2819 D		trim 216		1	4700847
1957	2819 D		trim 217		1	4701779
1957	2819 SD-39 SD		trim 235-238		1	4699509
1957	2819 SD-39 SD		trim 236-239		1	4699510
1957	2819 SD-39 SD		trim 237-240		1	4699511
1957	2819 SD-39 SD		trim 247-248		1	4709469

Group 11.925 LAMP, DOME (LESS BULB)

1941-48	Exc. 2567		1	4115307
1958	2547, 2831-39 All	on side roof rail	2	4719318
1959	2439, 2837-39	on side roof rail	1	4719318
1959	2439, 2837-39	on side roof rail-w/switch		4751914 LH
1960	2111-19-35-37-39-45, 2337-39, 2411-19, 2735	(see note)	1	4692184

NOTE: 1st type use w/round type bulb.

Group 11.927 LAMP-REFLECTOR-RETAINER-SUPPORT, DOME

1950-52	2537 All	LAMP, rear corner-less lens	2	4589575
1959-60	2167, 2867 (11,938)	PLATE, rear bow dome lamp switch	1	4002769
1949-55	All exc. 2537-67, 2837-67	REFLECTOR AND SWITCH ASSY., dome lamp	1	4300981
1955	2537 D		1	4300981
1956-57	2711-19-37-62-63, 2819 All		1	4300981
1958	2731-39-41-49-93-94, 2849 All		1	4300981
1959-60	2111-19-35-37-39-45, 2337-39, 2411-19, 2735	(see note)	1	4233835
1960	exc. 2167, 2867	dome and reading lamp	1	4771211
1953-54	2537, 2837 All	REFLECTOR, rear corner lamp	2	4603601
1955-57	25/2764, 2837-39 All		2	4650248
1959-60	2145	rear qtr. courtesy lamp	1	4650248
1953-57	2567, 2867 All	REFLECTOR AND RIM, rear bow lamp	1	4577220
1958-60	2167, 2567, 2867 All		1	4746615
1958	2547, 2831-39 All	REFLECTOR AND SOCKET, dome lamp	2	4238063
1959-60	2439, 2837-39	roof rail lamp		4304265 RH
1959-60	2439, 2837-39	roof rail lamp-with switch		4786176 LH
1956-60	21/25/2867 All	SPACER, dome lamp reflector to bow	1	4644496
1956-57	2737-39-62 FC, 2819 SD	SUPPORT ASSY., dome lamp	1	4570292
1956-57	2737-39-62 FC, 2819 SD		1	4570292
1958	2731-39-41-49-93-94, 2849 All		1	4691091
1959-60	2111-19-37-39, 2337, 2411-19-39	dome lamp	1	4771215
1959-60	2135-45, 2735	dome lamp	1	4640638
1960	2111-19-37, 2337, 2411-19, 2837	dome and reading lamp	1	4770731
1960	2135-45, 2735	dome and reading lamp	1	4570292
1960	2139, 2339, 2439, 2839	dome and reading lamp	1	4771216

NOTE: 1st type use w/round type bulb.

Group 11.928 RIM, DOME LAMP

1941-48	All exc. 2567	less lens	1	4115921
1949-55	All exc. 2537-67, 2837-67	less lens	1	4168052
1956-57	2711-19-37-39-62-63, 2819 All	less lens	1	4168052
1958	2731-39-41-49-93-94, 2849 All		1	4168052
1959-60	2111-19-35-37-39, 2337-39, 2411-19, 2735 All		1	4233080
1960	All exc. 2167, 2867	dome and reading lamp-includes lens	1	4771319
1939-40	26-29 All exc. 2667	LENS, dome lamp	1	4115920
1940	2511-19		1	4115920
1940-52	2567		1	4102341
1941-48	All exc. 2567		1	4115920
1949-55	All exc. 2537-67, 2837-67		1	4168051
1950-52	2537	rear quarter corner lamp	2	4589622
1953-54	2537, 2837 All		2	4605664
1953-54	2567, 2867		1	4577221
1955-57	25/2764, 2837-39 All		2	4605664
1955-57	2867 All		1	4644417

1956-57	2711-19-37-39-62-63, 2819 All		1	4168051
1958	2731-39-41-49-93-94, 2849 All		1	4168051
1958	2547, 2831-39 All		2	4237709
1958	2567		1	4577221
1959-60	2111-19-35-37-39-45, 2337-39, 2411-19, 2735	dome lamp	1	4233081
1959-60	2145	rear qtr. courtesy lamp	1	4605664
1959-60	2167, 2867	rear bow dome lamp	1	4577221
1959-60	2439, 2837-39		2	4237709
1960	All exc. 2167, 2867	dome and reading lamp	1	4304351

Group 11.935 SWITCH, DOME LAMP

1942-48	All		1	4594201
1949-54	2537-67, 2837-67	All	1	4610315
1955	2867	rear bow dome lamp	1	4610315
1956-57	2764	DF side roof rail	2	4610313
1956	2837	SD rear qtr. corner lamp	1	4678339
1956	2837	SD rear bow dome lamp	1	4610315
1956-57	2839	SD rear qtr. corner lamp	1	4162151
1956	2867	rear bow dome lamp	1	4678340
1957	2837	SD rear qtr. corner lamp	1	4711631
1957	2867	All rear bow dome lamp	1	4711630
1958	2547, 2831-39	All SD rear qtr. corner lamp-black	1	4162151
1958	2567	rear bow dome lamp-grey	1	4741843
1958	2567	rear bow dome lamp-green	1	4741844
1958	2567	rear bow dome lamp-blue	1	4741845
1958	2567	rear bow dome lamp-red	1	4741846
1958	2567	SD rear bow dome lamp	1	4610313
1958	2831D-39D	rear qtr. corner lamp-grey	1	4741848
1958	2831D-39D	rear qtr. corner lamp-green	1	4741849
1958	2831D-39D	rear qtr. corner lamp-blue	1	4741850
1958	2831 D-39 D	rear qtr. corner lamp-red	1	4747072
1959-60	2145	rear qtr. courtesy lamp		4673705 LH
1959	2167	rear bow dome lamp	1	4768135
1959-60	2439, 2837-39	side roof rail lamp		4304105 LH
1959	2867	rear bow dome lamp	1	4610313
1960	2167, 2867	rear bow dome lamp	1	4610313

Group 11.938 PLATE, SIDE ROOF RAIL LAMP SWITCH

1955-57	25/2764DF	ESCUTCHEON, rear qtr. courtesy lamp	2	4002769
1959-60	2145		1	4767829

Group 11.950 SWITCH, DOME LAMP HINGE PILLAR

1941-54	All		2	4598597
1955-56	All	front door	2	1998022
1955-56	2819-30 All	rear door	2	4598597
1957-60	All	front door	2	4709879
1957-58	2793 D-93 SD, 2819-39, 49 SD			
1959-60	2735, 2839	rear door	2	1998748

Group 11.951 GASKET, DOME LAMP DOOR HINGE PILLAR SWITCH

1941-56	All	2	4598587
1957-60	All	AR	4709880